

Multilin B95^{Plus} Bus Protection System



Instruction manual

B95^{Plus} firmware revision: 1.00

GE publication code: GEK-113657

GE Digital Energy
650 Markland Street
Markham, Ontario
Canada L6C 0M1

Tel: +1 905 927 7070 Fax: +1 905 927 5098

Internet: <http://www.GEDigitalEnergy.com>



GE Multilin's Quality Management System is registered to ISO 9001:2008

QMI # 005094
UL # e83849

Copyright © 2012 GE Multilin Inc. All rights reserved.

Multilin B95^{Plus} Bus Protection System Instruction Manual for product revision 1.00.

Multilin B95^{Plus} Bus Protection System, EnerVista, FlexLogic, FlexAnalog, Digital Energy, Multilin, and GE Multilin are trademarks or registered trademarks of GE Multilin Inc.

The contents of this manual are the property of GE Multilin Inc. This documentation is furnished on license and may not be reproduced in whole or in part without the permission of GE Multilin. The manual is for informational use only and is subject to change without notice.

Part number: 1601-0015-A2 (August 2012)



GENERAL SAFETY PRECAUTIONS - B95^{Plus}

- The use of Omega-level safety shoes, safety gloves, safety glasses, and protective clothing are recommended during equipment installation, maintenance, and service.
- Failure to observe and follow the instructions provided in the instruction manual can cause damage to the equipment and can lead to property damage, personal injury, and/or death.
- Before attempting to use the equipment, review all danger and caution indicators.
- If the equipment is used in a manner not specified by the manufacturer or functions abnormally, proceed with caution. Otherwise, the protection provided by the equipment can be impaired and can result in damage and/or injury.
- Hazardous voltages can cause shock, burns, or death.
- Installation/service personnel must be familiar with general device test practices and electrical awareness. Safety precautions must be followed.
- Before performing visual inspections, tests, or periodic maintenance on this device or associated circuits, isolate or disconnect all live circuits and sources of electric power.
- Failure to power equipment off prior to removing the power connections can lead to exposure to dangerous voltages causing injury or death.
- All recommended equipment that can be grounded should be and must have a reliable and uncompromised grounding path for safety purposes, protection against electromagnetic interference, and proper device operation.
- Equipment grounds should be bonded together and connected to the facility's main ground system for primary power.
- Keep all ground leads as short as possible.
- The equipment ground terminal must be grounded at all times during device operation and service.
- In addition to the safety precautions mentioned, all electrical connections made must respect the applicable local jurisdiction electrical code.
- LED transmitters are classified as IEC 60825-1 Accessible Emission Limit (AEL) Class 1M. Class 1M devices are considered safe to the unaided eye. Do not view directly with optical instruments.
- Before working on current transformers (CTs), short-circuit them.

FCC/Industry Canada

This device complies with Part 15 of the FCC Rules and Industry Canada rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

L'appareil conforme aux CNR d'Industrie Canada applicable aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Multilin B95^{Plus} Bus Protection System

Table of contents

GETTING STARTED	Safety words and definitions.....	1
	Unpacking and inspection checklist	1
	Quick start	2
	For further assistance	2

PRODUCT DESCRIPTION	Device overview.....	3
	FlexLogic equations	6
	HardFiber overview.....	6
	Order codes	8
	Specifications	8
	Remote resources specifications.....	9
	Protection specifications	9
	Communications specifications	11
	Digital fault recorder specifications.....	12
	Front panel interface	13
	Security specifications	13
	Hardware specifications	13
	Test specifications.....	15
Environmental specifications	16	
Approvals and certification	16	
Dielectric strength.....	16	

INSTALLATION	Installing the unit in a rack.....	17
	Rear terminal and port layout	18
	Typical wiring diagram.....	19
	Power supply card (slot A).....	21
	Communications card (slot C)	22
	Main processor card (slot D).....	23
	Ethernet port	23
	IRIG-B port	24
Process cards (slot J and optionally slot F).....	24	

ENERVISTA SOFTWARE	Introduction.....	27
	Installing the EnerVista software	28
	Establishing communication via USB	28
	Establishing communication via Ethernet.....	31
	Adding sites and devices.....	32
	Connecting to a device	33
	Accessing settings.....	33
	Operand quick select	34
	Navigating long lists	35
	Expanding/collapsing table rows.....	35
	Viewing actual values.....	35
	Viewing event records	36
	Viewing transient records.....	37
	Settings files	37
	Deploying settings files to multiple devices using settings templates	38
	Enabling the settings template in offline mode.....	38
	Enabling the settings template in online mode.....	39
	Editing a settings template	40
	Adding password protection to a settings template	40
	Applying a settings template.....	41
	Removing a settings template.....	42
Bus replica graphical editor	42	
Securing and locking FlexLogic equations.....	47	
Locking FlexLogic equation entries.....	47	
Locking a settings file and FlexLogic equations to a serial number	48	
Settings file traceability	48	
<hr/>		
SETTINGS – GENERAL	Installation.....	51
	Power system	52
	User programmable self-tests.....	54
<hr/>		
COMMUNICATIONS	Communications overview	57
	Network settings	57
	Ethernet.....	57
	TFTP	61
	SNTP.....	62
	HTTP	63
	Viewing Ethernet actual values.....	64
	Viewing TCP/IP connection actual values	66
	Modbus communications.....	66
	Protocol.....	67
	User map	68
	DNP communications	69
	Protocol.....	69
	User point list	72
	IEC 60870-5-104 communications	73
	Configuring IEC 60870-5-104 settings.....	74
	Configuring IEC 60870-5-104 point lists	75
IEC 61850 communications	76	
GSSE/GOOSE configuration.....	76	
Server configuration.....	89	

GGIO1 status configuration.....	89
Viewing IEC 61850 actual values.....	90
Real time clock and IRIG-B.....	93
Virtual inputs.....	96
Communication logic operands.....	97

REMOTE RESOURCES

Field units.....	99
Settings.....	100
Auto populate.....	101
Actual values.....	102
FlexLogic operands.....	102
Field contact inputs.....	102
Settings.....	103
Actual values.....	104
FlexLogic operands.....	105
Field contact inputs chatter detection.....	105
Field contact outputs.....	106
Settings.....	107
Actual values.....	108
FlexLogic operands.....	109
Field latching outputs.....	110
Settings.....	110
Actual values.....	111
FlexLogic operands.....	112
Shared inputs and outputs.....	112
Shared input settings.....	113
Shared input actual values.....	114
Shared output settings.....	115
Shared output actual values.....	116
FlexLogic operands.....	116

PROTECTION

Bus protection overview.....	117
Bus source concept.....	117
Bus zone concept.....	118
Bus replica concept.....	119
Bus sources.....	120
General settings.....	121
CT settings.....	122
Bus configuration settings.....	125
Zone trip bus settings.....	129
End fault protection settings.....	130
Breaker failure settings.....	132
Instantaneous overcurrent settings.....	140
Inverse time overcurrent settings.....	141
Actual values.....	142
FlexLogic operands.....	144
Analog operands.....	145
Voltage sources.....	145
General settings.....	146
Voltage sources settings.....	147
Undervoltage settings.....	150
Actual values.....	151
FlexLogic operands.....	153

	Analog operands.....	153
	Bus differential.....	153
	General settings.....	155
	Operating characteristic settings.....	157
	Supervision settings.....	160
	Actual values.....	163
	FlexLogic operands.....	164
	Analog operands.....	165
	Bus replica graphical editor	165
	FlexLogic	165
	FlexLogic rules.....	167
	FlexLogic gates and operators.....	167
	FlexLogic equation editor.....	168
	FlexLogic timers.....	169
	Non-volatile latches.....	169
	Setting group control.....	171
	Isolators	172
	Settings.....	174
	Actual values.....	175
	FlexLogic operands.....	177
<hr/>		
DIGITAL FAULT RECORDER (DFR)	Event recorder	179
	Viewing records.....	179
	Transient recorder	180
	Settings.....	181
	Viewing records.....	186
	FlexLogic operands.....	188
<hr/>		
FRONT PANEL	Front panel overview	189
	Status LED.....	190
	Annunciator panel.....	190
	Operation.....	190
	Settings.....	192
	Self-test summary display operation	196
	Bus diagram operation.....	196
	Bus source template editor	197
	Dynamic symbols.....	199
	Static symbols.....	200
	Pre-configured mimic diagrams.....	201
	Metering summary.....	201
	Display properties	203
	Phasor display.....	204
<hr/>		
SECURITY	User and password management.....	205
	Local and remote passwords	206
	Access alarms	209
<hr/>		
CONFIGURE FLEXOPERANDS	Configure FlexOperands.....	211

PRODUCT INFORMATION	Serial number	213
----------------------------	---------------------	-----

MAINTENANCE	Test mode	215
	Self-tests	216
	Major self-tests	217
	Minor self-tests	218
	FlexLogic operands	220
	Set date and time	221
	Raw data viewer	222
	Analog inputs	223
	Contact and shared input/output	224
	Diagnostics	226
	Modbus analyzer	228
	Updating firmware	230
	Replace module	231

BUS REPLICA APPLICATION GUIDE	Static bus arrangements	233
	Dynamic bus arrangements	241
	Sectionalized bus	241
	Double-bus single-breaker	246
	Main and transfer bus	250
	Breaker bypass switches	255
	Check zones	256
	Undervoltage supervision	260
	Zone expansion/reduction and end fault protection	260
	Breaker failure	261

APPENDIX	Revision history	263
	Warranty	263

Multilin B95^{Plus} Bus Protection System

Chapter 1: Getting started

This section outlines the symbols used in the document, what is in the box, and general approach to set up the Multilin B95^{Plus} Bus Protection SystemTM.

Safety words and definitions

Before attempting to install or use the device, review all safety indicators in this document to help prevent injury, equipment damage, or downtime.

The following safety and equipment symbols are used in this document.



Indicates a hazardous situation which, if not avoided, will result in death or serious injury.



Indicates a hazardous situation which, if not avoided, could result in death or serious injury.



Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



Indicates practices not related to personal injury.

Unpacking and inspection checklist

Use this procedure to unpack and inspect the B95^{Plus}.

1. Inspect the packaging for physical damage.
2. Open it and inspect the B95^{Plus} for physical damage.
3. Check that the following items have been delivered:
 - Multilin B95^{Plus} Bus Protection System
 - GE EnerVistaTM CD (software and documentation)
 - Instruction Manual (if ordered)
 - Certificate of Calibration

- Test Report
 - EC Declaration of Conformity
4. View the rear nameplate of the product and verify that the correct model has been delivered.
 5. For product information, instruction manual updates, and software updates, visit the GE Multilin website at <http://gedigitalenergy.com/multilin>.
 6. If any of the contents listed are missing or there is physical damage to the product, contact GE Digital Energy immediately using the contact information in the For Further Assistance section.

Quick start

The process for installing the unit is as follows:

- Install the unit in a rack (see Installing the Unit in a Rack)
- Connect the power supply and wire the unit (see Typical Wiring Diagram)
- Install the EnerVista software on a computer (see Installing the EnerVista Software)
- Connect the computer to the unit using a USB or Ethernet cable. Use of a USB cable is recommended for setup because of ease of use, after which you can switch to Ethernet for faster communications. (See Establishing Communication via USB and see Establishing Communication via Ethernet. Setup using the USB cable is documented.)
- Configure the unit by accessing the **Settings** panels in the **Online Window** area of the EnerVista software. Use this document for information as you work through the settings panels.
- Configure user access (see Security)

If a device is not available, one can still familiarize oneself by installing EnerVista software and experimenting with the Offline Window features, skipping the steps involving a device.

Note that the chapters starting with Settings - General largely follow the structure displayed in the software.

For further assistance

For product support, contact the information and call center as follows:

GE Digital Energy
650 Markland Street
Markham, Ontario
Canada L6C 0M1
Worldwide telephone: +1 905 927 7070
Europe/Middle East/Africa telephone: +34 94 4854 88 54
North America toll-free: 1 877 547 8630
Fax: +1 905 927 5098
E-mail: multilin.tech@ge.com
Website: <http://www.gedigitalenergy.com/multilin/>

Comments about new features or modifications for specific requirements are welcome.

Multilin B95^{Plus} Bus Protection System


Chapter 2: Product description

This chapter provides an overview and technical specifications of the Multilin B95^{Plus} Bus Protection System.

Device overview

The Multilin B95^{Plus} Bus Protection System is a relay to detect faults on a bus. It measures currents connected to the bus and when it detects a fault on the bus, it sends signals to isolate the bus. When there is a fault on a bus, the entire bus goes down, making the B95^{Plus} crucial. The B95^{Plus} extends the UR^{Plus}-series product family and the HardFiberTM Process Bus product family to provide a distributed, low impedance, current differential protection solution for medium and high voltage large and reconfigurable buses.

Figure 1: Front view



The protection system consists of a distributed process interface (data acquisition and tripping) architecture using GE HardFiber Bricks, with centralized processing performed by the B95^{Plus}.

The functions of the B95^{Plus} include the following:

- Multi-zone differential protection with both restrained (dual-slope percent or biased) and unrestrained (unbiased or instantaneous) functions incorporated. Differential protection is fast and secure. Security is achieved by using a reliable current transformer (CT) saturation detection algorithm and a directional comparison operating principle. Security is further enhanced by support for redundant process interface (Bricks). Three-phase tripping is supported; differential protection operands are provided for individual phase tripping.
- Interfaces with up to eight HardFiber Bricks per process card. The B95^{Plus} can contain one or two process cards.
- Supports up to 12 bus sources per process card. A single bus source is used to interface a network element connection to the bus, such as a feeder, line, transformer, capacitor, or reactor. A single bus source is used to interface a bus tie disconnect. Two bus sources are used to interface a bus tie breaker.
- Dynamic bus replica functionality and multi-zone protection is supported allowing application of the B95^{Plus} to multi-section reconfigurable buses. A zone expansion/contraction to an open breaker feature is included.
- Check-zone functionality can be configured by programming one of the differential zones to enclose the entire bus.
- Supports up to two undervoltage functions per process card for differential protection supervision purposes.
- End-fault protection (dead-zone protection) is provided for each bus source.
- A breaker fail function with three-phase tripping support and fast resetting current detectors is provided for each bus source.
- An instantaneous phase overcurrent function is provided for each bus source for possible supervision purposes.
- An inverse time phase overcurrent function is provided for each bus source for possible backup protection.
- An isolator position resolution and monitoring feature monitors 48 isolators per process card.
- A CT trouble monitoring function is provided for each zone of differential protection.

Voltage and current metering are built into the relay as standard features, as fundamental frequency-only root mean square (RMS) scaled magnitude and angle (phasor).

Diagnostic features include an event recorder capable of storing 4,096 time-stamped events plus 4,096 time-stamped events per process card. Oscillography is user-programmable as to sampling rate (up to 128 samples per cycle), content, writing mode, and record length. The internal clock used for time stamping can be synchronized with an IRIG-B signal or using the simple network time protocol (SNTP) over Ethernet. This precise time stamping allows the sequence of events to be determined throughout the system. Events can also be programmed using FlexLogicTM equations to trigger oscillography data capture, which can be set to record the measured parameters before and after the event for viewing on a computer. These tools significantly reduce troubleshooting time and simplify report generation in the event of a system fault.

On the communications card, either of the two Ethernet ports can be used for supervisory control and data acquisition (SCADA) access, the programming of settings, and the monitoring of actual values. These two Ethernet ports have both 100Base-TX and

100Base-FX interfaces, and they can be used to provide fast, reliable communications in noisy environments. These ports support TFTP, SNMP, IEC 61850, Modbus/TCP, and IEC 60870 protocols. DNP 3.0 and IEC 60870 cannot be enabled at the same time.

A third Ethernet port supports engineering access using the EnerVista B95^{Plus} Setup™ software.

The B95^{Plus} intelligent electronic devices (IEDs) use Flash^{Plus} memory technology that allows field upgrading as new features are added.

The following single-line diagram illustrates the relay functionality using American National Standards Institute (ANSI) device numbers.

Table 1: ANSI device numbers and functions

Device	Function
87B	Percent bus differential
27	Undervoltage
50	Instantaneous overcurrent
50/74	CT trouble
50/87	Unrestrained bus differential
50EF	End fault protection
51	Time overcurrent
50BF	Breaker failure

Figure 2: ANSI device number schematic




Table 2: Other device functions

Function	Function
HardFiber Brick interface (8 Bricks per process card)	Differential zone expansion/contraction
Field contact inputs (144 per process card)	Event recorder
Field contact outputs (48 per process card)	Transient recorder (oscillography)
Current AC banks (12 per process card) Voltage AC banks (2 per process card)	Time synchronization via SNTP or IRIG-B
Dynamic bus replica	User-definable mimic, metering, and annunciator displays
End-fault protection	User-programmable self-test
DNP 3.0 or IEC 60870-5-104 communications	Virtual inputs (64)
IEC 61850 communications, including GOOSE and sampled values	Virtual outputs (96 plus 96 per process card)
Metering: current, voltage, tracking frequency	FlexLogic equations (512 lines plus 512 lines per process card of protection speed code)
Modbus communications	Non-volatile latches (16 plus 16 per process card)
Modbus user map	Setting groups (2)

Advanced functionality allows the user to access comprehensive information without having to navigate through conventional displays and keypads. Information displays on two graphical display panels on the front panel. One serves as a digital annunciator and the other, called the HMI, displays mimic diagrams, phasor plots, and other information.

The configurable, color LCD annunciator on the front panel eliminates the need for LEDs and separate annunciator devices. Any contact input, remote input, or internally generated logic operand can be assigned to each indicator, as well as any analog operand. Up to 288 indicators can be assigned. The display can be configured for 12, 24, or 48 indicators per page. A separate self-test message page on the annunciator panel displays error messages about device health.

The HMI panel provides easy access and visualization of device information, ranging from the graphical and numeric display of bus source current phasors, voltage source phasors, differential and restraint phasors, and tracking frequency, as well as a display of sequence of events and a transient records list. The HMI can display a mimic diagram that provides the status of each bus source's breaker and isolators. Many bay configurations can be realized through the setting of the device.

FlexLogic equations

FlexLogic refers to executable code developed by GE or you for use with the device. You can create or edit FlexLogic equations in order to customize the relay's behavior. You can subsequently view automatically generated logic diagrams.

HardFiber overview

The GE HardFiber Process Bus System allows copper wiring to be replaced in substation switchyards with optical fiber. The system includes all physical components required for its installation: relays; factory pre-terminated fiber cables; fiber crossconnect panels; factory connectorized copper cables; and switchyard I/O interface devices known as Bricks. The Bricks implement the concept of an IEC 61850 merging unit, expanded to optically connect relays with all types of input and output signals in the switchyard, not just instrument transformers. The relays are the proven GE Multilin Universal Relay (UR) series devices with a decade-long field record, and they incorporate all major applications from a simple


feeder relay to a sophisticated generator protection package. With the release of the B95^{Plus}, the HardFiber system can also be used for the protection of large and dynamic buses.

Figure 3: GE HardFiber Brick top view



The HardFiber system replaces copper wiring between power apparatus in the switchyard and protection and control devices in the control house with off-the-shelf components that use standard physical and logical interfaces. As such, it shortens deployment time, reduces labour requirements, facilitates work transfer, improves quality, simplifies procurement, and improves safety.

Figure 4: B95^{Plus} in control house and HardFiber Bricks in switchyard



Bricks, cables, and crossconnect panels can simultaneously connect to the B95^{Plus} relays and UR-series relays. For example, a Brick located in a feeder bay can be used by a D60 Line Distance Protection System protecting the feeder and a B95^{Plus} protecting the bus.

The B95^{Plus} is designed to work with GE HardFiber Bricks. Any references to Bricks in this manual refer to HardFiber Bricks.

Details of the HardFiber Bricks, cables, crossconnect panels, and protocols are contained in the HardFiber Process Bus System Reference Manual. Chapters 5 and 6 of the HardFiber manual do not apply to the B95^{Plus} because the B95^{Plus} has its own process card, settings, actual values, and self-test errors.

Order codes

The B95^{Plus} is a 19-inch horizontal rack-mount unit that consists of required and optional cards. For the B95^{Plus}, only process card F is optional.

Reading across the order code table, an example of an ordering code is B95P-HE-BX03SSX-XHXAPXPPX.



Order codes are subject to change without notice. See the GE Multilin ordering page at <http://store.gedigitalenergy.com/Multilin/front.asp> for the latest B95^{Plus} options.

For communications, the DNP option or the IEC 60870-5-104 option is ordered, not both.

Figure 5: Order codes

	B95P	*	*	*	**	*	*	*	*	A	B	C	E	F	G	H	J	K
Base	B95P																	
Front Panel Interface H		E																
Language			S															
Protection			B															
Automation				X														
Communications					01													
					02													
					03													
					04													
Metering					S													
Digital Fault Recorder						S												
Equipment Manager							X											
Harsh-Environment Coating								X										
Power Supply									H									
Peer-to-Peer Communications Module										X								
Communications Module											A							
UR ^{Plus} Process Card													X	X	X	X	P	X
(if only one process card, it must be in slot J)														P				

* single-digit ordering code
 ** double-digit ordering code

Each supports 8 Bricks and 12 bus/voltage sources

870788A1.CDR

After the unit is set up, the order code is viewable in the EnerVista software.

To view the order code:

1. In the **Online Window** area of the EnerVista software, navigate to **Actual Values > Product Information > Model Information**. Or view the code on the Product Information page on the front panel annunciator display.

Specifications

This section outlines specifications, which are subject to change without notice.

Remote resources specifications

REMOTE RESOURCE SPECIFICATIONS

Number of field units (bricks):	8 per process card
Number of field contact inputs:	18 for each brick
Number of field contact outputs:	6 for each brick
Number of field latching outputs:	1 for each brick
Number of shared inputs:	16 per process card
Number of shared outputs:	16 per process card

Protection specifications

BUS DIFFERENTIAL PROTECTION

Comparator algorithm:	low impedance differential with through current restraint, direction and CT saturation supervision (same as B90)
Number of differential zones:	six 3-phase zones
Maximum number of currents:	total dynamic number of bus source to zone connections closed at any one moment in time up to 120
CT ratio compensation range:	32:1
Supervision:	2 user-programmable conditions per zone
Pickup level:	0.050 to 2.000 pu on bus base in steps of 0.001 pu
Low slope:	15 to 100% in steps of 1%
High slope:	50 to 100% in steps of 1%
Low breakpoint:	1.00 to 30.00 pu on bus base in steps of 0.01 pu
High breakpoint:	1.00 to 30.00 pu on bus base in steps of 0.01 pu
Dropout level:	<98% of pickup
Level accuracy:	
0.1 to 2.0 × bus base:	±0.5% of reading or ±1% of bus base (whichever is greater)
>2.0 × bus base:	±1.5% of reading
Operating time:	<1 power system cycle
High set (unbiased) level:	2.00 to 99.99 pu in steps of 0.01 pu
High set (unbiased) operate time:	<1 power system cycle

CT TROUBLE MONITORING

Number of CT trouble detectors:	1 per bus differential zone, that is, 6
Responding to:	differential current
Pickup level:	0.020 to 2.000 pu in steps of 0.001 pu
CT trouble operate delay:	1.0 to 60.0 s in steps of 0.1 s
Supervision trouble delay:	0.00 to 5.00 cycles in steps of 0.25

BUS REPLICA

Features:	Dynamic bus source current assignment to each zone. Dynamic zone trip assignment to each bus source. Dynamic blocking of zones on CT bypassed. 3 user-programmable auxiliary zone trip inputs. 3 user-programmable bus source trip inputs. Dynamic zone expansion/reduction.
-----------	---

BUS SOURCES

Number of bus sources:	12 per process card included in the order code
Current inputs:	3-phase currents
CT rated primary:	1 to 65000 A
CT rated secondary:	1 or 5 A
Nominal frequency:	50 or 60 Hz

BREAKER FAILURE PROTECTION

Number of BF protections:	1 per bus source
Mode:	3-pole initiate only
Current supervision:	phase current
Current supervision pickup:	0.01 to 30.00 pu on CT base in steps of 0.01 pu
Current supervision dropout:	<98% of pickup
Current supervision accuracy:	
0.1 to 2.0 × CT rating:	±0.75% of reading or ±2% of CT base (whichever is greater)
above 2 × CT rating:	±2.5% of reading
Current supervision reset time:	< 0.5 cycles
Coordination delay timers:	0 to 60 s in steps of 1 ms
Delay accuracy:	±3% or ±4 ms, whichever is greater
Breaker position inputs:	advanced and final position contact inputs, each optionally dual-redundant
Stages:	current + advanced breaker position status + time current + time final breaker position + time opening resistor protection

INSTANTANEOUS PHASE OVERCURRENT

Number of IOC protections:	1 per bus source
Comparators:	3 phase, sensing fundamental frequency current
Pickup level:	0.00 to 30.00 pu on CT base in steps of 0.01
Dropout level:	<98% of pickup
Level accuracy:	
0.1 to 2.0 × CT:	0.5% of reading or 1% of CT base (whichever is greater)
above 2.0 × CT:	1.5% of reading
Pickup delay:	0 to 60 s in steps of 1ms
Reset delay:	0 to 60 s in steps of 1ms
Delay accuracy:	±3% or ±4 ms (whichever is greater)
Operate time:	<1 power system cycle at 3 × pickup

INVERSE TIME PHASE OVERCURRENT

Number of TOC protections:	1 per bus source
Comparators:	3 phase, sensing fundamental frequency current
Pickup level:	0.01 to 30.00 pu on CT base in steps of 0.01 pu
Dropout level:	<98% of pickup
Level accuracy:	
0.1 to 2.0 × CT:	0.5% of reading or 1% of CT base (whichever is greater)
above 2.0 × CT:	1.5% of reading
Curve shapes:	IEEE Moderately/Very/Extremely Inverse; IEC (and BS) A/B/C and Short Inverse; GE IAC Inverse, Short/Very/Extremely Inverse; I2t; Definite Time (0.01 s base curve)
TD multiplier:	0.00 to 600.00 in steps of 0.01
Reset type:	instantaneous or timed (per IEEE)
Timing accuracy:	±3% or ±40 ms (whichever is greater)

END FAULT PROTECTION

Number of EFPs:	1 per bus source
IOC pickup level:	0.01 to 30.00 pu in steps of 0.01 pu
IOC dropout level:	<98% of pickup
Level accuracy:	
at 0.1 to 2.0 × CT:	0.5% of reading or 1% of nominal (whichever is greater)
above 2.0 × CT:	1.5% of reading
CB open delay timer:	0.10 to 60 s in steps of 1 ms
End fault dropout timer:	0 to 60 s in steps of 1 ms
Time accuracy:	±3% or ±8 ms (whichever is greater)

VOLTAGE SOURCES

Number of voltage sources:	2 per process card included in the order code
Voltage inputs:	3-phase voltages, wye or delta
VT ratio:.....	1.00 to 24000.00
VT rated secondary:	25.0 to 240.0 V
Nominal frequency:	50 or 60 Hz

UNDERVOLTAGE PROTECTION

Number of UV protections:.....	2 per process card
Comparators:.....	3 phase-to-phase and 3 phase-to-ground
Pickup level:	0.50 to 1.50 pu in steps of 0.01
Dropout level:.....	>102% of pickup
Level accuracy:.....	±0.5% of reading from 10 to 208 V
Operate time:.....	<1 power system cycle at 0.5 x pickup

ISOLATORS

Number of isolators:.....	48 per process card
Isolator status inputs:	form "a" and form "b" contact inputs, each optionally dual-redundant
Configurable failsafe modes:	open, closed, last valid state
Monitoring:.....	alarm on inconsistent inputs persisting longer than a user set time

FLEXLOGIC DESIGN

Programming language:	Reverse Polish Notation with graphical visualization
Inputs:.....	Any logical variable, contact, or virtual input
Number of timers:.....	32 per process card plus 32 on main card
Timer pickup delay:.....	0 to 1000 hrs in steps of 1 ms
Timer dropout delay:.....	0 to 1000 hrs in steps of 1 ms
Timer accuracy:.....	± the sum of 1/8 power system cycle and 1% of the timer setting
Virtual outputs:	96 per process card plus 96 on main card
Non-volatile latch latches:.....	16 per process card plus 16 on main card
Non-volatile latch modes:.....	Set-dominant or reset-dominant
Lines of code:.....	512 per process card plus 512 on main card
Supported operations:	NOT, XOR, OR (2 to 16 inputs), AND (2 to 16 inputs), NOR (2 to 16 inputs), NAND (2 to 16 inputs), latch (reset-dominant), edge detectors, timers
Execution speed:.....	recalculated at 8 times per power system cycle
Card-to-card operand delay:	up to 1/8 power system cycle

SETTINGS GROUPS

Number of settings groups:	2
Grouped settings:	threshold type settings for bus source, voltage source, and bus differential

Communications specifications**MODBUS USER MAP**

Number:	up to 256 Modbus addresses
Programmability:	any setting or actual value in decimal

REMOTE INPUTS (IEC 61850 GSSE/GOOSE)

Input points:.....	64
Remote devices:.....	32
Default states on loss of communications:.....	On, Off, Latest/Off, Latest/On
Remote double-point status inputs:	16

Front panel interface

ANNUNCIATOR MAIN DISPLAY

Annunciator pages:	
Indicators:	288
Indicators per page:	12 to 48
Pages:	up to 24
Sequence:	manual reset, locking
Off indication:	alarm inactive and reset
Flashing indication:	alarm active and not acknowledged, alarm inactive and not acknowledged
On indication:	alarm active and acknowledged, alarm inactive and not reset
Priority:	by active window and page number
Data storage:	non-volatile memory
Other annunciator displays:	
Product information page:	displays order code, serial number, relay ID, configuration name and date, and firmware version and date
Communication status page:	displays remaining connections for MMS, Modbus, DNP, PMU, IEC. Also displays Modbus slave addresses and TCP/IP port. Also displays for Ethernet ports their MAC address, IP addresses, subnet mask, and gateway.
Self-test summary page:	displays all active or unacknowledged B95 ^{Plus} device - related self-test messages in a sequence of events format

HMI DISPLAY

Mimic diagram:	mimic diagrams display bus source breaker and isolator status
Phasors:	digital and phasor diagram display of present voltage source phase voltages, bus source phase currents, zone differential currents, and zone restraint currents, both magnitudes and angles
Sequence of events:	displays the stored events record
Transient records:	list of stored transient records

MULTI-LANGUAGE SUPPORT

Languages:	English
------------------	---------

Security specifications

SECURITY SPECIFICATIONS

Features:	Two access levels (Command and Setting), with separate remote and local passwords for each level. Dictionary attack deterrence. Programmable authorization control.
-----------------	---

Hardware specifications

PROCESS I/O

Number of process bus ports:	8 per process card
Port type:	100Base-BX-D, in SFP package with LC 50/125 μm multi-mode connector
Transceiver diagnostics:	per SFF-8472
Brick synch frame jitter:	$\pm 1 \mu\text{s}$

ETHERNET PORTS

Standard: 2 ports on the communications card supporting SNMP, TFTP, Modbus TCP, DNP 3.0, IEC 60870-5-104, IEC 61850, or EnerVista software. 1 port on main processor card supporting EnerVista software.

Media types: 100Base-FX or 10/100Base-TX

100Base-FX type:

Power budget: 10dB

Maximum input power: -14 dBm

Receiver sensitivity: -30 dBm

Typical distance: 2.0 km

10/100Base-TX type: RJ45 connector

SNMP clock synchronization: <10 ms typical

USB FRONT PORT

Standard: type B USB connector for EnerVista software

IRIG-B INPUT

Amplitude modulation: 1 to 10 V pk-pk

DC shift: TTL

Input impedance: 50 kΩ

Isolation: 2 kV

An internal clock free runs when neither the IRIG-B signal nor SNMP is present.



CRITICAL FAILURE RELAY

Type: Form-C, normally energized

Make and carry for 0.2 s: 10 A as per ANSI C37.94

Carry continuous: 6 A

Break at L/R of 40 ms: 0.25 A DC at 125 V DC; 0.125 A DC at 250 V DC

POWER SUPPLY

Nominal DC voltage: 125 to 250 V

Minimum DC voltage: 80 V

Maximum DC voltage: 300 V

Nominal AC voltage: 100 to 240 V at 50/60 Hz

Minimum AC voltage: 80 V at 48 to 62 Hz

Maximum AC voltage: 275 V at 48 to 62 Hz

Voltage withstand: 2 × highest nominal voltage for 10 ms

Voltage loss ride-through: 200 ms duration at nominal input voltage

Power consumption: 65 VA maximum

Control power wiring: 14 AWG or larger

Control power protection: Has internal non-user replaceable 4 Amp "slo blo" fuse. Recommend external upstream disconnect on both sides. Recommend external overcurrent protection of 5 to 10 Amps.

Control power terminal connection: Use suitable ring terminal, torque terminal to 9 in lb (1 N-m)

Grounding connection: 10 AWG or larger wire or braid, independent and direct-to-cubicle ground bus

PROCESS CARD OPTICAL

Number of transceivers:8

Transceiver type:.....transmit 1550 nm, receive 1310 nm, 100 Mbps, bidirectional single-fiber 50/125 µm multimode module (complies with IEEE 802.3 standard 100Base-BX-D)

Optical transmit power:.....-14 to -8 dBm

Maximum optical input power:-8 dBm

Optical receiver sensitivity:.....-30 dBm

Termination:LC fiber connector

Laser class:Class 1. Class 1 devices are considered safe to the unaided eye. Do not view directly with optical instruments.

**Test specifications**

Test	Reference standard	Test level
Dielectric voltage withstand	EN 60255-5	2.3 KV
Impulse voltage withstand		5 KV
Insulation resistance		500 V DC
Damped oscillatory	IEC 61000-4-18 / IEC 60255-22-1	2.5 KV CM, 1 KV DM
Electrostatic discharge	EN 61000-4-2 / IEC 60255-22-2	Level 4
Radio frequency (RF) immunity	EN 61000-4-3 / IEC 60255-22-3	Level 3
Fast transient disturbance	EN 61000-4-4 / IEC 60255-22-4	Area B
Surge immunity	EN 61000-4-5 / IEC 60255-22-5	Level 3
Conducted RF immunity	EN 61000-4-6 / IEC 60255-22-6	Level 3
Voltage interruption and ripple DC	IEC 60255-11	15% ripple, 200 ms interrupts
Radiated and conducted emissions	CISPR 11 / CISPR 22 / IEC 60255-25	Class A
Sinusoidal vibration	IEC 60255-21-1	Class 1
Shock and bump	IEC 60255-21-2	Class 1
Seismic	IEC 60255-21-3	Class 2
Power magnetic immunity	IEC 61000-4-8	Level 5
Pulse magnetic immunity	IEC 61000-4-9	Level 4
Damped magnetic immunity	IEC 61000-4-10	Level 4
Voltage dip and interruption	IEC 61000-4-11	0, 40, 70, 80% dips, 250/300 cycle interrupts
Voltage ripple	IEC 61000-4-17	15% ripple
Ingress protection	IEC 60529	IP30 front
Environmental (cold)	IEC 60068-2-1	-40°C / 16 hours
Environmental (dry heat)	IEC 60068-2-2	85°C / 16 hours
Relative humidity cyclic	IEC 60068-2-30	6 day, variant 1
Electrostatic discharge	IEEE ANSI C37.90.3	8 KV contact, 15 KV air
Damped oscillatory	IEEE ANSI C37.90.1	2.5 KV, 1 MHz
Fast transient disturbance	IEEE ANSI C37.90.1	4 KV, 2.5 KHz
RF immunity	IEEE ANSI C37.90.2	20 V/m, 80 MHz to 1 GHz
Safety	UL 508	e83849 NKCR
	UL C22.2-14	e83849 NKCR7
	UL 1053	e83849 NKCR

Environmental specifications

TEMPERATURE

Cold: IEC 60028-2-1, 16 hours at -40°C
 Dry heat: IEC 60028-2-2, 16 hours at 85°C
 Humidity: up to 95°C non-condensing at 55°C, as per IEC 60068-2-30
 variant 1, 6 days
 Storage temperature: -40 to 85°C
 Operating temperature: -40 to 60°C

OTHER ENVIRONMENTAL SPECIFICATIONS

Altitude: up to 2000 m
 Insulation class: I
 Overvoltage category: II
 IP rating: IP30
 Pollution degree: II

Approvals and certification

APPROVALS AND CERTIFICATION

Compliance: CE, CSA, UL, ISO

Compliance	Applicable council directive	According to
CE	Low voltage directive	EN 60255-27 (normative sections)
	EMC directive	EN 60255-26 / EN 50263
		EN 61000-6-5 (Area G)
C-UL-US	---	UL 508
		UL 1053
		C22.2 No 14
ISO	---	ISO 9001:2008

Dielectric strength

Dielectric strength is the maximum electric strength that can be sustained without breakdown. It is measured in volts.

The dielectric strength of the B95^{Plus} hardware is outlined in the table.

Table 3: Dielectric strength for the B95^{Plus}

Function	Terminals		Dielectric strength
	from	to	
Power supply module	high (+), low (+), (-)	chassis	2,000 V AC for 1 minute
Power supply module	relay terminals	chassis	2,000 V AC for 1 minute
Main CPU	RJ45 port	chassis	1,500 V AC for 1 minute
Main CPU	IRIG-B port	chassis	2,000 V AC for 1 minute
Front panel	USB port	chassis	2,000 V AC for 1 minute
Communications module	RJ45 ports	chassis	1,500 V AC for 1 minute

Filter networks and transient protection clamps are used in the hardware to prevent damage caused by high peak voltage transients, radio frequency interference (RFI), and electromagnetic interference (EMI).

NOTICE

The protective components can be damaged by application of the test voltage for a period longer than the specified minute.

Multilin B95^{Plus} Bus Protection System

Chapter 3: Installation

This section describes the physical and electrical installation of the Multilin B95^{Plus} Bus Protection System.

Installing the unit in a rack

The B95^{Plus} is a 19-inch horizontal rack-mount unit. The front faceplate is hinged to allow access to removable modules. This design allows the relay to be upgraded and repaired by qualified service personnel.

The cutout dimensions for panel mounting and case dimensions are shown in the following figures. When planning the location of your panel cutout, provide space for the faceplate to swing open from the top. Under normal operating conditions, the unit has no special cooling requirements, but adequate clearance must be provided to the bottom, sides, and top of the device to allow air to circulate. Do not block the ventilation openings of the chassis. Do not place other equipment or panels in such a way to obstruct airflow around the chassis.

The unit is typically installed in the control center.

To install the unit:

1. Mount the unit in a 19-inch rack such that the front faceplate sits semi-flush with the panel or switchgear door, allowing the operator access to the front panel keys and USB communications port. Leave a 1U (1 rack-unit) space below the chassis for ventilation and for the front panel to swing open from the top without obstruction. No extra space is required above the chassis. Clearance is provided by the shape of the mounting plate. Do not install other equipment or panels in such a way to obstruct this clearance.
2. Secure the unit to the panel using the four screws supplied with the relay.
3. Wire the unit as outlined in the Typical Wiring Diagram section.

Figure 1: Panel cutout dimensions






Figure 2: Dimensions



Rear terminal and port layout

The back of the B95^{Plus} chassis is shown in the figure.

Figure 3: Rear terminal view



Printed circuit cards/modules are housed in slots. The slots are labelled from right to left: A, B, C, D, E, F, G, H, J, K. Active slots are as follows:

- **Slot A** – Contains the power supply module, which conditions the AC or DC station service power such that it is suitable for internal use, and contains the critical failure relay. Terminals on the power supply module are designated 1 through 10 with a slot letter (slot A) prefix.
- **Slot C** – Contains the communications card, which handles all station bus type Ethernet communications for the relay. The Ethernet ports on the communications card are port 2 on the top and port 3 on the bottom.
- **Slot D** – Contains the main card, which handles central processing tasks. Ports from top to bottom are IRIG-B and Ethernet port 1.
- **Slot F** – Optional – Same as slot J, if present
- **Slot J** – Contains a process card to connect to up to eight HardFiber Bricks and implement protection and control elements for 12 bus sources and two voltage sources. The port number assignments are two characters, assigned in order by card slot position (slot F or J) and the row number (1 through 8, top to bottom).

Other slots are empty.


Typical wiring diagram

This section outlines the electrical installation of the B95^{Plus}. For Brick and fiber cable connections, see the HardFiber manual.

The unit can be connected to AC or DC power. Use of DC power is typical in the field.

The following wiring diagram provides an example of how to wire the device. Actual wiring varies according to application.

Figure 4: Typical wiring diagram



870749A1.CDR



Ensure that power is not live when connecting the wires to the unit, else injury or death can result.

To connect power:

1. Wire the unit according to the wiring diagrams.

After wiring the unit, to continue with installation skip ahead to Installing the EnerVista software section.

Power supply card (slot A)

The power supply card in slot A provides power to the unit. It can be connected to any of the following standard power sources:


- DC power — 110, 125, 220, or 250 V DC
- AC power — 115 or 230 V AC

Figure 5: Slot A on back of unit



The setup is shown schematically in the figure.

Figure 6: Control power connection



NOTICE

Power supplied to the unit must be connected to the matching power supply terminal of the unit. If the voltage is applied to the wrong terminals, damage can occur.

NOTICE

The **B95^{Plus}**, like almost all electronic relays, contains electrolytic capacitors. These capacitors are well-known to be subject to deterioration over time if voltage is not applied periodically. Avoid deterioration by powering up the unit once a year.

The power supply card provides a critical failure relay, with form-C contacts that are energized once control power is applied and the relay successfully boots up with no critical self-test failures. If ongoing self-tests detect a critical failure or power is lost, then the critical failure relay de-energizes. This feature gives external indication when the relay has failed.

Extensive filtering and transient protection has been incorporated into the unit to ensure reliable operation in harsh industrial environments. Transient energy is removed from the relay and conducted to ground via the ground terminal. This terminal must be connected to the cubicle ground bus using a 10 AWG or larger stranded wire or ground braid. Do not daisy-chain grounds with other relays or devices. Each is to have an independent and direct connection to the ground bus.

The control power to the power supply card is protected by a non-replaceable 4 Amp slo-blo fuse. 14 AWG or larger stranded wire is recommended for control power connection. A ring terminal is recommended to ensure integrity of the connection. The rated torque for the terminal screw is 9 in lb (1 N m). External downstream disconnects and external overcurrent protection of 5 to 10 Amps are recommended for both control power inputs.

Communications card (slot C)

The communications card has two Ethernet ports designated as ports 2 and 3. They allow the B95^{Plus} to communicate at high speed (100 Mbps) with gateways, other relays, and computers running the EnerVista software. The ports are independent of each other. They run all protocols supported by the relay.

Each port supports IEEE 802.3 100Base-FX on an ST fiber connector and IEEE 802.3 100Base-TX on an RJ45 copper connector. Only one of these two Ethernet media types can be used on a given port at a given time; the relay automatically recognizes and uses the particular media connected on each port.


The optical fiber sizes supported are 50/125 μm and 62.5/125 μm ; the wavelength is 1310 nm. IEEE 802.3 100Base-FX light levels are used, and as such can be connected directly to another 100Base-FX device without an attenuator. When splicing optical fibers, the diameter and numerical aperture of each fiber must be the same. In order to engage or disengage the ST connector, only a quarter turn of the coupling is required.



Ensure that the dust covers are installed when the fiber is not in use. Dirty or scratched connectors can lead to high losses on a fiber link.

The figure shows slots D and C on the rear of the unit.

Figure 7: Slots D and C on rear of unit



Main processor card (slot D)

The main processor module contains ports for Ethernet communications and IRIG-B connection.

Ethernet port

Ethernet ports allow the B95^{Plus} to communicate at high speed (100 Mbps) with gateways and computers running the EnerVista software. The main processor card has one Ethernet port designated as port 1 to distinguish it from ports 2 and 3 on the communications card. Port 1 is typically used as the main Ethernet connection between the unit and the network. It is intended for engineering services, such as settings management and historical record retrieval, and so runs TFTP, FTP, HTTP, SNMP, and Modbus TCP/IP. This includes the ability to interface with the EnerVista B95^{Plus} Setup software for settings management, monitoring, and recovering historical records.

The port supports IEEE802.3 100Base-FX on an ST fiber connector and IEEE 802.3 100Base-TX on an RJ45 copper connector. Only one of these two Ethernet media types can be used on the port at a given time; the relay automatically recognizes and uses the particular media connected.

The optical fiber sizes supported are 50/125 μm and 62.5/125 μm ; the wavelength is 1310 nm. IEEE 802.3 100Base-FX light levels are used, and as such can be connected directly to another 100Base-FX device without an attenuator. When splicing optical fibers, the diameter and numerical aperture of each fiber must be the same. In order to engage or disengage the ST connector, only a quarter turn of the coupling is required.



Observing any fiber transmitter output can cause injury to the eye.




Ensure that dust covers are installed when the fiber is not in use. Dirty or scratched connectors can lead to high losses on a fiber link.

IRIG-B port

IRIG-B is a standard time code format that allows stamping of events to be synchronized among connected devices within one millisecond. The IRIG time code formats are serial, pulse width-modulated codes that can be either DC level shifted or amplitude modulated (AM).

Third-party equipment is available for generating the IRIG-B signal. This equipment can use a global positioning system (GPS) satellite system to obtain the time reference so that devices at different locations can also be synchronized.

Figure 8: IRIG-B connection



Other options are to use simple network time protocol (SNTP) and the internal clock.

For additional information, refer to:

[Real time clock and IRIG-B](#) on page 93

Process cards (slot J and optionally slot F)

The unit comes with one or two process cards, these being slots J and F. They are used to connect to the GE HardFiber Bricks.

Each process card contains eight optical fiber Ethernet ports, each of which can interface with a Brick, through which the B95^{Plus} acquires power system voltage and current waveform information, contact input information (such as isolator and breaker status), and through which the B95^{Plus} issues breaker trip commands.

In B95^{Plus} units with a single process card, the card is installed in slot J. In relays with two process cards, the cards are installed in slots F and J. Process card ports are designated with the card's slot number followed by the port number on that card. The port numbers run from 1 through 8, top to bottom. For example, the top port on the process card in slot J is designated "J1," and the bottom port on the process card in slot F is designated "F8."

All process bus ports comply with IEC 802.3 100Base-BX, but with LC connectors and supporting multimode fiber. More detail on the fiber and the communications profile of IEC 61850 are contained in the HardFiber Process Bus System Reference Manual.



Ensure that the dust covers are installed when the fiber is not in use. Dirty or scratched connectors can lead to high losses on a fiber link.

Figure 9: Process card J



Multilin B95^{Plus} Bus Protection System

Chapter 4: EnerVista software

The GE EnerVista software supplied with the Multilin B95^{Plus} Bus Protection System provides tools to configure, monitor, maintain, and integrate information generated.

Introduction

The EnerVista B95^{Plus} Setup software provides a graphical user interface (GUI) to configure, monitor, and maintain the B95^{Plus} connected locally to the computer or over local or wide area networks.

The software can be used in offline mode (not communicating with a B95^{Plus}) or online mode (communicating with a B95^{Plus}). In offline mode, a device settings file can be created or configured for eventual downloading to the B95^{Plus}. In online mode, the current B95^{Plus} settings can be browsed, individually modified, uploaded, or downloaded. In addition, the relay's actual values can be monitored and historical records recovered and viewed utilizing real-time communication.


The EnerVista B95^{Plus} Setup software is provided with every B95^{Plus} relay and available for download on the GE website. It runs on computers with Microsoft Windows 2000 or later.

This chapter outlines how to install the software, then provides a summary of the software interface features. After installing the software, you connect via USB or Ethernet cables, and work your way through the menus to configure the B95^{Plus}. The individual functions are described in subsequent chapters. Content of this manual is also contained in the online Help accessible from the main menu.

The following figure shows the main software window. The display depends on the features ordered, which means that features documented display in the software when the unit was purchased with them.

The software supports drag-and-drop functionality. For example, files dropped in the selected device in the **Online Window** area are sent automatically to the device.

Figure 1: EnerVista software main window



Installing the EnerVista software

The software can be installed on a computer running Windows 2000 or later.

To install the EnerVista B95^{Plus} Setup software from the Internet or the CD:

1. To download, access <http://www.gedigitalenergy.com/multilin/>. Use **Product Lookup** to navigate to the B95^{Plus} page. Under **Resources**, select **Software**. Click the EnerVista B95^{Plus} Setup software entry. Enter the requested information, then click the download button.
2. To install from the download or CD, locate and click the EnerVista B95^{Plus} Setup file.

The software installs in the directory selected and a shortcut to the Windows desktop and in the Windows start menu is created. Use either the desktop shortcut or start menu to launch the software.



Establishing communication via USB

The easiest way to establish communication between the EnerVista software and the B95^{Plus} for the first time is to use the USB interface located on the front of the unit. Once established, you can then configure settings for the Ethernet ports.

Figure 2: Connecting computer to unit via USB




870823A2.CDR

To set up the B95^{Plus} using the USB port:

1. Turn on the computer and power up the B95^{Plus}. The B95^{Plus} takes a few minutes to start up and run self-tests; a test summary displays when ready.
2. With both the computer and B95^{Plus} powered on, connect a USB cable between them. On the B95^{Plus}, plug the cable into the lower port on the front panel.
3. The first time that the computer is connected, a hardware configuration wizard opens. Complete the wizard. For the driver location, browse to the EnerVista B95^{Plus} Setup software location and locate the **USB Driver** folder that contains the SerialUSB.inf driver file. The path is typically **C:\Program Files\GE Power Management\B95Plus\USB Driver**, or for Windows 7 64-bit **C:\Program Files\GE Power Management\B95Plus\USB Driver 64-bit**


If an error displays and the wizard does not complete, the Multilin Relay USB Serial Emulation driver software is being blocked. The following fix uses Windows XP Service Pack 3 as an example. Access the **Control Panel** application in Windows, then click **System**, click the **Hardware** tab, then click the **Driver Signing** button. Change the setting to **Warn** or **Ignore** (see figure). Then restart the hardware wizard in the Control Panel by clicking **Administrative Tools**, then **Computer Management**, then **Device Manager**, and search for the **GE Protective Relay** entry. Reinstall the driver.

Figure 3: Unblocking driver installation on a Windows XP computer




4. Launch the EnerVista B95^{Plus} Setup software. Then click the **Quick Connect** button on the left of the EnerVista software window. In the window that displays, select **USB** in the **Interface** box and **Multilin Relay USB Serial Emulation** in the **USB Device** box. Click the **Connect** button.

Figure 4: Using the USB port to establish communication to the B95^{Plus}



5. Once the software has read the relay's order code, the message "Device has been successfully added to the online tree under the site Quick Connect" displays. This verifies that communication has been established between the software and the relay.


Figure 5: Successful installation message



6. In the software, click **OK** and then expand the menu entry by clicking the **+** symbol beside an entry on the left side. You double-click a page name to open the panel.

To continue configuring the unit, in the **Online Window** area on the left side of the software, access **Settings** and work your way through each panel. The software display depends on the B95^{Plus} ordered; some features documented may not appear in your software interface. Use this document for information on each panel. Because the first panel is the **Installation** panel, skip ahead to that section. Leave the USB cable connected until you configure the IP address for the Ethernet port in the next section. You configure entries such as SNTP, Modbus, and DNP only if you intend to use them.

Figure 6: Starting configuration



Establishing communication via Ethernet

There are two ways to establish communication for the first time between the EnerVista software on the computer and the B95^{Plus}: USB port or Ethernet port. You typically connect using a USB cable, configure the IP addresses of the Ethernet port, then use Ethernet for regular use of the unit. This section describes how to connect via Ethernet.

There are two Ethernet cable options. Use standard (blue) Ethernet cables to connect the computer and the relay to the same Ethernet network. Or, use a crossover cable (typically red) to connect the computer directly to one of the relay's Ethernet ports.

Port 1, which is the Ethernet port on the main processor card in slot D, is recommended for communication with the computer.

When using the crossover cable to connect the relay to the computer:

1. Manually configure Windows to use an IP address that is in the same subnet as the relay. A straight forward way to do this set the computer's IP address to one count greater than that of the relay's port. The computer's subnet mask can be set to match the relay's mask.
2. If computer settings have been changed to support direct connection via a crossover cable, restore them when finished with the connection.

When using regular Ethernet cables to connect the relay and computer to a switched network, configure the relay’s Ethernet port settings with an IP address, subnet mask, and gateway address compatible with the network using the USB communications described in the preceding section. These settings are typically assigned by the network administrator and entered into the relay.

1. Connect the Ethernet cable to the back of the unit.
2. In the software, click the **Quick Connect** button on the left. In the window that displays, select **Ethernet** in the **Interface** box, and enter the relay’s IP address. Click the **Connect** button. The unit is now configured to communicate with the computer using Ethernet.

To view the relay’s IP address when the B95^{Plus} is already in operation:

1. On the relay’s front panel, press the **Next Page** button below the annunciator display to the Communications Status page to view the IP address of the relay’s Ethernet port chosen for communication.

Figure 7: Viewing the IP address on the unit

COMMUNICATION STATUS			
Remaining Connections			
MMS	5	Modbus Address: 1	
Modbus	3	Modbus IP Port: 502	
DNP	0		
PMU	N/A		
IEC	N/A		
	Port 1	Port 2	Port 3
IP Address	3.94.248.245	192.168.252.252	192.168.253.253
Subnet Mask	255.255.255.0	255.255.255.0	255.255.255.0
Gateway	3.94.248.1	0.0.0.0	0.0.0.0
MAC Address:	00 A0 F4 07 84 B4		
Tests: 2	Alarms: 0	2012/02/10 16:06:35	
			Next Page



Observing any fiber transmitter output can cause injury to the eye.



Ensure that dust covers are installed when the fiber is not in use. Dirty or scratched connectors can lead to high losses on a fiber link.

Adding sites and devices

The EnerVista software allows for multiple B95^{Plus} devices to be run from it. Communications parameters are organized in a hierarchical tree structure, with “sites” at the top level and devices (each a B95^{Plus}) allocated to specific sites. Sites can contain any number of devices. There are four options to add sites and devices, as follows:

- The **Device Setup** button in the software window
- Right-clicking in the **Online Window** area of the software window and selecting **Device Setup**
- The **Edit Device Setup** icon on the tool bar
- Clicking the **Online > Device Setup** menu option


Use one of these options to configure the sites and devices now. One example follows.

To add a site and device to the software:

1. Click the **Device Setup** button.
2. Click the **Add Site** button in the window that opens.
3. Change the **Site Name** field to a descriptive name.

4. Click the **Add Device** button.
5. Change the **Device Name** field to a descriptive name.
6. From the **Interface** drop-down list, select **Ethernet** to connect to the B95^{Plus} device over a network.
7. Add the **IP address**.
8. Click the **Read Order Code** button.
9. Click **OK** to exit from the window.

Figure 8: Adding sites and devices



Once configured, online connection to a particular B95^{Plus} can be established by navigating to the device in the **Online Window** area of the software. Files dragged and dropped into that part of the software window are sent automatically to the online communicating device.

Connecting to a device

The usual method to access a device is to click Quick Connect.

To access a device using the software:

1. In the **Online Window** area of the EnerVista software, double-click the **Quick Connect** menu item.
2. Double-click the **Quick Connect Device** menu item. The information loads.

Accessing settings

Three features facilitate selection and navigation:

- Quick select for operands

- Screen navigation feature for long lists
- Expanding and collapsing a settings table


Operand quick select

Using different mouse gestures, the user is able to initiate three different logic operand selection modes in the B95^{Plus}, as follows:

- By right-clicking on the far right side of any logic operand setting entry field, a drop-down list of all logic operands opens. In this mode, the user can use the scroll-bar to scroll through the list until the required logic operand is visible, then click it to select it and close the list. The user can also type a letter on the keyboard to jump down the list to the next operand with a name starting with that letter.
- By right-clicking twice anywhere except the far right side of any logic operand setting entry field, the field opens for keyboard entry of the operand name. (The first click opens the operand quick select popup described as follows.) In this mode, as each character is typed, the characters to the right are replaced to match the first operand that matches the characters up to and including the new character. Characters that do not match an operand are not accepted. Windows operating system's select, copy and paste features also can be used in this mode.
- By single-clicking anywhere except the far right side of any logic operand setting entry field, the logic operand quick select window opens. The window is generally as shown in the figure that follows. The left-hand side displays a tree structure containing logical groups of operands, and the right-hand side shows the operands of the tree element selected.

Double-clicking an operand in the right-hand window or single-clicking an operand and clicking **Ok** selects that operand and closes the window.

Figure 9: Accessing operands using quick select feature



Operands associated with process cards not present in the order code do not display. Operands associated with process cards that are present in the order code display whether or not they are associated with bricks that are disabled or not connected.


Navigating long lists

For tables with many columns, a feature allows you to navigate quickly to a column.

The feature uses the **Parameter** and **ID** fields at the top of the table. Simply click the **Parameter** field to select a column to which to navigate. Or select the **ID** field and select a specific entry. For both fields, you can also type a letter to have the software jump to the first entry starting with that letter. To exit without selecting, press the **Esc** key.

In the example shown, **ID** was clicked and there are two options from which to select, CB3 and CB5.

Figure 10: Using the drop-down list to navigate columns




Expanding/collapsing table rows

For tables in the EnerVista software with numerous rows, the rows are generally collapsed when the window opens. Simply click the row heading, which is typically a grey box with bold text, to expand content. In the example shown, the General Settings rows have been expanded.

The ID row at the top of the table is always expanded and cannot be collapsed.

Figure 11: Bus sources settings



Viewing actual values

Actual values refers to live data. You can view real-time data from the B95^{Plus}, such as input/output status and measured parameters.

To view data:

1. In the **Online Window** area of the EnerVista software, navigate to the **Actual Values** entry.

Information on actual values is outlined in applicable sections later in this document.

Viewing event records

The events recorder in the B95^{Plus} provides a time-stamped record of state changes of signals monitored by the unit. These signals can include the state of circuit breakers and disconnect switches, external alarms and indications, and any of the internal functions of the device. The B95^{Plus} can store a total of 4,096 events on the main card and 4,096 events on each process card. Once this memory is filled, the oldest events are overwritten. Events are displayed in chronological order from most recent to oldest.


Most B95^{Plus} elements contain an events setting. Event recording is enabled by default for most functions, and state changes for FlexLogic operands associated with the element are written to the events recorder. When the setting is disabled, state changes for the element are not recorded.

The following procedures outline how to view event records and enable/disable event recording. See the Event Recorder section later in the document for information on how to compare event records and how to access the records on the B95^{Plus}.

To view the event records of a B95^{Plus} device:

1. In the **Online Window** area of the EnerVista software, navigate to **Actual Values > DFR > Event Record**. The event record displays.
2. Click the **Refresh** button whenever the screen needs to be updated with the recent events.

Figure 12: Viewing event records



An example follow for enabling/disabling event recording.

To enable/disable bus differential event recording of a B95^{Plus} device:

1. In the **Online Window** area of the EnerVista software, navigate to **Settings > Protection > General > Bus Differential**.
2. View the **Events** field.

Viewing transient records

Transient records are detailed data records covering short periods of time. The B95^{Plus} records up to 128 samples per cycle for the transient records. EnerVista includes the ability to view oscillography waveform traces and digital states in a visual display of power system and relay operation data for specific triggered events.

To view transient records in the software:

1. In the **Online Window** area, navigate to **Actual Values > DFR > Transient Recorder**, select the required record, and click the **Read** button to recover the record and start the Comtrade waveform viewer. The records can also be retrieved from the EnerVista software event record screen by double-clicking the transient record's icon, which is located on the right side of the event record window.

Figure 13: Transient record retrieval screen



To manually force a trigger of the transient recorder, use the transient retrieval screen shown. Click the **Force Trigger** button.

To clear transient records, use the **Actual Values > DFR > Transient Recorder > Command** screen.

Settings files

Settings files contain device and configuration information. They are used to apply new settings to devices, or to restore previously saved settings. They are organized by file names assigned by the user. Settings files contain data pertaining to the following types of relay settings:

- Device definition
- General
- Communications (station bus interface)
- Remote resources (process bus interface)
- Protection (protection elements, FlexLogic, Isolators, Group Control)
- Digital fault recorder (DFR), including transient recorder and Event Recorder
- Front panel
- Security
- Configure FlexOperands (assigning application-specific names)

Settings files have .urs file extensions.

The EnerVista software supports the following three ways of handling changes to relay settings:

- In offline mode (relay disconnected) to create or edit relay settings files for later download to communicating relays
- In online mode (relay connected) to directly modify any relay settings via relay data view windows, and then later save the settings to a file
- Create/edit settings files offline while connected to the relay, then write them to the relay

Factory default values are supplied and can be applied after any changes.

The following settings are not transferred to the B95^{Plus} with settings files:

- Relay Settings Programmed/Not Programmed
- Modbus TCP Port Number
- IP Address
- IP Subnet Mask
- Gateway IP Address
- Network Address NSAP
- IEC61850 Config GOOSE ConfRev.

Deploying settings files to multiple devices using settings templates

Settings templates simplify the configuration of multiple devices that protect similar assets. In these situations, typically a large number of settings are identical among devices, reflecting a common bus architecture and protection approach. The templates allows engineers to configure and test these common settings, then lock them so they are not available to others. For example, these locked-down settings can be hidden from view to field engineers, allowing them to quickly identify and concentrate on the settings specific to their application. The site-specific settings can be specified as editable and made available to field engineers installing the devices. These are settings such as protection element pickup values and current transformer (CT) and voltage transformer (VT) ratios.

The settings template mode allows the user to define which settings are visible in the EnerVista B95^{Plus} Setup software. Settings templates can be applied to both settings files (settings file templates) and online devices (online settings templates). The functionality is identical for both purposes. When in template mode, only settings that are available for editing are saved to the device or setting file during the read/write process.

This section outlines how to enable and edit the templates.

Enabling the settings template in offline mode


The settings file template feature is disabled by default.

To enable the settings template while in offline mode:

1. Select a settings file from the **Offline Window** area of the EnerVista software.
2. Right-click the selected settings file and select **Settings File Template > Create Template**. When the option does not display, it means that the template is already enabled.

The settings file template is now enabled and the file tree displayed in light blue. The settings file is now in template editing mode (shown).

Figure 14: Enabled settings template




Enabling the settings template in online mode

The settings file template feature is disabled by default.

To enable the settings template while in online mode:

1. Select an installed device in the **Online Window** area of the EnerVista software.
2. Right-click the device and select **Template Mode > Create Template**. If the option does not display, it means that the template is already enabled.

Figure 15: Enabling the template



3. In the password window that appears, enter and re-enter a password, then click **OK**. The password is for the template and must be at least four characters in length.

Figure 16: Entering a settings file password



The online settings template is now enabled. The device is now in template editing mode.


Editing a settings template

The template editing feature is used to specify which settings are available for viewing and modification in the EnerVista software. By default, all settings except the FlexLogic equation editor settings are locked.


To edit a settings file template:

1. Right-click an installed device or a settings file on the left side of the EnerVista software.
2. Select **Template Mode > Edit Template** (online mode) or **Settings File Template > Edit Template** (offline mode) to place the device or settings file in template editing mode.
3. Enter the template password (if required) then click **OK**.
4. Navigate to and select the relevant settings windows that contain settings to be specified as viewable. In the example shown, **Protection > General > Bus Sources** was selected.

By default, settings specified as locked display with a grey background. The **Edit** icon on the upper right of the settings window indicates that software is in edit mode.



5. Specify which settings to make viewable by clicking them. The settings selected as available to view display in yellow.



6. Click **Save** to save changes to the settings template. Only the settings that are available for editing are saved to the device or setting file.

Adding password protection to a settings template

To maximize security, save a template with password protection.

To add password protection to a settings file template:

1. Right-click a settings file in the **Offline Window** area of the EnerVista software.

2. Select **Settings File Template > Password Protect Template**. When the option is not available, it means that the template is not active or that a password already exists. To activate the template, select the **Create Template** option.

Figure 17: Template password entry window

3. In the password window that appears, enter and re-enter a password, then click **OK**. The password is for the template and must be at least four characters in length.

The settings file template is now secured with password protection.



NOTE

When templates are created for online settings, the password can be added during the initial template creation step. It does not need to be added after the template is created.

Applying a settings template

Once all necessary settings are specified for viewing, users can use the settings template on the online device or the settings file.

To display only the settings available for editing:

1. Right-click an installed device or a settings file at the left side of the EnerVista software.
2. Select **Template Mode > View in Template Mode** (online mode) or **Settings File Template > View in Template Mode** (offline mode).
3. Enter the template password (if required) then click **OK** to apply the template.

Once the template has been applied, users are only able to view and edit the settings specified by the template. The effect of applying the template to the bus source settings is shown. The white fields can be changed. The grey fields cannot be changed.

Figure 18: Setting window view via the View in Template Mode command

PARAMETER	F/SRC 1	F/SRC 2	F/SRC 3
ID			
General Settings			
Function	Enabled	Enabled	Enabled
Block	OFF	OFF	OFF
Events	Enabled	Enabled	Enabled
HMI Template	1	1	1
CT Settings			
Bus Configuration Settings			
Bus Trip Settings			
Breaker Failure Inputs			

Viewing in template mode also modifies the panels displayed in the software, showing only the settings categories that contain editable settings. The effect of applying the template is shown as follows. In the first figure the template has not been applied and all menu items display. In the second figure, the template has been applied and only the Bus Source item displays.

Figure 19: Settings template not applied





Figure 20: Settings template applied




Removing a settings template

It can be necessary to remove a settings template. Upon removal, it cannot be reapplied and a new settings template is required.

To remove a template:

1. Right-click an installed device or settings file on the left side of the EnerVista software.
2. Select **Template Mode > Remove Template** (online mode) or **Settings File Template > Remove Settings Template** (offline mode).
3. Enter the template password (if required) and click **OK** to continue.
4. Verify that you want to remove the template by clicking **Yes**.

Figure 21: Confirming settings template removal



The EnerVista software removes all template information and all settings are available.

Bus replica graphical editor

A bus replica graphical editor is provided as an alternate means of entering settings and visualizing the behavior of the bus replica. The bus replica is the means by which the determines moment-by-moment the extent of each differential zone, as detailed in later chapters. Dynamic buses in particular elicit complex bus replica behavior, which can be difficult to visualize using only the usual matrixes of settings. Graphical presentation facilitates visualization.

The graphical editor operates on settings related to configuring the bus replica. Basically, the graphical editor allows a schematic diagram of the protected bus to be constructed, and by clicking on the isolators, breakers, and CTs in the diagram, settings entered that fit the diagram to the actual bus. These settings are the same settings that can also be configured by the usual methods from screens containing matrixes of settings, although there are restrictions on opening both the matrix screens and the graphical editor at the same time. The graphical editor also has a few "virtual settings" concerning the graphical presentation that are not accessible from the matrix screens, but none of these affect relay operation.

This section contains instructions on the use of the graphical editor. The effect of the settings the graphical editor accesses on relay behavior and guidance on setting their values are contained in following chapters.

The bus graphical editor does not display dynamic open/close status of the isolators and breakers. It displays only how they are arranged.




NOTE

The bus replica graphical editor displays only bus sources that are selected for display. It is possible for enabled bus sources that therefore are contributing to protection operation to be omitted from the display, and as a result their contribution overlooked by personal using the display. Verification of the presence on the graphical display of all bus sources shown as enabled on the **Settings > Protection > General > Bus Sources** screen is highly recommended.


The following figure shows as an example a completed diagram. The wide short boxes stacked vertically on the left side are bus zone labels, the horizontal lines extending from them to the right are each a bus zone representation. The tall boxes to the right are each a representation of a bus source.

Figure 22: Bus replica graphical editor example




The following figure shows the symbols used in each bus source representation. The back-slash (“\”) symbols represent bus or bypass isolators, the solid squares represent circuit breakers, the triangles represent network elements, and the double arc symbols represent CTs.

Figure 23: Symbols used in a bus source



An isolator can display three ways. First, it is greyed-out when its dynamic status connection setting is set to OFF (for example if there is a permanent primary open circuit at that position). To set it to OFF, you double-click the isolator and select the “Isolator Does Not Exist” option. Second, when you select the “Solid Connection” option, the isolator is ON and displays as a straight-through connection (for example if there is a permanent primary connection in that isolator’s position). Third, the isolator displays as a disconnected slash when the setting is set to any logic operand other than OFF or ON (for example if there is an actual primary isolator at that position).

Figure 24: Setting an isolator as on or off




A circuit breaker is greyed-out when its breaker opened settings are both set to OFF, indicating that the zone expansion/reduction feature is not deployed.

The CT drawing convention used here is that an instantaneously positive primary current entering one side of the CT symbol results in an instantaneously positive secondary current exiting the same side of the CT symbol. That is to say, if polarity marks were to be drawn on the symbol, then primary and secondary marks are on the same side of the symbol. The side of the CT with the longer tail represents the side of the CT that connects to the Brick. Thus when the tail is on the side away from the bus, primary current flowing into the bus results in a positive relay current. If the CT origin settings are both None (meaning there is no actual CT), the CT symbol is greyed-out.

To configure the bus replica using the bus replica graphical editor:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > General > Bus Replica Graphical Editor**.
2. Double-click the bus zone label of each bus zone to be used, and in the Bus Zone Properties window that opens, enter an ID descriptive of the bus segment to be protected. Also select the required function and zone type setting. Click **OK** to close the window.
3. Add the required bus sources. To add a bus source to the right of all existing sources on the diagram, click the icon at the top right of the window shown in the following figure. To add a bus source to the left of an existing source, right-click the existing source and select the **Insert Bus Source** option.



4. In the Bus Source Properties window that opens on adding a bus source, select the designation of the required bus source from the **Source** drop-down list. Next, while still in the Bus Source Properties window, enter an ID descriptive of the bay modelled by the bus source. Also select the required function and events setting, and the operand to use for bus source block feature. Select the appropriate Graphical Presentation icon that best represents the arrangement of the CTs and breaker in the bus source. Click **OK** to close the window.
5. Double-click each of the isolator, breaker, and CT symbols, and in the window that open, adjust the presented settings appropriately.

6. Double-click anywhere inside a bus source except over an isolator, CT, or breaker to re-open the Bus Source Properties window when bus source setting changes are required.
7. Right-click a bus source and select the **Hide Bus Source** option to remove a bus source no longer wanted in that position on the diagram. This action does not disable the bus source; it only removes the bus source from the diagram. Once removed, a bus source can be inserted in a different location as described in step 3.

Note that the **Copy Special** option copies the diagram to the Windows paste buffer as a bitmap. The bitmap can then be pasted into other documents using programs such as Word or Paint.

Securing and locking FlexLogic equations

The B95^{Plus} allows users to secure parts or all of a FlexLogic equation, preventing unauthorized viewing or modification of critical FlexLogic applications.

This is accomplished using the settings template feature to lock individual entries within FlexLogic equations. Secured FlexLogic equations remain secure when files are sent to and retrieved from any B95^{Plus} device.

Use the following procedures.

Locking FlexLogic equation entries

To lock individual entries of a FlexLogic equation:


1. Right-click the settings file or online device on the left side of the EnerVista software, and select **Template Mode > Edit Template**. If the template has not already been enabled, click **Settings File Template > Create Template** or **Template Mode > Create Template**.
2. In the same navigation tree, navigate to **Settings > Protection > Main Card FlexLogic > FlexLogic Equation Editor**.

By default, all FlexLogic entries are viewable and display against a yellow background. The icon on the upper right of the window indicates that the software is in edit mode.

3. Specify the entries to lock by clicking them.

The locked entries display against a grey background.

Figure 25: Locking FlexLogic entries using the template



4. Click the **Save** button.

Locking a settings file and FlexLogic equations to a serial number

A settings file and associated FlexLogic equations can be locked to a B95^{Plus} serial number. Once the FlexLogic entries in a settings file have been secured, use the following procedure to lock the settings file to a serial number.

1. Right-click the settings file in the **Offline Window** area and select **Manage Settings File > Edit Properties**.

The following window displays.

Figure 26: Locking the settings file to a device

2. Enter the serial number of the B95^{Plus} device to lock to the settings file in the **Serial # Lock** field. To view the serial number, look for the bar code on the back of the unit, navigate to Actual Values > Product Information > Model Information in the **Online Window** area of the software, or page down in the annunciator display on the front of the unit.
3. Click **OK**. The settings file and FlexLogic equations are now locked to the B95^{Plus} device specified.

Settings file traceability

A traceability feature allows the user to determine if the settings in a B95^{Plus} device have been changed since installation from a settings file.

To determine if settings have changed since installation:

1. Simply right-click in the **Online Window** area and select **Compare with Settings File**. The number of differences then a list of differences displays.

Figure 27: List of settings file differences

#	Setting Name	Card	Group	Module	Item	Value
1	- DNP Channel 1 Address	Main	1	1	1	1
2	- DNP Channel 1 Port	Main	1	1	1	0
3	- DNP Channel 2 Port	Main	1	1	1	0
4	- DNP Client Address	Main	1	1	1	0
5	- DNP Client Address	Main	1	1	2	0
6	- DNP Client Address	Main	1	1	3	0
7	- DNP Client Address	Main	1	1	4	0
8	- DNP Client Address	Main	1	1	5	0
9	- DNP Current Default Deadband	Main	1	1	1	30000
10	- DNP Current Scale Factor	Main	1	1	1	2
11	- DNP Fragment Size	Main	1	1	1	240
12	- DNP IP Port Number	Main	1	1	1	20000
13	- DNP Number Of Paired Controls	Main	1	1	1	0
14	- DNP Object 1 Default Variation	Main	1	1	1	2
15	- DNP Object 20 Default Variation	Main	1	1	1	0
16	- DNP Object 21 Default Variation	Main	1	1	1	0

Multilin B95^{Plus} Bus Protection System

Chapter 5: Settings – General

This chapter and subsequent chapters on Communications, Remote Resources, Protection, Digital Fault Recorder, Front Panel, and Security describe features on a presentation structure that facilitates comprehension by the settings engineer. This chapter describes general features whose settings appear in the software under **Settings > General**.


Installation

After installation of the Multilin B95^{Plus} Bus Protection System, installation of the EnerVista software, and addition of the B95^{Plus} device to the software, start configuration of the device with the relay name.

To configure or view installation information:

1. In the **Online Window** area of the software, navigate to **Settings > General > Installation**.
2. Click the right side of a field to access any drop-down list, for example to the right of “Not Programmed.” Otherwise, click a field to change the setting.
3. Click **Save** when done.

Figure 1: General installation information



The following settings are available.

Relay Settings*Range: Programmed, Not Programmed**Default: Not Programmed*

To safeguard against the installation of a device without any entered settings, the B95^{Plus} does not allow signaling of any output relay until this setting value is “Programmed.” The **UNIT NOT PROGRAMMED** self-test error message displays on the front panel self-test summary page until it is put into the programmed state. Normally, you set the value to “Programmed” after configuring all the **Settings** panels and the unit is ready to go into service. You do this manually while online using this field; downloading a settings file does not change this setting.

Relay Name*Range: up to 20 characters**Default: ----*

This setting allows the user to uniquely identify a relay. This name appears on all generated reports and displays and on the front panel Product Information page as the **Relay ID**.

User Configuration Name*Range: up to 20 characters**Default: Initial*

This setting allows the user to provide a description for the settings that are loaded at a particular time (for example, “Spring-summer settings”). This description displays on the Product Information page of the front panel as the **Configuration** field.

User Configuration Date*Range: up to 20 characters**Default: ----*

This setting records the date of last setting change through the B95^{Plus} software. Each time any settings are changed or a new settings file loaded, this value updates. This description also displays on the front panel Product Information page as the **Configuration Date**.


Power system

The power system includes the following items: nominal frequency; frequency tracking function; frequency and phase reference; current cutoff level; and voltage cutoff level. Configure these for first setup.

To configure or view power system information:

1. In the **Online Window** area of the software, navigate to **Settings > General > Power System**.

Figure 2: Frequency and voltage information



SETTING	PARAMETER
Nominal Frequency	60 Hz
Frequency Tracking Function	Enabled
Frequency And Phase Reference	None
Current Cutoff Level	0.020 pu
Voltage Cutoff Level	1.0 V

Quick Connect Device | Settings: General

Nominal Frequency*Range: 50 Hz, 60 Hz**Default: 60 Hz*

This value is used as a default to set the digital sampling rate if the system frequency cannot be measured from available signals. This can happen if the Frequency Tracking Function is Disabled, the Frequency and Phase Reference setting is None, or the signals are not present or are heavily distorted. Before reverting to the nominal frequency, the frequency tracking algorithm holds the last valid frequency measurement for a safe period of time while waiting for the signals to reappear or for the distortions to decay.

Frequency Tracking Function*Range: Disabled, Enabled**Default: Enabled*

This setting is set to “Disabled” only in unusual circumstances; consult GE Multilin for special variable-frequency applications.

Frequency And Phase Reference*Range: None, all bus sources, and all voltage sources**Default: None*

This setting determines which signal source is used (and hence which AC signal) for frequency tracking and phase angle reference. The Clarke transformation of the phase signals is used for frequency metering and tracking ($V_{\text{FREQ}} = (2V_A - V_B - V_C) / 3$) for better performance during fault, open pole, and voltage transformer (VT) and current transformer (CT) fail conditions.

The reference signal phase angle always displays zero degrees and all other phase angles are relative to this signal. If the pre-selected reference signal is not measurable at a given time, the phase angles are not referenced and typically continuously rotate.

The phase angle referencing is done via a phase locked loop, which can synchronize independent B95^{Plus} devices if they have the same AC signal reference. This results in precise correlation of time tagging in the event recorder between different devices during periods of IRIG-B unavailability. Note that the other devices are not typically B95^{Plus} units; they are UR or UR^{Plus} devices or from other vendors.

Current Cutoff Level*Range: 0.002 to 0.020 per unit (pu) in steps of 0.001**Default: 0.020 pu*

This setting modifies the current cutoff threshold. Very low currents (0.2 to 2% of the rated value) are very susceptible to noise. Some customers prefer low currents to display as zero, while others prefer the current to be displayed even when the value reflects noise rather than the actual signal. The B95^{Plus} applies a cutoff value to the magnitudes and angles of the measured currents. If the magnitude is below the cutoff level, it is substituted with zero. This applies to phase current phasor values. The cutoff operation applies to quantities used for metering, general protection, and control, as well as those used by communications protocols. Raw current samples available via oscillography are not subject to cutoff.

The bus differential algorithm does not use cutoff.

**NOTE**

Lower this setting with care because the B95^{Plus} accepts lower signals as valid measurements. Unless dictated otherwise by a specific application, the default setting of “0.020 pu” is recommended.

Voltage Cutoff Level

Range: 0.1 to 1.0 volts secondary in steps of 0.1
Default: 1.0 volts secondary

This setting specifies the voltage cutoff threshold. Low secondary voltage measurements (at the fractional volt level) can be affected by noise. Some customers prefer these low voltages to be displayed as zero, while others prefer the voltage to be displayed even when the value reflects noise rather than the actual signal. The B95^{Plus} applies a cutoff value to the magnitudes and angles of the measured voltages. If the magnitude is below the cutoff level, it is substituted with zero. This operation applies independently to phase voltages and to phase-to-phase voltages. The cutoff operation applies to quantities used for metering, protection, and control, as well as those used by communications protocols. Raw samples of the voltages available via oscillography are not subject cutoff.



Lower this setting with care because the B95^{Plus} accepts lower signals as valid measurements. Unless dictated otherwise by a specific application, the default setting of “1.0 V” is recommended.


User programmable self-tests

The B95^{Plus} performs self-tests to verify relay integrity. There are the two types of self-tests: major and minor. These tests are itemized in the Maintenance chapter. The settings described in this section allow certain self-tests to be enabled or disabled to meet requirements of the application.

To configure self-tests:

1. In the **Online Window** area of the software, navigate to **Settings > General > User Programmable Self Test**.

Figure 3: Self-test settings



The following settings are available.

Remote Device Off Function

Range: Enabled, Disabled
Default: Enabled

When this setting is Enabled, the REMOTE DEVICE OFF self-test operates as described in the minor self-tests section of the Maintenance chapter. When Disabled, this self-test does not alarm.

Ethernet Port 1...3 Fail Function

Range: Enabled, Disabled

Default: Disabled

When this setting is Enabled, the ETHERNET PORT 1...3 FAILURE self-tests operate as described in the minor self-tests section of the Maintenance chapter. When Disabled, this self-test does not alarm.

SNTP Fail Function

Range: Enabled, Disabled

Default: Enabled

When this setting is Enabled, the SNTP FAILURE self-test operates as described in the minor self-tests section of the Maintenance chapter. When Disabled, this self-test does not alarm.

IRIG-B Fail Function

Range: Enabled, Disabled

Default: Enabled

When this setting is Enabled, the IRIG-B FAILURE self-test operates as described in the minor self-tests section of the Maintenance chapter. When Disabled, this self-test does not alarm.

Configurable Major Self-Test

Range: any FlexLogic operand

Default: OFF

When the operand selected by this setting is in the On state, this self-test is alarmed. This allows the relay to use FlexLogic or other means to generate an application specific major self-test alarm, thereby taking the relay out of service.

Multilin B95^{Plus} Bus Protection System

Chapter 6: Communications

This chapter outlines how to program the Multilin B95^{Plus} Bus Protection System communication settings.

Communications overview

The B95^{Plus} has one Ethernet port (port 1) on the main module and two additional Ethernet ports (ports 2 and 3) on the communications module. Each port supports 100Base-FX over multimode fiber and 10/100Base-TX over twisted-pair, with auto-negotiation. Port 1 is primarily intended for configuration and file retrieval purposes. Ports 2 and 3 are intended for supervisory control and acquisition data (SCADA) and peer-to-peer messaging. The following protocols are available, depending on the order code of the unit.:

- Ethernet port 1 — Modbus TCP, TFTP, SNTP, HTTP
- Ethernet port 2 — Modbus TCP, DNP 3.0, IEC 60870-5-104, IEC 61850, SNTP, TFTP, HTTP
- Ethernet port 3 — Modbus TCP, DNP 3.0, IEC 60870-5-104, IEC 61850, SNTP, TFTP, HTTP

Network settings

This section outlines configurable network settings, such as Ethernet, trivial file transfer protocol (TFTP), and simple network time protocol (SNTP).

Ethernet

Each of Ethernet ports 1 to 3 have globally unique identifiers known as MAC addresses. The MAC address of port 1 is displayed on the Product Information page of the annunciator and in the EnerVista software under **Actual Values > Product Information > Model Information**. The MAC address of port 2 is one greater than port 1, and the MAC address of port 3 is one greater than port 2.

If not already done, configure the IP address of the B95^{Plus} and enable the Ethernet ports for use. Ethernet ports 2 and 3 can be configured for single or dual IP redundancy.


In the single IP redundancy configuration, the port 2 IP address, subnet mask, and gateway address are used for both ports 2 and 3, and the port 3 settings are ignored. All communications traffic are normally routed on port 2. If a failure occurs (determined at the hardware layer upon detecting loss of link signal on the active channel) then the traffic is re-routed to port 3. Switchover to port 3 takes place in less than 10 ms from the moment that the physical layer detects a failure. The device reverts from port 3 to port 2 as soon as port 2 becomes available, regardless of the state of port 3. Switchover to port 2 takes place in less than 500 ms. A link pulse is maintained in the transmit direction on both ports regardless of the port in use. This ensures that communications are established with minimal delays. An Ethernet broadcast message is transmitted immediately upon port switch, thereby forcing all Ethernet switches in the network to immediately update their routing tables.

In the dual IP redundancy configuration, each port has a unique IP address, with separate subnet mask, and gateway address settings. Multiple client-server connections can be opened on each port simultaneously. Under normal conditions, GOOSE messages are sent on both ports and received on either.

To configure Ethernet settings:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > Network > Ethernet** to open the Ethernet configuration window.
2. After entering the addresses and settings, click the **Save** button then the **Apply** button.

Figure 1: Configuring Ethernet ports



The IP addresses are used with the DNP, Modbus/TCP, IEC 61580 MMS services, IEC 60870-5-104, SNMP, and TFTP protocols.



NOTE

When the NSAP address or any user map setting (when used with DNP) is changed, it becomes active after power to the relay has been cycled (off-to-on).

The following settings are available for each Ethernet port, except for **OSI Network Address (NSAP)** and **ESH Configuration Timer**, which are not port-specific, and the **Port 2 Redundancy**, which applies only to Ethernet port 2.

Port 1, Port 2, Port 3 IP Address

Range: standard IP address range

Default: 192.168.251.251 (port 1), 192.168.252.252 (port 2), 192.168.253.253 (port 3)

These settings specify the dedicated IP address for each Ethernet port. Each port must be configured for a different subnet. The IP address setting for port 3 is not available when the Port 2 Redundancy setting is "Single IP."

Port 1, Port 2, Port 3 IP Subnet Mask

Range: standard IP subnet mask range

Default: 255.255.255.0

These settings specify the dedicated subnet mask for each Ethernet port. Each port must be configured for a different subnet, though the subnet masks can be identical.

The subnet mask setting for port 3 is not available when the **Port 2 Redundancy** setting is "Single IP."

Port 1, Port 2, Port 3 Gateway IP Address

Range: standard IP address range

Default: 0.0.0.0

These settings specify the gateway address for the selected Ethernet port. The setting 0.0.0.0 codes no gateway. Configure only one gateway for the relay and be sure to configure this setting when using FTP and/or SNTP. Because only one port can declare a gateway, the port selected in the SNTP settings is the port to declare the gateway address.

The gateway IP address setting for port 3 is not available when the **Port 2 Redundancy** setting is "Single IP."

Port 1, Port 2, Port 3 Ethernet Mode

Range: Auto, 10/100 Base-TX, 100 Base-FX

Default: Auto

These settings select the Ethernet connection hardware type, either 10/100Base-TX (twisted-pair) or 100Base-FX (fiber optic). The "Auto" selection is used to automatically detect the Ethernet hardware type.

The Ethernet mode setting for port 3 is not available when the **Port 2 Redundancy** setting is "Single IP."

Port 2 Redundancy

Range: Single IP, Dual IP

Default: Dual IP

This settings selects single-IP or dual-IP operation for Ethernet ports 2 and 3. In single-IP mode, the link status of both ports is continuously monitored but only one port is active at a time. Each port uses the same source MAC address and IP parameters specified for Ethernet port #2. In dual-IP mode, Ethernet ports 2 and 3 operate independently with their own MAC addresses and IP parameters. Changes to this setting are implemented immediately on saving.

OSI Network Address (NSAP)

Range: Any valid address

Default: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 49 00 00 00

This setting specifies the NSAP address used with the IEC 61850 GSSE protocol over the OSI (CLNP/TP4) stack.

This address and the ESH Configuration Timer are not port-specific. When the NSAP address is changed, it becomes active when power to the relay is cycled (off-to-on).

ESH Configuration Timer

Range: 0 to 32767 seconds in steps of 1

Default: 120 seconds

The End System to Intermediate System Routing Exchange protocol used with ISO 8473 mandates that the end system construct and transmit an End System Hello (ESH) signal for each NSAP it serves, based on an internal timer. This setting specifies the transmission time for the ESH signal. This setting takes effect when the B95^{Plus} is restarted.

The following commands are available from this window.

Configure IP Network

To make changes to the Ethernet settings outlined, save them, then click the **Apply** button here.

This command validates the IP address, subnet mask, and gateway IP address settings for all ports. When the validation is successful, the **Configure IP Network Status** value is "OK" and the new settings take effect immediately. When the validation fails, the **Configure IP Network Status** value indicates the reason for failure and the network settings are restored to previous values.

The following actual values are available in this window.

Configure IP Network Status

Range: OK, PORT 1 NETMASK ERROR, PORT 2 NETMASK ERROR, PORT 3 NETMASK ERROR, PORT 1 IP ADDR RSVD, PORT 2 IP ADDR RSVD, PORT 3 IP ADDR RSVD, PORT 1 IP ADDR LPBK, PORT 2 IP ADDR LPBK, PORT 3 IP ADDR LPBK, PORT 1 IP ADDR NETWK, PORT 2 IP ADDR NETWK, PORT 3 IP ADDR NETWK, PRT 1-2 SUBNET OVRLP, PRT 1-3 SUBNET OVRLP, PRT 2-3 SUBNET OVRLP, >1 GATEWAY DEFINED

This actual value displays the status of the **Configure IP Network** command. The following status values are indicated:

- "OK": All supplied user IP parameters are valid and have been applied to the network stack.
- "PORT 1 NETMASK ERROR," "PORT 2 NETMASK ERROR," "PORT 3 NETMASK ERROR": An invalid network mask value was entered for Ethernet port 1, 2, or 3, respectively.
- "PORT 1 IP ADDR RSVD," "PORT 2 IP ADDR RSVD," "PORT 3 IP ADDR RSVD": A reserved IP address was entered for Ethernet port 1, 2, or 3, respectively. Reserved IP addresses include 0.---.---.--- (for self-identification), 224.---.---.--- through 239.---.---.--- (multicast), and 240.---.---.--- through 255.---.---.--- (reserved by IANA).
- "PORT 1 IP ADDR LPBK," "PORT 2 IP ADDR LPBK," "PORT 3 IP ADDR LPBK": A loopback IP address was entered for Ethernet port 1, 2, or 3, respectively.
- "PORT 1 IP ADDR NETWK," "PORT 2 IP ADDR NETWK," "PORT 3 IP ADDR NETWK": The entered IP address is the network address for Ethernet port 1, 2, or 3, respectively.
- "PRT 1-2 SUBNET OVRLP": The entered network parameters for Ethernet port 1 overlap the network parameters for Ethernet port 2.
- "PRT 1-3 SUBNET OVRLP": The entered network parameters for Ethernet port 1 overlap the network parameters for Ethernet port 3.

- "PRT 2-3 SUBNET OVRLP": The entered network parameters for Ethernet port 2 overlap the network parameters for Ethernet port 3.
- ">1 GATEWAY DEFINED": The user has entered more than one default gateway.

Active Port 1, Port 2, Port 3 IP Address

Range: standard IP address range

These actual values display the configured IP address for each Ethernet port.

The active port IP address actual value for port 3 is not available when the **Port 2 Redundancy** setting is "Single IP."

Active Port 1, Port 2, Port 3 IP Subnet Mask

Range: standard IP subnet mask range

These actual values display the configured subnet mask for each Ethernet port.

The active port subnet mask actual value for port 3 is not available when the **Port 2 Redundancy** setting is "Single IP."

Active Port 1, Port 2, Port 3 Gateway IP Address

Range: standard IP address range

These actual values display the configured gateway address for the selected Ethernet port.

The active port gateway address actual value for port 3 is not available when the **Port 2 Redundancy** setting is "Single IP."

Navigate to **Actual Values > Communications > Communication** and to **Actual Values > Communications > Remaining Connection** to view additional actual values.

TFTP

The trivial file transfer protocol (TFTP) can be used to transfer files from the B95^{Plus} over a network. As such, the B95^{Plus} operates as a TFTP server. TFTP client software is available from various sources, including Microsoft Windows XP. The `dir.txt` file obtained from the B95^{Plus} contains a list and description of all available files (for example, event records and transient record oscillography).

To transfer the `dir.txt` file using TFTP:


1. On the Windows computer, open a command window. Use the `ls` and `cd` commands to change to the folder in which you want to place the file.
2. Enter


```
tftp <B95Plus IP address> get dir.txt B95Plus_dir.txt
for example
tftp 3.94.248.245 get dir.txt B95Plus_dir.txt
copies the dir.txt file to the computer and names the file B95Plus_dir.txt
```

To configure TFTP:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > Network > TFTP** to open the TFTP configuration window.

Figure 2: TFTP configuration settings



The following settings are available.

TFTP Main UDP Port Number

Range: 1 to 65535 in steps of 1

Default: 69

This setting specifies the main user datagram protocol (UDP) port number.

TFTP Data UDP Port Number 1...4

Range: 0 to 65535 in steps of 1

Default: 0

These settings specify data for UDP port numbers 1 through 4. A TFTP data port value of zero specifies that the B95^{Plus} is to automatically assign a port number.



Changes to the TFTP protocol settings become active after power to the B95^{Plus} has been cycled (off-to-on).

SNTP

There are three options for setting the internal clock: simple network time protocol (SNTP); IRIG-B; and manually using the EnerVista software.

The B95^{Plus} supports SNTP specified in RFC-2030. With SNTP, the B95^{Plus} can obtain clock time over an Ethernet network. The B95^{Plus} acts as an SNTP client to receive time values from an SNTP/NTP server, usually a dedicated product using a global positioning system (GPS) receiver to provide accurate time. Unicast SNTP is supported. Broadcast, multicast, and anycast are not supported.


When SNTP functionality is enabled at the same time as IRIG-B, the IRIG-B signal provides the time value to the B95^{Plus} clock for as long as a valid signal is present. If the IRIG-B signal is removed, then the time obtained from the SNTP server is used. When either SNTP or IRIG-B is enabled, the B95^{Plus} clock value cannot be changed using the EnerVista software.

When SNTP and IRIG-B are disabled, the date and time can be set using the **Maintenance > Set Date and Time** option.

To configure SNTP settings:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > Network > SNTP** to open the SNTP protocol configuration window.
2. For security reasons, companies typically use their own time server and know the IP address of it. Otherwise, search the Internet for the IP address of a public server; select one close to the B95^{Plus} device. An IP address is required, for example time.nrc.ca is an invalid address.

Figure 3: SNTP protocol configuration settings



The following settings are available.

Function

Range: Enabled, Disabled

Default: Disabled

This setting enables and disables SNTP use.

Server IP Address

Range: standard IP address

Default: 0.0.0.0

This setting specifies the SNTP/NTP server IP address.

To use SNTP in unicast mode, program this setting to the SNTP/NTP server IP address. Once this address is set, the B95^{Plus} attempts to obtain time values from the SNTP/NTP server. Since many time values are obtained and averaged, it generally takes three to four minutes until the B95^{Plus} clock is synchronized with the SNTP/NTP server. It can take up to two minutes for the B95^{Plus} to signal an SNTP self-test error if the server is offline.

SNTP UDP Port Number

Range: 0 to 65535 in steps of 1

Default: 123

This setting specifies the UDP port number for use with the SNTP protocol.

Ethernet Interface

Range: 1, 2, or 3

Default: 1

This setting selects the Ethernet port to use for SNTP communications.

The gateway IP address for this port needs to be configured in **Settings > Communications > Network > Ethernet**.

HTTP

The B95^{Plus} contains an embedded web server and is capable of transferring web pages to a web browser, such as Firefox or Chrome. The web pages are organized as a series of menus that can be accessed starting at the B95^{Plus} main menu. Web pages are read-only and are available showing DNP and IEC 60870-5-104 points lists, Modbus registers, event records, and so on. The main menu displays in the web browser simply by entering the IP address of the B95^{Plus} device into the address field of the web browser. Using the settings outlined in this section, you can enable/disable this feature and set the port number.

To view the IP address of a B95^{Plus}:

1. Click the **Next Page** button repeatedly under the annunciator panel on the left side of the unit until the IP address displays. Or in the **Online Window** area of the software, navigate to **Settings > Communications > Network > Ethernet**.

Figure 4: Accessing a B95^{Plus} device over the Internet (Chrome web browser)



To configure web browser access:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > Network > HTTP** to open the HTTP configuration window.

Figure 5: Enabling web access



The following settings are available.

HTTP TCP Port Number

Range: 1 to 65535 in steps of 1

Default: 80

This setting specifies the transmission control protocol (TCP) port number for the embedded web server. This setting takes affect once the B95^{Plus} is restarted.

Web Server Function

Range: Disabled, Enabled

Default: Disabled

This setting enables and disables the web server feature and web browser access of the device.


Viewing Ethernet actual values

Information about the Ethernet ports, speed, and status is viewable.

To view information about the Ethernet ports:

1. In the **Online Window** area of the software, navigate to **Actual Values > Communications > Communication** to open the communications actual values window.

Figure 6: Ethernet actual values



PARAMETER	VALUE
Port 1 Ethernet Actual Mode	10/100 BASE-TX
Port 1 Ethernet Duplex	Full Duplex
Port 1 Ethernet Speed	100 Mbps
Port 1 Ethernet Link Status	Online
Port 2 Ethernet Actual Mode	10/100 BASE-TX
Port 2 Ethernet Duplex	Half Duplex
Port 2 Ethernet Speed	10 Mbps
Port 2 Ethernet Link Status	Offline
Port 3 Ethernet Actual Mode	10/100 BASE-TX
Port 3 Ethernet Duplex	Half Duplex
Port 3 Ethernet Speed	10 Mbps
Port 3 Ethernet Link Status	Offline
IEC 60870-5-104 Available	No
IEC 61850 Available	Yes
Configure IP Network Status	OK

The following information displays.

Port 1, Port 2, Port 3 Ethernet Actual Mode

Range: 10/100 BASE-TX, 100 BASE-FX

Indicates the Ethernet hardware type on each of the three ports.

Port 1, Port 2, Port 3 Ethernet Duplex

Range: Full Duplex, Half Duplex

Indicates the Ethernet duplex mode on each of the three ports.

Port 1, Port 2, Port 3 Ethernet Speed

Range: 10 Mbps, 100 Mbps

Indicates the network speed on each of the three Ethernet ports.

Port 1, Port 2, Port 3 Ethernet Link Status

Range: Online, Offline

indicates the connection status of each of the three Ethernet ports.

IEC 60870-5-104 Available

Range: No, Yes

Indicates if the IEC 60870-5-104 protocol is enabled on the Ethernet ports.

IEC 61850 Available

Range: No, Yes

Indicates if the IEC 61850 protocol is enabled on the Ethernet ports.

Configure IP Network Status

Range: OK, PORT 1 NETMASK ERROR, PORT 2 NETMASK ERROR, PORT 3 NETMASK ERROR, PORT 1 IP ADDR RSVD, PORT 2 IP ADDR RSVD, PORT 3 IP ADDR RSVD, PORT 1 IP ADDR LPBK, PORT 2 IP ADDR LPBK, PORT 3 IP ADDR LPBK, PORT 1 IP ADDR NETWK, PORT 2 IP ADDR NETWK, PORT 3 IP ADDR NETWK, PRT 1-2 SUBNET OVRLP, PRT 1-3 SUBNET OVRLP, PRT 2-3 SUBNET OVRLP, > 1 GATEWAY DEFINED

Indicates the validity of the IP parameters applied to the network stack. See [Ethernet](#) on page 57.


Viewing TCP/IP connection actual values

The numbers of connections available are viewable..

To view connections remaining information:

1. In the Online Window area of the software, navigate to **Actual Values > Communications > Remaining Connection** to open the remaining TCP/IP connections actual values window.

Figure 7: Remaining TCP/IP connections



The following actual values display.

MMS Available TCP/IP Connections

Range: 0, 1, 2, 3, 4, 5

Indicates the number of connections available for IEC 61850 manufacturing message specification (MMS) communications.

Modbus Available TCP/IP Connections

Range: 0, 1, 2, 3, 4

Indicates the number of connections available for Modbus communications.

DNP Available TCP/IP Connections

Range: 0, 1, 2

Indicates the number of connections available for distributed network protocol (DNP) communications. The number of DNP connections is zero unless the "Network - TCP" value has been selected for both the **DNP Channel 1 Port** and **DNP Channel 2 Port** settings.

IEC Available TCP/IP Connections

Range: 0, 1, 2

Indicates the number of connections available for IEC 60870-5-104 communications.

Modbus communications

The B95^{Plus} supports a subset of the Modicon Modbus protocol. Modbus is a serial communications protocol developed by a company called Modicon. The supported commands allow a Modbus master device to monitor, program, and control the B95^{Plus}. Modbus is typically available via a RS-485 serial link (Modbus RTU) or via Ethernet (Modbus/TCP). The B95^{Plus} supports Modbus using Ethernet only.


The B95^{Plus} always acts as a slave device, meaning that it never initiates communications; it listens and responds to requests issued by a master device.

If you intend to use Modbus, configure the B95^{Plus} for it using the following sections. Otherwise, skip this section.

Modbus addresses are listed in the embedded web server. See the HTTP section in the Communications chapter for information on this web server feature.

The Actuals memory mapped registers are accessed using the Modbus Input Registers function codes. The Settings memory mapped registers are accessed using the Modbus Holding Registers function codes. The main card slave address is 1, process card F slave address is 3, and process card J slave address is 6.

Figure 8: Viewing the memory map in a web browser



Protocol


In the B95^{Plus}, the Modbus server can simultaneously support four clients over Ethernet. The server is capable of reporting any indication or measurement and operating any virtual input. A user-configurable input and output map is also implemented.

The B95^{Plus} operates as a Modbus slave device.

To configure Modbus:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > Modbus > Protocol** to open the Modbus protocol configuration window.

Figure 9: Modbus protocol configuration settings



The following settings are available.

Modbus Slave Address

Range: 1

Default: 1

The base Modbus slave address for the B95^{Plus} is fixed at 1. Different Modbus devices are distinguished by their IP address.

Modbus TCP Port Number

Range: 1 to 65535 in steps of 1
 Default: 502

This setting specifies the Modbus TCP port number for Ethernet communications. Any change to this setting takes effect when power to the B95^{Plus} is cycled.

User map

The Modbus user map provides access of up to 256 registers. Accessing a contiguous block of registers via Modbus is faster than accessing the same number of individual registers. To obtain a memory map value, enter the required address in the **Parameter** field (this value must be in decimal format), the Modbus Type and Card. The corresponding value (if programmed) is displayed in the value field. A value of "0" in subsequent register address lines automatically returns values for the previous address lines incremented by 1. An address value of "0" in the initial register means none and values of "0" is displayed for all registers. Different address values can be entered as required in any of the register positions.


To view or change Modbus register values:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > Modbus > User Map** menu item to open the Modbus user map configuration window.
2. To add a B95^{Plus} register to the user map, for one of the user map addresses, complete the required register's card, address and address. This information (in hexadecimal) is listed on the relay's web page. The EnerVista software numeric setting tool can accept hexadecimal values.

To read the user map using a third-party device supporting Modbus over TCP/IP:

1. On the third-party device, set the TCP port number to the value of the **Settings > Communications > Modbus > Protocol > Modbus TCP Port Number**, which is also listed as Modbus IP Port on the front panel annunciator display, Communications Status page.
2. Set the IP address to the value of the **Settings > Communications > Network > Ethernet > Port x IP Address**, where x is the number of the B95^{Plus} port connected to.
3. Set the slave address as 1 (main card).
4. Set the function code to 4 (read Input Register).
5. Set the Address 0x1200 for user map starting at address 1, Address 0x1201 for user map starting at address 2, and so on in sequence.

Figure 10: Modbus user map configuration settings



The following Modbus user map settings are available for each of the 256 registers.

Card

Range: Main Card, Process Card F, Process Card J

Default: None

This setting selects the card originating the value mapped.

Modbus Type

Range: None, Settings, Actuals

Default: None

This setting selects the page originating the value mapped.

Parameter

Range: Modbus memory map address in decimal representation

Default: 0

This setting selects the Modbus address of the value mapped.

Value

Range: 0...65535

Default: 0

When the EnerVista software is online, this field indicates the actual value in decimal of the Modbus register the Modbus user map address maps to, if any. This is not a setting.

DNP communications

The distributed network protocol (DNP) allows for the optimization of control and data acquisition between the equipment in the substation and the central control center. The protocol is scalable; that is, it is compatible with the latest high speed local area network (LAN) technology and can still be implemented over slower speed serial links. DNP improves upon many master-slave protocols by improving overall communication performance requirements and providing time-stamping with millisecond accuracy.

If ordered, either the DNP or IEC 60870-5-104 option is included, not both.

If you intend to use DNP, configure the B95^{Plus} for it using the following sections. Otherwise, skip this section.

Protocol

The DNP server can simultaneously support one client over Ethernet or two clients over Ethernet. Level 3 is supported for parsing requests and generating responses. It is capable of reporting any indication or measurement and operating any output present in the device. Both direct-operate and select-before-operate modes of control are supported. Two user-configurable input and output maps are implemented.

To configure DNP:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > DNP > Protocol** to open the DNP protocol configuration window.

Figure 11: DNP configuration settings

SETTING	PARAMETER
DNP Channel 1 Port	NONE
DNP Channel 2 Port	NONE
DNP Channel Address	1
DNP Client Address 1	0. 0. 0. 0
DNP Client Address 2	0. 0. 0. 0
DNP Client Address 3	0. 0. 0. 0
DNP Client Address 4	0. 0. 0. 0
DNP Client Address 5	0. 0. 0. 0
DNP TCP/UDP Port Number	20000
DNP Unsolicited Response Function	Disabled
DNP Unsolicited Response Timeout	5 s
DNP Unsolicited Response Maximum Re-Tries	10
DNP Unsolicited Response Destination Address	1
DNP Current Scale Factor	1
DNP Voltage Scale Factor	1
DNP Other Scale Factor	1
DNP Current Default Deadband	30000
DNP Voltage Default Deadband	30000
DNP Other Default Deadband	30000
DNP Time Sync IIN Period	1440 min
DNP Message Fragment Size	240
DNP Object 1 Default Variation	2
DNP Object 2 Default Variation	2
DNP Object 20 Default Variation	1
DNP Object 21 Default Variation	1
DNP Object 22 Default Variation	1
DNP Object 23 Default Variation	1
DNP Object 30 Default Variation	1
DNP Object 32 Default Variation	1
DNP Number of Paired Controls	0
DNP TCP Connection Timeout	120

The following settings are available.



Changes to these settings take effect after power is cycled to the B95^{Plus}.

DNP Channel 1 Port, DNP Channel 2 Port

Range: None, Network-TCP, Network-UDP
Default: None

These settings specify the communications port assigned to DNP for each channel. When this setting is set to "Network-TCP," DNP can be used over TCP/IP on channels 1 or 2. When this value is set to "Network - UDP," DNP can be used over UDP/IP on channel 1 only.

Changes to these settings take effect after power is cycled to the B95^{Plus}.

DNP Channel Address

Range: 0 to 65519 in steps of 1
Default: 1

This setting specifies the DNP slave address. This number identifies the B95^{Plus} on a DNP communications link. Assign each DNP slave a unique address.

DNP Client Address 1...DNP Client Address 5

Range: any standard IP address
Default: 0.0.0.0

These settings force the B95^{Plus} to respond to a maximum of five specific DNP masters.

DNP TCP/UDP Port Number*Range: 1 to 65535 in steps of 1**Default: 20000*

This setting specifies the TCP/UDP port used for DNP communications.

DNP Unsolicited Response Function*Range: Enabled, Disabled**Default: Disabled*

Change this setting to “Enabled” to activate the function.

DNP Unsolicited Response Timeout*Range: 0 to 60 seconds in steps of 1**Default: 5 seconds*

This setting specifies how long the B95^{Plus} waits for a DNP master to confirm an unsolicited response.

DNP Unsolicited Response Maximum Re-Tries*Range: 1 to 255 in steps of 1**Default: 10*

This setting specifies the number of times the B95^{Plus} retransmits an unsolicited response without receiving confirmation from the master. A value of “255” allows infinite re-tries.

DNP Unsolicited Response Destination Address*Range: 0 to 65519 in steps of 1**Default: 1*

This setting specifies the DNP address to which all unsolicited responses are sent. The IP address to which unsolicited responses are sent is determined by the B95^{Plus} from the current TCP connection or the most recent UDP message.

DNP Current Scale Factor, DNP Voltage Scale Factor, DNP Other Scale Factor*Range: 0.001, 0.01, 0.1, 1, 10, 100, 1000, 10000, 100000**Default: 1*

These settings scale the analog input current values. For example, if the **DNP Current Scale Factor** is “10,” all DNP analog input points that represent currents are returned with values 10 times smaller (for example, a value of 700 amps on the B95^{Plus} is returned as 70). Likewise, if the **DNP Voltage Scale Factor** is “0.01,” all DNP analog input points that represent voltages are returned with values 100 times larger (for example, a value of 17 volts on the B95^{Plus} are returned as 1700).

These settings are useful when analog input values must be adjusted to fit within certain ranges in DNP masters.

DNP Current Default Deadband, DNP Voltage Default Deadband, DNP Other Default Deadband*Range: 0 to 100000000 in steps of 1**Default: 30000*

These settings determine when to trigger unsolicited responses containing analog input data. These settings group the B95^{Plus} analog input data into the following types: current; voltage; and other. Each setting represents the default deadband value for all analog input points of that type. For example, to trigger unsolicited responses from the B95^{Plus} when any current values change by 15 amps, set the **DNP Current Default Deadband** setting to “15.”

These settings are the deadband default values. DNP object 34 points can be used to change deadband values from the default for each individual DNP analog input point. Whenever power is removed and re-applied to the B95^{Plus}, the default deadbands are in effect.

DNP Time Sync IIN Period*Range: 1 to 10080 minutes in steps of 1**Default: 1440 minutes*

This setting determines how often the Need Time Internal Indication (IIN) bit is set by the B95^{Plus}. Changing this time allows the DNP master to send time synchronization commands more or less often, as required.

DNP Message Fragment Size*Range: 30 to 2048 in steps of 1**Default: 240*

This setting determines the size, in bytes, at which message fragmentation occurs. Large fragment sizes allow for faster and more efficient throughput; smaller fragment sizes cause more application layer confirmations to be necessary, which can provide for more robust data transfer over noisy communication channels.

DNP Object 1 Default Variation, DNP Object 2 Default Variation, DNP Object 20 Default Variation, DNP Object 21 Default Variation, DNP Object 22 Default Variation, DNP Object 23 Default Variation, DNP Object 30 Default Variation, DNP Object 32 Default Variation*Range: 1, 2 (object 1); 1, 2, 3 (object 2); 1, 2, 5, 6 (objects 20, 22, and 23); 1, 2, 9, 10 (object 21); 1, 2, 3, 4, 5 (object 30); 1, 2, 3, 4, 5, 7 (object 32)**Default 1 (objects 20, 21, 22, 23, 30, and 32); 2 (objects 1 and 2)*

These settings allow the user to select the DNP default variation number for object types 1, 2, 20, 21, 22, 23, 30, and 32. The default variation refers to the variation response when variation 0 is requested or in class 0, 1, 2, or 3 scans.

DNP Number of Paired Controls*Range: 0 to 32 in steps of 1**Default: 0*

The DNP binary outputs typically map one-to-one to IED data points. That is, each DNP binary output controls a single physical or virtual control point in an IED. In the B95^{Plus}, DNP binary outputs are mapped to virtual inputs. However, some legacy DNP implementations use a mapping of one DNP binary output to two physical or virtual control points to support the concept of trip and close (for circuit breakers) or raise and lower (for tap changers) using a single control point. That is, the DNP master can operate a single point for both trip and close, or raise and lower, operations. The B95^{Plus} can be configured to support paired control points, with each paired control point operating two virtual inputs. This setting allows configuration of from 0 to 32 binary output paired controls. Points not configured as paired operate on a one-to-one basis.

DNP TCP Connection Timeout*Range: 10 to 300 seconds in steps of 1**Default: 120 seconds*

This setting specifies a time delay for the detection of dead network TCP connections. When there is no data traffic on a DNP TCP connection beyond the time specified by this setting, the connection is aborted by the B95^{Plus}. This frees up the connection to be re-used by a client.

User point list


The binary and analog inputs points for the DNP protocol can be configured to a maximum of 256 points. The value for each point is user-programmable and can be configured by assigning FlexLogic operands for binary inputs or FlexAnalog™ parameters for analog inputs.

The DNP point lists always begin with point 0 and end at the first “Off” value. Since DNP point lists must be in one continuous block, any points assigned after the first “Off” point are ignored. Changes to the DNP point lists take effect when the B95^{Plus} is restarted.

To configure DNP input points:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > DNP > User Point List** to open the DNP user point list configuration window.

Figure 12: DNP user point list configuration settings



The following settings are available for points 0 through 255.

Binary Input Point 0...Binary Input Point 255

Range: any FlexLogic™ operand

Default: Off

These settings represent DNP binary input points and are configured by assigning an appropriate FlexLogic operand. Up to 256 binary input points can be configured for DNP.

Analog Input Point 0...Analog Input Point 255

Range: any FlexAnalog™ parameter

Default: Off

These settings represent DNP analog input points and are configured by assigning an appropriate FlexAnalog™ parameter. Up to 256 analog input points can be configured for DNP.

IEC 60870-5-104 communications

IEC 60870-5-104 is a standard for communication between a control station and substation using TCP/IP. The IEC 60870-5-104 server supports two clients simultaneously. It is capable of reporting any indication or measurement and operating any output present in the device. These point lists are shared with DNP.

To use it, you specify the client and power thresholds. The B95^{Plus} is not the client. Another device, such as a computer or a gateway, is the client, and it can be in the substation or elsewhere.

If ordered, either the DNP or IEC 60870-5-104 option is included, not both.

Configuring IEC 60870-5-104 settings

Specify the client, such as a computer or gateway, and thresholds to use the protocol.

To configure the IEC 60870-5-104 settings:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > IEC 60870-5-104 > Protocol** to open the configuration window. When the option does not display, it means that it was not ordered.

Figure 13: IEC 60870-5-104 protocol configuration settings

SETTING	PARAMETER
IEC TCP Port Number	2404
IEC Client Address 1	0. 0. 0. 0
IEC Client Address 2	0. 0. 0. 0
IEC Client Address 3	0. 0. 0. 0
IEC Client Address 4	0. 0. 0. 0
IEC Client Address 5	0. 0. 0. 0
IEC Common Address of ASDU	0
IEC Cyclic Data Period	60 s
IEC Current Default Threshold	30000
IEC Voltage Default Threshold	30000
IEC Power Default Threshold	30000
IEC Power Factor Default Threshold	30000
IEC Other Default Threshold	30000

The following settings are available.

IEC TCP Port Number

Range: 0 to 65535 in steps of 1

Default: 2404

This setting specifies the TCP port number to use for IEC 60870-5-104 communications.

IEC Client Address 1...IEC Client Address 5

Range: standard IP address format

Default: 0.0.0.0

These settings specify the IP addresses for five IEC 60870-5-104 clients. The B95^{Plus} is not a client. Examples of clients are a computer and a gateway, either in the substation or elsewhere.

IEC Common Address of ASDU

Range: 0 to 65535 in steps of 1

Default: 0

This setting specifies the local address of the B95^{Plus} for IEC 60870-5-104 transactions. The address is common to all data in a single application service data unit (ASDU). The combination of ASDU common address and information object address (IOA) uniquely identifies each data item in a system.

IEC Cyclic Data Period

Range: 1 to 65535 seconds in steps of 1

Default: 60 seconds

This setting specifies the rate at which the B95^{Plus} sends updated point data regardless of whether or not a status change has occurred. This data includes binary inputs, binary outputs, and analog inputs.

IEC Current Default Threshold, IEC Voltage Default Threshold, IEC Power Default Threshold, IEC Power Factor Default Threshold, IEC Other Default Threshold

Range: 0 to 100000000 in steps of 1

Default: 30000

These settings are used to determine when to trigger spontaneous responses containing M_ME_NC_1 analog data. These settings group the B95^{Plus} analog data into types: current, voltage, power, energy, and other. Each setting represents the default threshold value for all M_ME_NC_1 analog points of that type. For example, to trigger spontaneous responses from the B95^{Plus} when any current values change by 15 amps, set the **IEC Current Default Threshold** setting to "15." Note that these settings are the default values of the deadbands. P_ME_NC_1 (parameter of measured value, short floating point value) points can be used to change threshold values, from the default, for each individual M_ME_NC_1 analog point. The default thresholds take effect when power is cycled to the B95^{Plus} (turned off then on).

Configuring IEC 60870-5-104 point lists

The monitored single point (MSP) and monitored measured data (MME) points for the IEC 60870-5-104 protocol can be configured to a maximum of 256 points. The MME points are analog. The value for each point is user-programmable and can be configured by assigning FlexLogic operands for binary MSP points or FlexLogic parameters for analog MME points.

The IEC 60870-5-104 point lists always begin with point 0 and end at the first "Off" value. Because an IEC 60870-5-104 point list must be one continuous block, any points assigned after the first "Off" point are ignored.

To configure the point lists:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > IEC 60870-5-104 > User Point List** to open the IEC 60870-5-104 user point list configuration window. When the option does not display, it means that it was not ordered.

The following settings are available.

Changes to the lists take effect when the B95^{Plus} is restarted.

Binary Input Point 0...Binary Input Point 255

Range: any FlexLogic operand

Default: Off

These settings represent the IEC 60870-5-104 binary MSP points and are configured by assigning an appropriate FlexLogic operand. Up to 256 MSP points can be configured for the IEC 60870-5-104 protocol.

Analog Input Point 0...Analog Input Point 255

Range: any FlexAnalog parameter

Default: Off

These settings represent the IEC 60870-5-104 analog MME points and are configured by assigning an appropriate FlexLogic parameter. Up to 256 MME points can be configured for the IEC 60870-5-104 protocol.

IEC 61850 communications

Ethernet ports 2 and 3 on the communications card in slot C support the manufacturing message specification (MMS) protocol as specified by IEC 61850. MMS is supported over the TCP/IP-over-Ethernet protocol stack. Polling, unbuffered reporting, and buffered reporting are supported. In addition, these ports support GSSE/GOOSE. The process card ports intended for communication with Bricks support sampled values.

Remote inputs and outputs provide a way to exchange digital state information between Ethernet-connected devices. The GSSE and GOOSE standards are used for this purpose.

GSSE/GOOSE configuration

IEC 61850 provides the following two fast mechanisms to exchange information between relays in a substation at rapid speeds for performing interlocking and other time-critical substation functions:

- **GSSE** — Generic Substation Status Event — Used for transferring status information only
- **GOOSE** — Generic Object-Oriented Substation Event — Supports a variety of information types, including measured values

The B95Plus supports GSSE and two variants of GOOSE: the so-called Fixed GOOSE and configurable GOOSE.

The sharing of digital point state information between GSSE/GOOSE equipped relays is essentially an extension to FlexLogic, allowing for distributed FlexLogic by making operands available to and from devices on a common communications network. The publisher (relays that source the data) packages the values of user selected FlexLogic and/or FlexAnalog operands in an Ethernet frame according to the GSSE/GOOSE protocol, using a multi-cast destination address. The network sends each multi-cast frame to all or to a configured subset of all the relays in the substation. Subscribers (relays that listen to the data) set other FlexLogic and/or FlexAnalog operands from the specific values in the received frames according to their configuration settings.

FlexLogic operands selected for transmission are scanned eight times per power system cycle; whenever a change of state is observed, the containing GSSE/GOOSE frame is immediately transmitted with the new state value. FlexAnalog operands selected for transmission are also scanned but at a lower rate; whenever a value is observed that is outside its configured bandwidth, the containing GSSE/GOOSE frame is immediately transmitted with the new value. The bandwidth is initially 10%, but can be changed using the IEC 61850 SetDataValues service. (The deadband extends to either side of the last reported value by the set percentage of 46 times the base current for current quantities, or by the set percentage of 275 times the voltage ratio setting for voltage quantities.)

To guard against loss of a change of state frame in the network, after the initial frame, the frame is repeated. GSSE and Fixed GOOSE frames are resent 16, 32, 64, 128, and 256 ms following the initial change of state frame. Configurable GOOSE frames are resent according to the Retransmission Profile setting. To allow subscribers to detect loss of communications and publisher offline, when no change of state has occurred, the frame is resent at the rate of the Default GSSE/GOOSE Update Time setting. Publishers include in the frame a time-to-live value, which indicates to the subscribers the time to wait for another frame before declaring the connection failed.

In dual-IP redundant configurations, the IED transmits and listens on both ports simultaneously.

Remote inputs and outputs provide a way to exchange digital state information between Ethernet-connected devices. The GSSE and GOOSE standards are used for this purpose.

The sharing of digital point state information between GSSE/GOOSE equipped relays is essentially an extension of FlexLogic, allowing for distributed FlexLogic by making operands available to and from devices on a common communications network. In addition to digital point states, GSSE/GOOSE messages identify the originator of the message and provide information required by the communication specification. All devices listen to network messages and capture data only from messages that have originated in selected devices.

IEC 61850 GSSE messages are compatible with UCA GOOSE messages and contain a fixed set of digital points. IEC 61850 GOOSE messages can, in general, contain any configurable data items.

Both GSSE and GOOSE messages are designed to be short, reliable, and have high priority. GOOSE messages have additional advantages over GSSE messages due to their support of VLAN (virtual LAN) and Ethernet priority tagging functionality.

The GSSE message structure contains space for 160 bit-pairs representing digital point state information. The IEC 61850 specification provides 32 DNA bit-pairs that represent the state of two pre-defined events and 30 user-defined events. All remaining bit-pairs are UserSt bit-pairs, which are status bits representing user-definable events. The B95^{Plus} implementation provides access to the first 32 UserSt bit-pairs. The B95^{Plus} also supports a so-called "Fixed GOOSE" service, wherein the data set consists of 32 DNA members and 32 UserSt members. Each member contains the same information as a bit-pair.

The IEC 61850 specification includes features that are used to cope with the loss of communication between transmitting and receiving devices. Each transmitting device sends a GSSE/GOOSE message on power-up, when the state of any included point changes, or after a specified interval (the default update time) if a change-of-state has not occurred. The transmitting device also sends a hold time that is the GSSE equivalent of time-to-live (TTL) in IEC GOOSE messages.

Receiving devices constantly monitor the communications network for messages they require, as recognized by the identification of the originating device carried in the message. Messages received from remote devices include the message TTL allowed. The receiving relay sets a timer assigned to the originating device to this time interval, and if it has not received another message from this device at time-out, the remote device is declared to be non-communicating, so it uses the programmed default state for all points from that specific remote device. If a message is received from a remote device before the TTL expires, all points for that device are updated to the states contained in the message and the hold timer is restarted. The status of a remote device, where "Offline" indicates non-communicating, can be displayed.

The B95^{Plus} provides for 64 remote inputs and 64 remote outputs.

In a UR^{Plus}-series IED, the device ID that identifies the originator of the message is programmed in the **IED Name** setting.

Traditionally hardwired digital inputs and outputs were used to exchange signals between relays. The IEC 61850 peer-to-peer messaging service is designed to replace this traditional signaling technique with messaging over Ethernet. Within the UR^{Plus} and B95^{Plus} family, the function of the contact inputs and outputs for signaling are, in effect, replaced by remote inputs and remote outputs.

The B95^{Plus} has an additional class of transmission called fixed GOOSE, which is really the standard GOOSE transmission restricted to digital values. The user can configure up to eight GOOSE data transmissions and 40 receptions and are collectively referred to as the configurable GOOSE within B95^{Plus} documentation. The relay supports an additional transmission and reception using Fixed GOOSE or GSSE. All GOOSE transmissions support 64 items within the data set, a unique name, VLAN ID, and priority and work as independently transmission/reception entities within the relay. The data that can be

configured for transmission within each of the eight transmissions can be a combination of digital and analog points. A digital status change or an analog point exceeding its dead-band setting will cause the associated data set to be transmitted within 1 msec of the event.

Use of GSSE or GOOSE needs to be enabled for the device, as outlined in this and subsequent sections.

To configure communication to remote devices:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > IEC 61850 > GSSE/GOOSE Configuration > Inputs/Outputs > Remote Devices** to open the remote devices configuration window.

Figure 14: Remote devices configuration settings

SETTING	ID	ETYPE APPID	DATASET
Remote Device 1	Remote Device 1	0	Fixed
Remote Device 2	Remote Device 2	0	Fixed
Remote Device 3	Remote Device 3	0	Fixed
Remote Device 4	Remote Device 4	0	Fixed
Remote Device 5	Remote Device 5	0	Fixed
Remote Device 6	Remote Device 6	0	Fixed
Remote Device 7	Remote Device 7	0	Fixed
Remote Device 8	Remote Device 8	0	Fixed
Remote Device 9	Remote Device 9	0	Fixed
Remote Device 10	Remote Device 10	0	Fixed
Remote Device 11	Remote Device 11	0	Fixed

The following settings are available for each of the 32 remote devices.

ID

Range: up to 65 characters

Default: Remote Device n

Up to 32 remote devices can be selected for settings purposes. A receiving relay must be programmed to capture messages from only those originating remote devices of interest. This setting is used to select specific remote devices by entering an exact identification (ID) assigned to those devices.

ETYPE APPID

Range: 0 to 16383 in steps of 1

Default: 0

This setting is used with GOOSE messages; it does not apply to GSSE messages. This setting identifies the application identification in the GOOSE message. It needs to match the corresponding settings on the sending device.

DATASET

Range: Fixed, GOOSE 1 through GOOSE 8

Default: Fixed

This setting provides for the choice of the UR^{Plus}-series fixed (DNA/UserSt) dataset (that is, containing DNA and UserSt bit-pairs), or one of the configurable datasets.


The dataset for the received data items must be made up of existing items in an existing logical node. For this reason, logical node GGIO3 is instantiated to hold the incoming data items. GGIO3 is not necessary to make use of the received data. The remote input data item mapping takes care of the mapping of the inputs to remote input FlexLogic operands. However, GGIO3 data can be read by IEC 61850 clients.

Transmission

To change the default GSSE/GOOSE update time:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > IEC 61850 > GSSE/GOOSE Configuration > Transmission > General** to open the GSSE/GOOSE general transmission configuration window.

Figure 15: General transmission configuration settings



The following setting is available.

Default GSSE/GOOSE Update Time

Range: 1 to 60 seconds

Default: 60 seconds

This setting specifies the time between GSSE or GOOSE messages when there are no remote output state changes to be sent. When remote output data changes, GSSE or GOOSE messages are sent immediately. This setting controls the steady-state heartbeat time interval.


This setting applies to GSSE, B95^{Plus} Fixed GOOSE, and configurable GOOSE.

GSSE

To configure the unit to transmit information using the GSSE protocol:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > IEC 61850 > GSSE/GOOSE Configuration > Transmission > GSSE** to open the GSSE transmission configuration window.

Figure 16: GSSE transmission configuration settings



The following settings are available.

Function

Range: Enabled, Disabled

Default: Disabled

This setting enables and disables the GSSE transmission functionality.

ID

Range: up to 65 ASCII characters

Default: GSSEOut

This setting represents the IEC 61850 GSSE name string sent as part of each GSSE message. This name string identifies the GSSE message to the receiving device, so that the receiving device can distinguish it from GSSE messages from other devices. This setting is required by IEC 61850 to be unique within the substation.

Destination MAC

Range: standard MAC address format

Default: 00 00 00 00 00 00

This setting specifies the destination Ethernet MAC address for the GSSE transmission. Make this address a multicast address and set the least significant bit of the first byte.

If this setting is specified as "00 00 00 00 00 00" (the default value), then a multicast MAC address is formed based on the MAC address of Ethernet ports 2 and 3. To view the MAC address of the B95^{Plus} at hand, page down the annunciator panel to the Communications Status page, or navigate in the software to **Actual Values > Product Information > Model Information**.

GSSE Minimum Hold Time

Range: 50 to 4000 ms in steps of 1

Default: 400 ms

This setting specifies the minimum hold time for GSSE data. This refers to the lifespan of the data, after which the subscribers consider it old data.

Fixed GOOSE

To configure the unit to transmit information using the fixed GOOSE protocol:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > IEC 61850 > GSSE/GOOSE Configuration > Transmission > Fixed GOOSE** to open the fixed GOOSE transmission configuration window.

Figure 17: Fixed GOOSE transmission configuration settings

SETTING	PARAMETER
Function	Disabled
ID	GOOSEOut
Destination MAC	00 00 00 00 00 00
GOOSE VLAN Priority	4
GOOSE VLAN ID	0
GOOSE ETYPE APPID	0
GOOSE Minimum Time To Live	400 ms

The following settings are available.

Function

Range: Enabled, Disabled

Default: Disabled

This setting enables and disables the fixed GOOSE transmission functionality.

ID

Range: up to 65 ASCII characters

Default: GOOSEOut

This setting represents the IEC 61850 GOOSE ID (GoID) name string sent as part of each GOOSE message. This name string identifies the GOOSE message to the receiving device, so that the receiving device can distinguish it from GOOSE messages from other devices. This setting is required by IEC 61850 to be unique within the substation.

Destination MAC

Range: standard MAC address format

Default: 00 00 00 00 00 00

This setting specifies the destination Ethernet MAC address for the fixed GOOSE transmission. Make this address a multicast address, and set the least significant bit of the first byte.

If this setting is specified as "00 00 00 00 00 00" (the default value), then a multicast MAC address is formed based on the MAC address of Ethernet ports 2 and 3. To view the MAC address of the B95^{Plus} at hand, page down the annunciator panel to the Communications Status page, or navigate in the software to **Actual Values > Product Information > Model Information**.

GOOSE VLAN Priority

Range: 0 to 7 in steps of 1

Default: 4

This setting indicates the Ethernet priority of GOOSE messages. This allows GOOSE messages to have higher priority than other Ethernet data. This setting is required by IEC 61850.

GOOSE VLAN ID

Range: 0 to 4096 in steps of 1

Default: 0

This setting allows the selection of a specific VLAN ID for each GOOSE sending device. The value can be left at its default when the feature is not required.

GOOSE ETYPE APPID

Range: 0 to 16383 in steps of 1

Default: 0

This setting allows the selection of a specific application ID for each GOOSE message. The APPID is another way by which the receiving device can distinguish this GOOSE message from other GOOSE messages. This setting is required by IEC 61850, to be unique within the substation.

GOOSE Minimum Time to Live

Range: 50 to 4000 ms in steps of 1

Default: 400 ms

This setting specifies the minimum time to live value for the GOOSE transmission data set. This refers to the lifespan of the data, after which the subscribers consider it old data.

Tx Configurable GOOSE

The configurable GOOSE settings allow the B95^{Plus} to be configured to transmit a number of IEC 61850 GOOSE messages, each with configurable datasets. Up to eight messages can be configured and transmitted, allowing for the optimization of data transfer between devices. This is useful for intercommunication between B95^{Plus} IEDs and devices from other manufacturers that support IEC 61850 GOOSE.


Items programmed for GOOSE messages 1 through 8 have changes in their values checked for change once per protection pass for digital data and less often for analog data. When a change is detected, a GOOSE message is transmitted immediately and repeated several times as determined by the Retrans Profile setting. When no change is detected, GOOSE messages are sent periodically at a rate determined by the Default GSSE/GOOSE Update Time setting to allow subscribers to verify link integrity and to communicate the values to subscribers that have just started up or have just had their communications restored.

IEC 61850 GOOSE messages contain a number of configurable parameters, all of which must be correct for successful data transfer. It is critical that the configured datasets at the transmission and reception devices are an exact match in terms of data structure and that the GOOSE addresses and name strings match exactly. Manual configuration is possible, but third-party substation configuration software can be used to automate the process. The EnerVista software can produce IEC 61850 ICD files and import IEC 61850 SCD files produced by a substation configurator.

To configure the unit to transmit information using the GOOSE protocol:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > IEC 61850 > GSSE/GOOSE Configuration > Transmission > Tx Configurable GOOSE** to open the configurable GOOSE transmission configuration window.

Figure 18: Configurable GOOSE transmission configuration settings



The following settings are available for each of the eight configurable GOOSE messages.

GOOSEOut Function

Range: Enabled, Disabled

Default: Disabled

This setting enables and disabled the configurable GOOSE transmission functionality.

GOOSEOut ID

Range: up to 65 ASCII characters

Default: GOOSEOut_1

This setting represents the IEC 61850 GOOSE ID (GoID) name string sent as part of each GOOSE message. This name string identifies the GOOSE message to the receiving device, so that the receiving device can distinguish it from GOOSE messages from other devices. This setting is required by IEC 61850 to be unique within the substation.

GOOSEOut Destination MAC

Range: standard MAC address format

Default: 00 00 00 00 00 00

This setting specifies the destination Ethernet MAC address for the configurable GOOSE transmission. Make this address a multicast address, and set the least significant bit of the first byte.

If this setting is specified as "00 00 00 00 00 00" (the default value), then a multicast MAC address is formed based on the MAC address of Ethernet ports 2 and 3. To view the MAC address of the B95^{Plus} at hand, page down the annunciator panel to the Communications Status page, or navigate in the software to **Actual Values > Product Information > Model Information**.

GOOSEOut VLAN Priority

Range: 0 to 7 in steps of 1

Default: 4

This setting indicates the Ethernet priority of GOOSE messages. This allows GOOSE messages to have higher priority than other Ethernet data. This setting is required by IEC 61850.

GOOSEOut VLAN ID

Range: 0 to 4096 in steps of 1

Default: 0

This setting allows the selection of a specific VLAN ID for each GOOSE sending device. This value can be left at its default if the feature is not required.

EGOOSEOut ETYPE APPID

Range: 0 to 16383 in steps of 1

Default: 0

This setting allows the selection of a specific application ID for each GOOSE sending device. The APPID is another way by which the receiving device can distinguish this GOOSE message from other GOOSE messages. This setting is required by IEC 61850, to be unique within the substation.

GOOSEOut ConfRev

Range: 1 to 16383 in steps of 1

Default: 1

This setting determines the value sent in the GOOSE message's ConfRev field whenever a Dataset Item's mapping is changed. This value increments automatically as described in IEC 61850 part 7-2.

GOOSEOut Minimum Time to Live

Range: 50 to 4000 ms in steps of 1

Default: 400 ms

This setting specifies the minimum time to live (TTL) for the GOOSE transmission data. This refers to the lifespan of the data, after which the subscribers consider it old data.

GOOSEOut Retransmission Profile

Range: None, Aggressive, Standard, Relaxed

Default: Standard

The B95^{Plus} supports four retransmission schemes: aggressive; standard; relaxed; and none. The "Aggressive" profile can be selected for trip schemes, the "Standard" profile for remedial action schemes, the "Relaxed" profile for analogues, and "None" for schemes that incorporate a separate confirmation scheme.

The following retransmission times are specified under these profiles:

- "Aggressive": 4, 8, 16, 32, and 64 ms
- "Standard": 16, 32, 64, 128, and 256 ms
- "Relaxed": 100, 200, 400, 800, and 1000 ms
- "None": no retransmission

For GSSE and fixed GOOSE, the profile is fixed at "Aggressive" and there is no associated setting.

GOOSEOut Dataset Item 1, Dataset Item 2, Dataset Item 3,..., Dataset Item 64

Range: all IEC 61850 information model basic attributes supported for transmission

Default: 0

These settings are used to select an attribute for each configurable GOOSE dataset item, that is, an IEC 61850 information model item that has a value.


To create a configurable GOOSE dataset that contains an IEC 61850 Single Point Status indication and its associated quality flags, the following dataset items can be selected: "GGIO1.ST.Ind1.stVal" and "GGIO1.ST.Ind1.q." The B95^{Plus} then creates a dataset containing these two data items. The status value for GGIO1.ST.Ind1.stVal is determined by the operand assigned to GGIO1 indication 1. Changes to this operand result in the transmission of GOOSE messages containing the defined dataset.

Rx Configurable GOOSE

To configure the unit to receive data using the GOOSE protocol:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > IEC 61850 > GSSE/GOOSE Configuration > Reception > Rx Configurable GOOSE** to open the configurable GOOSE reception configuration window.

Figure 19: Configurable GOOSE reception configuration settings



The following settings are available for each of the eight datasets for configurable GOOSE reception.

Dataset Item 1...Dataset Item 64

Range: all IEC 61850 information model basic attributes supported for reception

Default: None


These settings are used to select an attribute for each configurable GOOSE dataset item.

Remote devices

To configure communication to remote devices:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > IEC 61850 > GSSE/GOOSE Configuration > Inputs/Outputs > Remote Devices** to open the remote devices configuration window.

Figure 20: Remote devices configuration settings



The following settings are available for each of the 32 remote devices.

ID

Range: up to 65 characters

Default: Remote Device n

Up to 32 remote devices can be selected for settings purposes. A receiving relay must be programmed to capture messages from only those originating remote devices of interest. This setting is used to select specific remote devices by entering an exact identification (ID) assigned to those devices.

ETYPE APPID

Range: 0 to 16383 in steps of 1
Default: 0

This setting is used with GOOSE messages; it does not apply to GSSE messages. This setting identifies the application identification in the GOOSE message. It needs to match the corresponding settings on the sending device.

DATASET

Range: Fixed, GOOSE 1 through GOOSE 8
Default: Fixed

This setting provides for the choice of the UR^{PLUS}-series fixed (DNA/UserSt) dataset (that is, containing DNA and UserSt bit-pairs), or one of the configurable datasets.

The dataset for the received data items must be made up of existing items in an existing logical node. For this reason, logical node GGIO3 is instantiated to hold the incoming data items. GGIO3 is not necessary to make use of the received data. The remote input data item mapping takes care of the mapping of the inputs to remote input FlexLogic operands. However, GGIO3 data can be read by IEC 61850 clients.

Remote inputs

Remote inputs are FlexLogic operands at the receiving relay whose values are extracted from GSSE/GOOSE messages originating in remote devices. The B95^{PLUS} provides 64 remote inputs, each of which can be selected from a list consisting of 128 selections as follows: DNA-1 through DNA-32; UserSt-1 through UserSt-32; and DatasetItem 1 through 64. The function of DNA end UserSt inputs is defined by the user selection of the FlexLogic operand whose state is represented in the GSSE/GOOSE message.


The first two DNA items are reserved by IEC 61850 for “test” and “ConfRev” and are not to be used for other purposes.

Remote input are programmed to replicate the logic state of a specific signal from a specific remote device for local use. This programming is performed via the three settings indicated as follows.

To configure the unit for use of remote inputs:

1. In the **Online Area** window of the software, navigate to **Settings > Communications > IEC 61850 > GSSE/GOOSE Configuration > Inputs/Outputs > Remote Inputs** to open the remote inputs configuration window.

Figure 21: Remote inputs configuration settings



The following settings are available for each of the 32 remote inputs.

Name

Range: up to 12 characters
Default: Rem Ip n

This setting allows the user to assign descriptive text to the remote input.

Device

Range: 1 to 32 inclusive

Default: Remote Device n

This setting selects the number (1 to 32) of the remote device that originates the required signal, as previously assigned to the remote device via the **Remote Device ID** setting.

Bit Pair

Range: None, DNA-1 to DNA-32, UserSt-1 to UserSt-32, Dataset Item 1 to Dataset Item 64

Default: None

This setting selects the specific bit of the GSSE/GOOSE message required.

Default State

Range: On, Off, Latest/On, Latest/Off

Default: Off

This setting selects the logic state for this point if the local relay has just completed startup or the remote device sending the data is declared to be non-communicating. The following choices are available.

- The "On" value defaults the input to logic 1.
- The "Off" value defaults the input to logic 0.
- The "Latest/On" value freezes the input in case of lost communications. If the latest state is not known, such as after relay power-up but before the first communication exchange, the input defaults to logic 1. When communication resumes, the input becomes fully operational.
- The "Latest/Off" value freezes the input in case of lost communications. If the latest state is not known, such as after relay power-up but before the first communication exchange, the input defaults to logic 0. When communication resumes, the input becomes fully operational.

Events

Range: Enabled, Disabled

Default: Disabled

This setting enables and disables the logging of remote input status changes in the event recorder.

Remote DPS inputs


Remote double-point status (DPS) inputs are extracted from GOOSE messages originating in the remote device. The B95^{Plus} provides 16 remote double-point status inputs. Each remote double-point status input must be programmed to replicate the logic state of a specific signal from a specific remote device for local use.

The configurable GOOSE dataset items must be changed to accept a DPS item from a GOOSE dataset. Dataset items configured to receive any of "GGIO3.ST.IndPos1.stVal" to "GGIO3.ST.IndPos16.stVal" accept double-point status information that is decoded by the remote DPS inputs configured to this dataset item.

To configure the unit for remote double-point status inputs:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > IEC 61850 > GSSE/GOOSE Configuration > Inputs/Outputs > Remote DPS Inputs** to open the remote double-point status inputs configuration window.

Figure 22: Remote double-point status inputs configuration settings



The following settings are available for each of the 16 remote double-point status inputs.

Remote DPS Input Name

Range: up to 12 characters

Default: RemDPS Ip n

This setting allows the user to assign descriptive text to the remote DPS input.

Remote DPS Input Device

Range: Remote Device 1 through Remote Device 32

Default: Remote Device n

This setting selects the number (1 to 32) of the remote device that originates the required signal, as previously assigned to the remote device via the Remote Device ID setting.

Remote DPS Input Item

Range: None, Dataset Item 1 through Dataset Item 64

Default: None

This setting specifies the required bits of the GOOSE message.

Remote DPS Input Default State

Range: Intermediate, Off, On, Bad, Latest

Default: Latest

This setting selects the default value for the offline remote double-point status input if the relay has just completed startup or the remote device sending the data is declared to be non-communicating.

Remote DPS Input Events

Range: Enabled, Disabled

Default: Disabled

This setting enables and disables the logging of remote double-point status input status changes in the events recorder.

Remote outputs DNA


Remote outputs (1 to 32) allow FlexLogic operands to be inserted into transmitted GSSE/GOOSE messages. Each item in the message carries the state of a specific FlexLogic operand.

The first two DNA items are reserved by IEC 61850 for “test” and “ConfRev” and are not to be used for other purposes.

To configure the unit for remote output DNA bit-pairs:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > IEC 61850 > GSSE/GOOSE Configuration > Inputs/Outputs > Remote Outputs DNA** to open the remote inputs configuration window.

Figure 23: Remote outputs DNA bit-pair configuration settings



The following settings are available for each of the 32 DNA items.

Operand

Range: any FlexLogic operand

Default: Off

This setting specifies the FlexLogic operand assigned to the DNA item.


Remote outputs UserSt

Remote outputs UserSt 1 to 32 allow FlexLogic operands to be inserted into transmitted GSSE/GOOSE. Each item in the message carries the state of a specific FlexLogic operand. The setting above is used to select the operand that represents a specific UserSt function (as selected by the user) to be transmitted.

To configure the unit for remote output UserSt bit-pairs:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > IEC 61850 > GSSE/GOOSE Configuration > Inputs/Outputs > Remote Outputs UserSt** to open the remote inputs configuration window.

Figure 24: Remote output UserSt bit-pair configuration settings



The following settings are available for each of the 32 UserSt items.

Operand

Range: any FlexLogic operand

Default: Off

This setting specifies the FlexLogic operand assigned to the UserSt item.


Server configuration

As a publisher/sender of data, the B95^{Plus} acts as a server compliant to the IEC 61850 protocol.

To configure server settings:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > IEC 61850 > Server Configuration** to open the IEC 61850 server configuration window.

Figure 25: IEC 61850 server configuration settings



The following settings are available.

IED Name

Range: up to 32 characters

Default: IEDName

This setting represents the MMS domain name where all IEC/MMS logical nodes are located. Changes to this setting and the GOOSE dataset take effect when the unit is restarted. The setting value can be composed of up to 32 characters, including upper and lowercase letters, numbers, and the underscore (_) character. The first character in the string must be a letter.

Logical Device Instance

Range: up to 32 characters

Default: LDInst

This setting represents the IEC 61850 logical device where all IEC/MMS logical nodes are located. The setting value can be composed of up to 32 characters, including upper and lowercase letters, numbers, and the underscore (_) character. The first character in the string must be a letter.

LPHD DC PhyNam Location

Range: up to 80 ASCII characters

Default: Location

This setting represents a string that appears within the PhyName of the LPHD node. It can be composed of up to 80 characters, including upper and lowercase letters, numbers, and the underscore (_) character. The first character in the string must be a letter.

MMS TCP Port Number

Range: 1 to 65535 in steps of 1

Default: 102

This setting specifies the TCP port number for MMS connections.

GGIO1 status configuration


The GGIO1 logical node provides access to as many as 128 FlexLogic operands and associated timestamps and quality flags. Use GGIO1 to access FlexLogic operand values from the B95^{Plus} and to transmit FlexLogic operand values in configurable GOOSE

messages. Configuration settings are provided to select the number of operand status indications available in GGIO1 (8 to 128) and to select FlexLogic operands to drive the status of the GGIO1 status indications. Clients can utilize the IEC 61850 buffered and unbuffered reporting features available from GGIO1 to build sequence of events (SOE) logs and HMI display screens. Buffered reporting is recommended for SOE logs because the buffering capability reduces the chances of missing data state changes. Use unbuffered reporting for local status display.

To configure GGIO1 status:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > IEC 61850 > GGIO1 Status Configuration** to open the GGIO1 status configuration window.

Figure 26: IEC 61850 GGIO1 status configuration



The following settings are available.

Number of Status Points

Range: 8 to 128 in steps of 8

Default: 8

This setting specifies the number of “Ind” points (single point status indications) instantiated in the GGIO1 logical node. Changes to this setting take effect when the B95^{Plus} is restarted.

GGIO1 Indication 1...GGIO1 Indication 128

Range: any FlexLogic operand

Default: OFF

These settings assign FlexLogic operands to represent GGIO1 status indications.

Viewing IEC 61850 actual values

Data for IEC 61850 is available in multiple panels.

Viewing remote device status

The remote devices are the publishers/senders of the GSSE or GOOSE messages. These remote devices can be B95^{Plus}, UR^{Plus}-series, or other relays.

To view the online status of remote devices:

1. In the **Online Window** area of the software, navigate to **Actual Values > Communications > Inputs/Outputs > Remote Devices Status** to open the remote device status values window.

Figure 27: Remote device status values

REMOTE DEVICE	NAME	STATUS
All Remote Devices Online	Yes	Yes
Remote Device 1	Remote Device 1	Offline
Remote Device 2	Remote Device 2	Offline
Remote Device 3	Remote Device 3	Offline
Remote Device 4	Remote Device 4	Offline
Remote Device 5	Remote Device 5	Offline
Remote Device 6	Remote Device 6	Offline
Remote Device 7	Remote Device 7	Offline
Remote Device 8	Remote Device 8	Offline
Remote Device 9	Remote Device 9	Offline
Remote Device 10	Remote Device 10	Offline
Remote Device 11	Remote Device 11	Offline

The following status values are available for the IEC 61850 remote devices. The name and status display for each remote device.

All Remote Devices Online

Range: Yes, No

Default: Yes

This value indicates whether or not all programmed remote devices are online. If the state is "No," then at least one remote device is offline.

Name

Range: up to 65 characters

Default: Remote Device n

This value displays the name programmed for the corresponding remote device.

Status

Range: Online, Offline

This value indicates the present state of the corresponding remote device.

Viewing remote input actual values

To view remote input information:

1. In the **Online Window** area of the software, navigate to **Actual Values > Communications > Inputs/Outputs > Remote Inputs** to open the remote input actual values window.

Figure 28: Remote input actual values

REMOTE INPUT	NAME	STATUS
Remote Input 1	Rem I/P 1	Off
Remote Input 2	Rem I/P 2	Off
Remote Input 3	Rem I/P 3	Off
Remote Input 4	Rem I/P 4	Off
Remote Input 5	Rem I/P 5	Off
Remote Input 6	Rem I/P 6	Off
Remote Input 7	Rem I/P 7	Off
Remote Input 8	Rem I/P 8	Off
Remote Input 9	Rem I/P 9	Off
Remote Input 10	Rem I/P 10	Off
Remote Input 11	Rem I/P 11	Off

The following actual values are available for each remote input.

Name

Range: up to 12 characters

Default: Rem I/P n

This value displays the name programmed for the corresponding remote input.

Status

Range: On, Off

This value indicates the present state of the corresponding remote input. The state displayed is that of the remote point unless the remote device has been established to be "Offline," in which case the value shown is the programmed default state for the remote input.

Viewing remote double-point status input actual values

To view the remote double-point status input information:

1. In the **Online Window** area of the software, navigate to **Actual Values > Communications > Inputs/Outputs > Remote DPS Inputs** to open the remote double-point status input actual values window.

Figure 29: Remote double-point status input actual values

REMOTE DPS INPUT	NAME	STATUS
Remote DPS Input 1	RemDPS Ip 1	BAD
Remote DPS Input 2	RemDPS Ip 2	BAD
Remote DPS Input 3	RemDPS Ip 3	BAD
Remote DPS Input 4	RemDPS Ip 4	BAD
Remote DPS Input 5	RemDPS Ip 5	BAD
Remote DPS Input 6	RemDPS Ip 6	BAD
Remote DPS Input 7	RemDPS Ip 7	BAD
Remote DPS Input 8	RemDPS Ip 8	BAD
Remote DPS Input 9	RemDPS Ip 9	BAD
Remote DPS Input 10	RemDPS Ip 10	BAD
Remote DPS Input 11	RemDPS Ip 11	BAD
Remote DPS Input 12	RemDPS Ip 12	BAD
Remote DPS Input 13	RemDPS Ip 13	BAD
Remote DPS Input 14	RemDPS Ip 14	BAD
Remote DPS Input 15	RemDPS Ip 15	BAD
Remote DPS Input 16	RemDPS Ip 16	BAD

The following actual values are available for each remote double-point status input.

Name

Range: up to 12 characters

Default: RemDPS Ip n

This value displays the name programmed for the corresponding remote double-point status input.

Status

Range: On, Off, Intermediate, Bad

Default: Bad

This value indicates if the corresponding remote double-point status input is in the on (close), off (open), intermediate, or bad state.

Viewing remote device statistics

Information about remote devices can be viewed, such as the number of GSSE messages sent.

To view remote device statistics:

1. In the **Online Window** area of the software, navigate to **Actual Values > Communications > Inputs/Outputs > Remote Devices Statistics** to open the remote devices statistics window.

Figure 30: Remote device statistics

REMOTE DEVICE	NAME	STNUM	SQNUM
Remote Device 1	Remote Device 1	0	0
Remote Device 2	Remote Device 2	0	0
Remote Device 3	Remote Device 3	0	0
Remote Device 4	Remote Device 4	0	0
Remote Device 5	Remote Device 5	0	0
Remote Device 6	Remote Device 6	0	0
Remote Device 7	Remote Device 7	0	0
Remote Device 8	Remote Device 8	0	0
Remote Device 9	Remote Device 9	0	0
Remote Device 10	Remote Device 10	0	0
Remote Device 11	Remote Device 11	0	0

The following statistics are available for each of remote device.

Name

Range: up to 65 characters

Default: Remote Device n

This value displays the name programmed for the corresponding remote device.

StNum

Range: 0 to 4294967295 in steps of 1

Default: 0

This value is obtained from the indicated remote device, which increments it whenever a change of state of at least one dataset member value occurs.

SqNum

Range: 0 to 4294967295 in steps of 1

Default: 0

This value is obtained from the indicated remote device, which increments it whenever a GSSE/GOOSE message is sent. This number rolls over to zero when a count of 4294967295 is incremented. It is reset to zero when a change of state of a dataset member value occurs.

Creating an IED Capability Description (ICD) file

An ICD file describes the relay's implementation of the IEC 61850 information model and services in the XML file according to the IEC 61850-6 Edition 2 standard. The standard requires every IED to have such a file.

To generate an ICD file:

1. If using Windows 7, open the B95Plus installation folder, right-click the B95Plus.exe file, and select **Properties**. Click the **Compatibility** tab. Select the **Run this program as administrator** option. Click **OK** to apply and exit.
2. Launch the EnerVista software. In the **Online Window** area, right-click the device and select **Create ICD File**.
3. Select a destination directory, enter a file name, and click **Save**.

Real time clock and IRIG-B

There are four options for clock synchronization as follows: use SNTP over an Ethernet network; use IRIG-B; use the B95^{Plus} internal clock; or manual entry using EnerVista software. When SNTP is enabled at the same time as IRIG-B, the IRIG-B signal provides the time value. When neither SNTP nor IRIG-B is enabled, the B95^{Plus} internal real-time clock/

calendar free-runs. The internal clock/calendar used to timestamp events has the same accuracy as an electronic watch, approximately ± 1 minute per month. This section outlines IRIG-B setup.


The date and time can be synchronized to a known time base and to other devices using an IRIG-B signal. If an IEEE 1344 compliant IRIG-B generator is connected to the B95^{Plus}, then no additional information is required.

Configuration includes daylight savings time and time zone.

To configure the data and time settings using IRIG-B:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > Real Time Clock** menu item to open the real time clock configuration window.

Figure 31: Clock configuration settings



The following settings are available.

IRIG-B Signal Type

Range: None, DC Shift, Amplitude Modulated
Default: None

This setting selects the type of IRIG-B signal. Select “None” to disable IRIG-B. DC Shift refers to direct connection to digital systems. Amplitude modulation refers to audio tones or pulses.

Real Time Clock Events

Range: Enabled, Disabled
Default: Disabled

This setting enables and disables the logging of real-time clock events in the event recorder.

Time Zone Offset

Range: -24.0 to 24.0 hours in steps of 0.5
Default: 0.0 hours

This setting specifies the local time zone offset from Coordinated Universal Time (UTC, or Greenwich Mean Time) in hours. This setting has two uses. When the B95^{Plus} is time-synchronized with IRIG-B, or has no permanent time synchronization, the offset is used to calculate UTC time for IEC 61850 features. When the B95^{Plus} is time-synchronized with SNTP, the offset is used to determine the local time for the B95^{Plus} clock, since SNTP provides UTC time.

DST Function

Range: Enabled, Disabled

Default: Disabled

This setting enables and disables the daylight saving time (DST) function. The DST settings can be used to allow the B95^{Plus} clock to follow the DST rules of the local time zone, but not with IRIG-B. The DST settings are used when the B95^{Plus} is synchronized with SNTP, or when neither SNTP nor IRIG-B is used. The DST settings are ignored when IRIG-B synchronization is active.

DST Start Month

Range: January through December (all months of the year)

Default: April

This setting specifies the start month for daylight saving time. Examples are April in the northern hemisphere and October in the southern hemisphere.

DST Start Day

Range: Sunday through Saturday (all days of the week)

Default: Sunday

This setting specifies the day of the week to start daylight saving time.

DST Start Day Instance

Range: First, Second, Third, Fourth, Last

Default: First

This setting specifies the which instance of the day of the week to start daylight saving time. For example, if daylight saving time begins on the second Monday in April, program this setting to "Second."

DST Start Hour

Range: 0 to 23 in steps of 1

Default: 2

This setting specifies the hour to start daylight saving time. For example, if daylight saving time begins at 2:00 AM, program this setting to "2."

DST Stop Month

Range: January through December (all months of the year)

Default: November

This setting specifies the stop month for daylight saving time. Examples are October in the northern hemisphere and April in the southern hemisphere.

DST Stop Day

Range: Sunday through Saturday (all days of the week)

Default: Sunday

This setting specifies the day of the week to stop daylight saving time.

DST Stop Day Instance

Range: First, Second, Third, Fourth, Last

Default: First

This setting specifies the day of the week to stop daylight saving time. For example, if daylight saving time ends on the fourth Monday in November, program this setting to "Fourth."

DST Stop Hour

Range: 0 to 23 in steps of 1

Default: 2

This setting specifies the hour at which daylight saving time ends. For example, if daylight saving time ends at 4:00 AM, program this setting to "4."

Virtual inputs

Virtual inputs are FlexLogic operands that can be set and reset using DNP 3.0 and Modbus communication protocols.

You enable virtual inputs, then you are able to set and reset them.

To configure virtual inputs:

1. In the **Online Window** area of the software, navigate to **Settings > Communications > Virtual Inputs**.

To set and reset virtual inputs:

1. In the **Online Window** area of the software, navigate to **Actual Values > Communications > Commands > Virtual Inputs**.

Figure 32: Protection virtual inputs configuration settings

VIRT INPUT	FUNCTION	ID	TYPE	EVENTS
VIRT INPUT 1	Disabled	Virt Ip 1	Latched	Disabled
VIRT INPUT 2	Disabled	Virt Ip 2	Latched	Disabled
VIRT INPUT 3	Disabled	Virt Ip 3	Latched	Disabled
VIRT INPUT 4	Disabled	Virt Ip 4	Latched	Disabled
VIRT INPUT 5	Disabled	Virt Ip 5	Latched	Disabled
VIRT INPUT 6	Disabled	Virt Ip 6	Latched	Disabled
VIRT INPUT 7	Disabled	Virt Ip 7	Latched	Disabled
VIRT INPUT 8	Disabled	Virt Ip 8	Latched	Disabled
VIRT INPUT 9	Disabled	Virt Ip 9	Latched	Disabled
VIRT INPUT 10	Disabled	Virt Ip 10	Latched	Disabled
VIRT INPUT 11	Disabled	Virt Ip 11	Latched	Disabled

The following settings are available for each of the 64 virtual inputs. The default values shown are for virtual input 1.

Function

Range: Enabled, Disabled

Default: Disabled

When this setting is “Disabled,” the virtual input is forced to off (logic 0) regardless of any attempt to alter the input. When set to “Enabled,” the virtual input logic operands respond to received input signals.

ID

Range: up to 12 characters

Default: Virt Ip 1

This setting specifies an identifier assigned to each virtual input.

Type

Range: Self-Reset, Latched

Default: Latched

There are two types of operation: self-reset and latched. When this settings is “Self-Reset,” the output operand is asserted (logic 1) for only one evaluation of the protection FlexLogic equations and then returns to 0 when the input signal transits from off to on. When set to “Latched,” the virtual input sets the state of the output operand to the same state as the most recent received input.



The self-reset operating mode generates an output for a single evaluation of FlexLogic equations. If the operand is to be used anywhere other than internally in a FlexLogic equation, it will likely have to be lengthened in time. A FlexLogic timer with a delayed reset can perform this function.

Events

Range: Enabled, Disabled

Default: Disabled

When this setting is “Enabled,” every change in the protection virtual input state triggers an event in the sequence of events recorder.

Communication logic operands

The following communication logic operands are available for the B95^{Plus}. They are listed alphabetically by operand syntax and reflect the default operand names. If required, these operands can be assigned user-defined names through the **Settings > Configure FlexOperands** menu item.

GSSE/Fixed GOOSE DMA operands

IEC61850 ConfRev Asserted when the second bit-pair/attribute in GSSE or Fixed GOOSE message is being received in the 1 state.

IEC61850 Test Mode Asserted when the first bit-pair/attribute in GSSE or Fixed GOOSE message is being received in the 1 state.

Remote devices operands

Remote Device 1 On (RD1) Asserted when GOOSE or GSSE messages are being received from remote device 1.

Remote Device 1 Off (RD1) Complement of operand Remote Device 1 On (RD1)

Remote Device 2...32 The operands listed above are also available for remote devices 2 through 32.

Remote double-point status input operands

RemDPS Ip 1 Interm (RDSPI1) .. Asserted when the mapped GOOSE message attribute is being received in the intermediate state (0).

RemDPS Ip 1 Off (RDSPI1) Asserted when the mapped GOOSE message attribute is being received in the off state (1).

RemDPS Ip 1 On (RDSPI1) Asserted when the mapped GOOSE message attribute is being received in the on state (2).

RemDPS Ip 1 Bad (RDSPI1) Asserted when the mapped GOOSE message attribute is being received in the bad state (3).

Rem I/P 2...64 The operands listed above are also available for remote double-point status inputs 2 through 64.

Remote input operands

Rem I/P 1 ON (RI1) Asserted when the mapped GOOSE or GSSE message bit-pair/attribute is being received in the 1 state.

Rem I/P 2...64 The operand listed above is also available for remote inputs 2 through 64.

Virtual input operands

Virt Ip 1 On (VI1) Asserted when virtual input 1 has been set by a Modbus client or EnerVista UR Plus Setup.

Virt Ip 2...32 The operand listed above is also available for virtual inputs 2 through 64.

Multilin B95^{Plus} Bus Protection System

Chapter 7: Remote resources

Remote resources refers to the B95^{Plus} interface to the HardFiber Bricks that allow replacement of copper wiring in substation switchyards with optical fiber communications.

Field units

A field unit is a logical representation of a HardFiber Brick within the relay. Field units are firmware objects that link or bridge the relay to the Bricks. Bricks are the physical devices implementing the hardware interface a power system device, such as a breaker.

The primary responsibility of the field units is to ensure the relay is connected to the same Brick that was verified as the correct Brick during previous testing. This ensures the field process information the relay receives and the field commands the relay issues are from/to the correct origin/destination. This prevents, for instance, an inadvertent patching at the crossconnect panel from causing a trip intended for a breaker to instead raise a transformer's tap position, or from causing a transformer sudden gas pressure trip contact input to be handled as a breaker low temperature alarm. It also prevents inadvertent swapping of a Brick with 5 A nominal current inputs with a replacement unit with 1 A nominal inputs from causing a 1 pu current into a bus differential zone from appearing to be a 5 pu current.

The field unit accepts data from and sends commands to only Bricks with the user specified serial number and order code, only through the specified digital core of that Brick, and only through the process card optical fiber port of that field unit. If the Brick is swapped out or if the optical fiber connection between the relay and a Brick is changed, then the field unit normally alarms and blocks its data and commands. An exception is when the relay is in the test forcible mode, during which it accept Bricks with serial numbers and digital cores other than those specified. See the Test Mode section later in this document for more information.

Eight field units are provided for in each process card specified by the relay's order code, one for each optical fiber port. They are designated by the process card slot code and the optical fiber port number of the card that the field unit uses. Process cards can be in slots F and J. Ports on each process card are numbered 1 through 8, top to bottom. Thus the field unit designation associated with the first port on the first process card is "F1," while the last field unit is designated "J8."

Configure the settings for the field units, such as entering the serial numbers, as outlined in the following sections.


Settings

Each field unit is provided with an ID setting by which the user can assign a meaningful application-related name, a function setting to enable/disable the field unit and its Brick, and settings specifying the serial number, order code, and core number of the Brick to which it connects.

To configure the field unit Brick settings:

1. In the **Online Window** area of the software, navigate to **Remote Resources > Field Units**.

Figure 1: Field unit configuration



The following settings are available.

ID

Range: up to 20 characters

Default: blank

The text entered here identifies the field unit and its Brick. Typically, the text is the name of the power system device to which the field unit's Brick is connected (for example, "Breaker 1").

Function

Range: Disabled, Enabled

Default: Disabled

When disabled, the field unit forces all commands to the Brick to off, and forces all values received from the Brick to their failsafe values. It also suppresses self-test errors and troubles for that field unit. Effectively, the disabled value of this setting detaches logically a Brick connected physically on the associated port. The disabled value is applied to unused process card ports, and can also be used to temporarily suppress communications with a Brick.

Brick Order Code

Range: CC55, CV50, CC11, CV10

Default: CC55

This setting selects the order code of the Brick intended for interfacing with the field unit. The field unit communicates with a Brick only when the Brick order code setting matches that of the connected Brick. This is a security feature implemented to prevent inadvertent use of a Brick of other than the intended type. The setting is used by the relay to determine the AC input type, CT or VT, and for CT inputs, its nominal current.

"CC55": Two 5 amp current banks.

"CV50": One 5 amp current bank and one voltage bank.

“CC11”: Two 1 amp current banks.

“CV10”: One 1 amp current bank and one voltage bank.

Brick Serial Number

Range: up to 12 alphanumeric characters

Default: 000000000000

This setting specifies the serial number of the Brick that is intended to interface with the field unit. If you do not know the serial number, see the next section to Auto Populate the information.

The field unit communicates process information with a Brick only when the Brick serial number setting matches that of the connected Brick, a security feature to prevent inadvertent fiber connections resulting in incorrect mapping of Brick inputs/outputs to the relay. An exception is when the relay is in the test forcible mode, during which it accepts Bricks with serial numbers other than the specified serial number. See the Test Mode section later in this document for more information.

Brick Core

Range: 1...4

Default: 1

This setting selects the digital core that the field unit is intended to interface with in the Brick. The field unit communicates with a Brick only when the Brick core setting matches that of the actual connected digital core. This security feature is implemented to detect unintended fiber connections. An exception is when the relay is in the test forcible mode, during which it accepts Brick digital cores other than the specified core. See the Test Mode section later in this document for more information.


Auto populate

Since the setting engineer does not typically have the Brick serial numbers available at the time the relay settings are created, an auto-populate feature is provided when the EnerVista B95^{Plus} Setup software is in online mode. It changes the serial number to match the Brick connected. Invoke this feature only after tests have established that the field units are communicating with the correct Bricks.

To automatically populate fields for a Brick:

1. In the **Online Window** area of the software, navigate to **Settings > Remote Resources > Field Units**.
2. Click an **Auto Populate S/N** button, the serial number, order code, and digital core number being received from the Brick on the field unit's port are checked, and the field unit settings display side-by-side.
3. Press the **Change** button in this window to enter the actual Brick serial number into the field unit setting window, which must then be saved as with other setting changes.

Figure 2: Auto-populate serial number window



Actual values

This value indicates the status of the field unit. Alarm states are shown in red and normal states in green or grey.

The alarm states are as follows:

- **Communications Lost** — Communications with the Brick has been lost
- **Equipment Mismatch** — The Brick serial number, order code, or digital core number does not match the field unit settings
- **Trouble** — The Brick is reporting one or more diagnostic alarm. See the raw data viewer screen located under **Maintenance** in the EnerVista software for more information on the diagnostic alarm.
- **OK** — Indicates that all data is available. When a field unit state is OK, the corresponding field unit FlexLogic operand (for example, F1 On) is asserted, otherwise this operand is off.
- **Disabled** — Indicates that the field unit has been manually disabled through the function setting

When the EnerVista software is offline, actual values do not appear.

FlexLogic operands

FLEXLOGIC OPERANDS - FIELD UNITS

- F1 Field Units On: On when all data originating from the associated brick is available.
- F1 Field Unit Off:..... On when some data originating from the associated brick is unavailable or unreliable, and therefore some data has been forced to its failsafe state.
- F2 to F8; J1 to J8:..... The operands listed above are also available for all other field units in process cards specified by the order code.

Field contact inputs

A field contact input (FCI) is the logical representation within the B95^{Plus} of a Brick contact input.

Each FCI has a “On” operand (contact closed) and an “Off” operand (contact open). The “On” operand is set to the FCI’s failsafe state, and the “Off” operand to the complement of the FCI’s failsafe state, when valid state reports are not being received from the Brick or contact chatter is detected for that FCI. These operands can be used wherever other FlexLogic operands can be used, such as in FlexLogic equations and as inputs for the protection elements.

The chatter detection algorithm and its settings are described in the Field Contact Inputs Chatter Detection section that follows.

Eighteen FCIs are provided for each field unit, that is, one FCI for each Brick contact input. They are designated by the field unit designation, the FCI code “/FCI,” and the Brick contact input number. Field unit designations range from F1 through J8, and Brick contact input numbers range from 1 through 18. Thus the FCIs are designated “F1/FCI1” through “J8/FCI18.”


Settings

Each FCI is provided with settings to assign a logical name, failsafe state, debounce duration, and whether changes of state are recorded by the events recorder. These settings are outlined in this section.

To configure the FCI settings:

1. In the **Online Window** area of the software, navigate to **Settings > Remote Resources > Field Contact Inputs**.

Figure 3: Configuring FCIs



The following settings are available.

ID

Range: up to 20 characters
Default: blank

The text entered here is displayed in settings and actual values displays. Typically, the text will be the name of the power system quantity that the Brick contact input measures (for example, “Breaker 1 closed”).

Failsafe Value

Range: Off, On
Default: Off

This setting selects the state assumed by the FCI operand when the state of the contact is not available or chatter is detected. The contact input state is considered unavailable when the field unit is disabled, Brick communications fail, or the Brick reports self-test alarms potentially affecting the contact inputs, such as wetting supply fail. When unavailable, the field unit’s Field Unit Off operand is activated. When a process card detects chatter on any contact, the relay’s Contact Chatter self-test is activated. These two operands may be used with appropriate logic to override the FCI operand as required.

The appropriate value for this setting depends on the appropriate relay behavior when the contact state is not available. This in turn depends on the function of the contact. In the case where the FCI operands of dual redundant contacts are OR'd, FCI failsafe values of Off will result in the output of the OR following the healthy FCI should one contact state become unavailable. In the case contact closure that results in bus tripping such as a low-low insulating gas density contact, a failsafe value of Off will not cause tripping due to contact state unavailability. An auxiliary relay contact that opens on loss of process equipment power with a failsafe value of On will not generate spurious power alarm should the contact state become unavailable.



Changing this setting can cause momentary dropout of the FCI output operands. GE recommends that this setting not be changed while the relay is in service.

Debounce Time

Range: 0.0 to 16.0 ms in steps of 0.5

Default: 2.0 ms

This setting specifies the time required to overcome induced noise in field contact wiring and contact bouncing conditions. FCI operands do not follow a change of state of the contact until the contact is known to have settled into a new state for as long as the set debounce time. This setting is therefore a delay in the relay's internal recognition of the new contact state.

In particularly electrically noisy environments, a longer setting is required to prevent the relay from responding to noise hits. Where the user contact takes a long time to settle, and it is necessary to avoid the relay detecting multiple transitions on a single contact change of state, a long setting is required. However, due consideration must be taken of the tolerance of the application to the delay introduced by debouncing.



Changing this setting can cause momentary dropout of the FCI output operands. GE recommends that this setting not be changed while the relay is in service.

Events

Range: Enabled, Disabled

Default: Enabled

When "Enabled," every activation of an FCI operand is logged in the event record. Preliminary bounces that precede the debounced change of state are not recorded.

Actual values

There are two ways to view actual values: in the settings window or the actual values window.

To view FCI information in the settings window:

1. In the **Online Window** area of the software, navigate to **Settings > Remote Resources > Field Contact Inputs**.
2. Click the **Actual Values** field to expand the content.

To view FCI information in the actual values window:

1. In the **Online Window** area of the software, navigate to **Actual Values > Remote Resources > Field Contact Inputs**.

The following information displays.

Actual Values*Range: On, Off*

This field, when the EnerVista software is online, indicates the status of the FCI operand. This is not a setting.

A value of “On” signifies a closed contact and is displayed as an illuminated red LED indicator. A value of “Off” signifies an open contact and is displayed as an extinguished LED indicator. When the EnerVista software is offline, actual values do not appear.

FlexLogic operands**FLEXLOGIC OPERANDS - FIELD CONTACT INPUTS**

F1/FCI1 On:	This operand is asserted when the associated brick contact input state is closed, the contact input status is available, and chatter is not detected on that contact input. Otherwise, this operand is set to the associated failsafe value.
F1/FCI1 Off:	This operand is asserted when the associated brick contact input state is opened, the contact input status is available, and chatter is not detected on that contact input. Otherwise, this operand is set to the complement of the associated failsafe value.
F1/FCI2 to J8/FCI18:	The operands listed above are also available for all other FCIs in process cards specified by the relay's order code.

Field contact inputs chatter detection

Chatter is the name given to the behavior of a contact that is continuously opening and closing due to the quantity that it is monitoring being near the operate threshold, and hysteresis being less than instability in the quantity. For example, the output contact of an overcurrent relay measuring feeder load current can chatter when the average load current is near the pickup setting and the load is randomly increasing and decreasing due to changing demand.


The B95^{Plus} includes a chatter detection feature, which must be enabled.

When the contact input chatter detection feature is enabled, chatter is declared on an FCI when its state has been rapidly and continuously changing for some time, to limit the space consumed in the events record. In particular, chatter is declared for a FCI when the count of FCI state changes exceeds a settable threshold. These counters are periodically cleared to zero so that a low rate of state change does not result in chatter declaration; this period also settable. When chatter is declared on an FCI, that FCI's On operand is forced to its failsafe value, and its Off operand forced to the complement of the failsafe value.

The contact chatter condition resets for a contact input if the input undergoes no state changes for two successive periods.

The Contact Chatter minor self-test is activated while chatter is detected on any field contact input on any process card.


Figure 4: Chatter Time



To set the chatter detection:

1. In the **Online Window** area of the software, navigate to **Settings > Remote Resources > Field Contact Inputs Chatter Detection**.

Figure 5: Setting chatter detection



The following settings are applied to all available field contact inputs on the indicated process card.

F, J Function

Range: Enabled, Disabled
 Default: Disabled

This setting enables and disables the chatter detection feature. It applies to all contact inputs on the indicated process card.

F, J Chatter Time

Range: 1 to 100 seconds in steps of 1
 Default: 10 seconds

This setting specifies the period over which the Brick contact change of state counters count. Applies to all contact inputs on the indicated process card.

F, J Chatter State Changes

Range: 10 to 100 in steps of 1
 Default: 30

This setting specifies the number of state changes that must occur in one period as defined by the Chatter Time setting before issuing the Contact Chatter self-test and forcing the FCI status to its failsafe value. It applies to all contact inputs on the indicated process card.

Field contact outputs

A field contact output (FCO) is the logical representation within the B95^{Plus} of a Brick SSR or form-C contact output. Each FCO commands its associated physical contact according to the state of a user-selected FlexLogic operand. Each FCO also provides FlexLogic operands that follow the contact condition monitoring implemented by the Brick. Both SSR and

form-C contact outputs have DOn operands that reflect the state of the physical contact output driver, and thus the contact itself. These driver operands are provided as even if the field contact output is off, the contact may be driven on by other relays. The DOn operand may be used for example in a breaker close interlocking scheme intended to prevent issuing a close while a trip is being issued from another relay.

The SSR FCOs also have VOn and IOn operands. The VOn operand is On when an external voltage is detected across the output. The VOn operand is typically used for trip circuit or close circuit continuity monitoring. The IOn operand is On when current is detected flowing through the output. The IOn operand is intended to indicate that the contact has actually closed and contributed to the tripping of a circuit breaker in situations where another Brick is at the same time tripping the breaker.

If communications from a particular relay to a Brick are lost or disabled, the Brick behaves as if the field contact output command is off. If no other relay is driving the contact closed, it goes open. The output driver, voltage and current monitoring operands revert to the condition of driver off, no voltage detected and no current detected. If this monitor operand action is not appropriate for the application, use FlexLogic with the field unit communications failure operand (for example, F1 Off) to develop suitable action.

Six FCOs are provided for each field unit, i.e. one FCO for each of the four Brick SSR contact outputs, and one each for the two Brick form-C contact outputs. They are designated by the field unit designation, the FCO code "/FCO," and the Brick contact output number. Field unit designations range from F1 through J8, and Brick contact output numbers range from 1 through 4 for SSR outputs and 5 and 6 for form-C outputs. Thus the FCOs are designated "F1/FCO1" through "J8/FCO6."


Settings

Each FCO is provided with settings to assign a logical name, operate and seal-in operands, and whether changes of state are recorded by the events recorder.

To configure the FCO settings:

1. In the **Online Window** area of the software, navigate to **Settings > Remote Resources > Field Contact Outputs**.

Figure 6: Configuring FCOs



The following settings are available.

ID

Range: up to 20 characters

Default: blank

The text entered here appears in event records and other places where the FCO is referenced. Typically, the text is the name of the power system quantity that the Brick contact input controls (for example, "Breaker 1 trip out").

Operate Operand*Range: any FlexLogic™ operand**Default: OFF*

This setting selects an operand to control the FCO command. When the selected operand is “On,” there is no major self-test, and the relay test mode is either disabled or forcible, the FCO command is On. If the associated field unit communications status is OK, the Brick contact output is driven on.

Seal-in Operand*Range: any FlexLogic™ operand**Default: OFF*

This setting selects an operand to control the FCO command seal-in feature. Once an FCO is turned on by the operate operand, it stays on until both the operate and the seal-in operands are off. The seal-in operand cannot turn the FCO command on, it can only hold it on once the operate operand has turned it on.



NOTE

The seal-in feature provided by the FCO is local only. It does not seal-in a contact output that was turned on by another relay, it only seals in the local FCO command.

Events*Range: Enabled, Disabled**Default: Enabled*

When “Enabled,” every change of state of the FCO command operand (On or Off) and every activation of the monitoring operands (DOn, DOff, VOn, VOff, IOn and IOff) state is logged in the event record.

Actual values

There are two ways to view actual values: in the settings window or the actual values window.

To view FCO information in the settings window:

1. In the **Online Window** area of the software, navigate to **Settings > Remote Resources > Field Contact Outputs**.
2. Click the **Actual Values** field to expand the content.

To view FCO information in the actual values window:

1. In the **Online Window** area of the software, navigate to **Actual Values > Remote Resources > Field Contact Outputs**.

The following information displays.

Actual Values Output Command*Range: On, Off*

This field, when the EnerVista software is online, indicates the status of the outgoing FCO command. This is not a setting.

A value of “On” signifies the FCO command is On and is displayed as an illuminated red LED indicator. A value of “Off” signifies the FCO command is Off and is displayed as an extinguished LED indicator. When the EnerVista software is offline, this field does not appear.

Actual Values Driver Feedback*Range: On, Off*

This field, when the EnerVista software is online, indicates the actual status of the physical Brick contact output driver, that is, the value of the DOn operand. This is not a setting.

When the EnerVista software is offline, actual values do not appear.

Actual Values Voltage Monitor*Range: On, Off*

This field, when the EnerVista software is online, indicates the voltage monitor status of the physical Brick contact output, that is, the value of the VOn operand.



NOTE

The contact must be in the opened state with voltage applied to the control circuit in order for the voltage monitor to pickup. Voltage monitoring is provided for the SSR outputs only (FCO1 through FCO4).

When the EnerVista software is offline, this field does not appear.

Actual Values Current Monitor*Range: On, Off*

This field, when the EnerVista software is online, indicates the status of the current monitor on the physical Brick contact output, that is, the value of the IOn operand.



NOTE

The contact must be in the closed state with current flowing in the control circuit for the current monitor to pickup. Current monitoring is provided for the SSR outputs only (FCO1 through FCO4)

When the EnerVista software is offline, this field does not appear.

FlexLogic operands

FLEXLOGIC OPERANDS - FIELD CONTACT OUTPUTS

F1/FCO1 On:	This operand is asserted when the field contact output is on.
F1/FCO1 Off:	This operand is asserted when the field contact output is off.
F1/FCO1 DOn:	This operand is asserted when the associated brick physical contact output driver is on.
F1/FCO1 DOff :	This operand is asserted when the associated brick physical contact output driver is off.
F1/FCO1 VOn:	This operand is asserted when voltage is detected across the physical contact.
F1/FCO1 VOff:	This operand is asserted when no voltage is detected across the physical contact.
F1/FCO1 IOn:	This operand is asserted when current is detected through the physical contact.
F1/FCO1 IOff:	This operand is asserted when no current is detected through the physical contact.
F1/FCO2 to J8/FCO6:	The On, Off, DOn, DOff operands listed above are also available for all other FCOs in process cards specified by the relay's order code. The VOn, VOff, IOn, and IOff operands are available for all FCO1 through FCO4 in process cards specified by the relay's order code.

Field latching outputs

A field latching output (FLO) is the logical representation within a B95^{Plus} of a physical Brick magnetically latched mechanical contact output. Each FLO commands its associated physical latching output according to the state of two user-selected FlexLogic operands, open and close. Each FLO also provides FlexLogic operands that follow the latching output monitoring implemented by the Brick.

Each FLO has Opened and Closed operands that reflect the status of an auxiliary contact of the latching output (that is, the actual state of the latching output contact). Each FLO also has OpnDOn and ClsDOn operands that reflect the state of the latching output’s open and close drivers. These driver operands are provided because even if the local relay is driving the latching output closed, the output can be driven open by other relays – open dominance of the latching output is forced by Brick hardware.

The user need not provide logic to extend open or close operand pulses – the Brick seals-in open and close commands for a time sufficient to fully operate the latching output.

If communications from a particular relay to a Brick are lost or disabled, the latching output stays in its last commanded state, unless some other relay is commanding it otherwise. The latching output Opened and Closed operands monitoring the status of the auxiliary contact of the latching output revert to the closed state. The latching output driver monitoring operands OpnDOn and ClsDOn revert to the condition of drivers off. If this operand action is not appropriate for the application, use FlexLogic with the field unit communications failure operand (for example, F1 Off) to develop suitable action.


One FLO is provided for each field unit, that is, one FLO for each Brick’s latching output. They are designated by the field unit designation, and the FLO code “/FLO.” Field unit designations range from F1 through J8. Thus the FLOs are designated “F1/FLO” through “J8/FLO.”

Settings

To configure FLO settings:

1. In the **Online Window** area of the software, navigate to **Settings > Remote Resources > Field Latching Outputs**.

Figure 7: Configuring FLOs



Each FLO is provided with settings to assign a logical name, open and close operands, and whether changes of state are recorded by the events recorder. These settings are described as follows.

ID

Range: up to 20 characters

Default: blank

The text entered here displays in settings and actual values. Typically, the text is the name of the power system quantity that the Brick latching output controls (for example, “Breaker 1 lockout”).

Open Operand

Range: any FlexLogic™ operand

Default: OFF

This setting selects an operand to control the FLO open command. When the selected operand is “On,” there is no major self-test, and the relay test mode is either disabled or forcible, the FLO open command is On. If the associated field unit communications status is OK, the Brick latching output is driven open.

Close Operand

Range: any FlexLogic™ operand

Default: OFF

This setting selects an operand to control the FLO close command. When the selected operand is “On,” there is no major self-test, and the relay test mode is either disabled or forcible, the FLO close command is On. If the associated field unit communications status is OK, and no other relay is commanding the latching contact open, the Brick latching output is driven closed.

Events

Range: Enabled, Disabled

Default: Enabled

When “Enabled,” every activation of a monitoring operand (Opened, Closed, OpnDOn, OpnDOff, ClsDOn and ClsDOff) is logged in the event record.

Actual values

There are two ways to view actual values: in the settings window or the actual values window.

To view FLO information in the settings window:

1. In the **Online Window** area of the software, navigate to **Settings > Remote Resources > Field Latching Outputs**.
2. Click the **Actual Values** field to expand the content.

To view FLO information in the actual values window:

1. In the **Online Window** area of the software, navigate to **Actual Values > Remote Resources > Field Latching Outputs**.

The following information displays.

Actual Values Open Command

Range: On, Off

This field, when the EnerVista software is online, indicates the status of the outgoing FLO open command. This is not a setting.

A value of “On” signifies the FLO open command is On and is displayed as an illuminated red LED indicator. A value of “Off” signifies the FLO open command is Off and is displayed as an extinguished LED indicator. When the EnerVista software is offline, this field does not appear.

Actual Values Close Command

Range: On, Off

This field, when the EnerVista software is online, indicates the actual status of the outgoing FLO close command. This is not a setting.

A value of “On” signifies the FLO close command is On and is displayed as an illuminated red LED indicator. A value of “Off” signifies the FLO close command is Off and is displayed as an extinguished LED indicator. When the EnerVista software is offline, this field does not appear.

Actual Values Open Driver

Range: On, Off

This field, when the EnerVista software is online, indicates the status of the physical Brick latching contact open driver, that is, the value of the OpnDOn operand. This is not a setting.

When the EnerVista software is offline, this field does not appear.

Actual Values Close Driver

Range: On, Off

This field, when the EnerVista software is online, indicates the actual status of the physical Brick latching output close driver, that is, the value of the ClsDOn operand. This is not a setting.

When the EnerVista software is offline, this field does not appear.

Actual Values Status

Range: Opened, Closed

This field, when the EnerVista software is on-line, indicates the physical Brick latching output status, that is, the value of the Opened and Closed operands. Open is displayed as an illuminated red LED indicator, closed as an extinguished LED indicator.

When the EnerVista software is offline, this field does not appear.

FlexLogic operands

FLEXLOGIC OPERANDS - FIELD LATCHING OUTPUTS

E1/FLO Opened:.....	This operand is asserted when the associated brick physical latching output is opened.
E1/FLO Closed:.....	This operand is asserted when the associated brick physical latching output is not opened (i.e. closed).
E1/FLO OpnDOn:.....	This operand is asserted when the associated brick physical latching output open driver is on.
E1/FLO OpnDOff:.....	This operand is asserted when the associated brick physical latching output open driver is off.
E1/FLO ClsDOn:.....	This operand is asserted when the associated brick physical latching output close driver is on.
E1/FLO ClsDOff:.....	This operand is asserted when the associated brick physical latching output close driver is off.
F1/FLO to J8/FLO:.....	The operands listed above are also available for all other FLOs in process cards specified by the relay’s order code.

Shared inputs and outputs

A shared input (SI) is an object that maps a single received shared I/O channel to a FlexLogic operand.

A shared output (SO) is an object that maps a FlexLogic operand to one or two shared I/O channels.

Shared I/O is a feature that allows all relays connected to a particular Brick to communicate with each other via the Brick on multiple distinct binary channels. This feature is intended for applications requiring protection quality inter-relay signalling with high speed and deterministic latency. Application possibilities include breaker failure initiation, and inter-zone tripping. The B95^{Plus} provides shared outputs (SO) to transmit the values of local FlexLogic operands on selected shared I/O channels. The B95^{Plus} also provides shared inputs (SI) to connect selected received shared I/O channels to local operands that in turn can control the various features of the relay. When any shared output operates, a signal is sent to the Brick on the optical fiber link, and the Brick sends the signal back to all the connected relays. Like PLC carrier on/off signalling, multiple shared outputs can send on the same channel. If any shared output on a particular channel is on, all shared inputs mapped to that channel receives are on. Only when all shared outputs on that channel are off are the shared inputs off.

Shared input settings


A shared input (SI) is an object that maps a single received shared I/O channel to a FlexLogic operand. These operands can be used wherever other FlexLogic operands can be used, such as FlexLogic equations and as inputs for protection elements.

Sixteen SIs are provided for each process card specified by the relay's order code. They are designated by the process card slot code, the SI code "/SI," and an SI sequence number, 1 through 16. Process cards can be in slots F and J. Thus the SIs are designated "F/SI1" through "J/SI16."

To configure shared input settings:

1. In the **Online Window** area of the software, navigate to **Settings > Remote Resources > Shared Inputs**.

Figure 8: Configuring shared input settings



Each SI is provided with settings to assign a logical name, an origin field unit, and channel number, and whether changes of state are recorded by the event recorder. These settings are described as follows.

ID

Range: up to 20 characters

Default: blank

The text entered here displays in settings and actual values. Typically, the text describes the information being communicated (for example, "Bkr 1 BF Init Tx").

Origin Field Unit

Range: None, any field unit on the same process card as the shared input (for example, for process card F shared inputs, range is F1 ...8)

Default: None

This setting maps the SI to a field unit.

Origin Channel #,

Range: 1 to 15 in steps of 1

Default: 1

This setting maps the SI to a particular shared I/O channel on the origin field unit.

Events

Range: Enabled, Disabled

Default: Enabled

When "Enabled," the received channel transitions between On, Off, TestOn, and TestOff are logged in the event record.

Shared input actual values

There are two ways to view actual values: in the settings window or the actual values window.

To view shared input information in the settings window:

1. In the **Online Window** area of the software, navigate to **Settings > Remote Resources > Shared Inputs**.
2. Click the **Actual Values** field to expand the content.

To view shared input information in the actual values window:

1. In the **Online Window** area of the software, navigate to **Actual Values > Remote Resources > Shared Inputs**.

The following information displays.

Actual Values SI Operand Value

Range: On, Off

This field, when the EnerVista software is online, indicates the status of the SI operand. This is not a setting.

A value of "On" signifies the SI operand is On and is displayed as an illuminated red LED indicator. A value of "Off" signifies the SI operand is Off and is displayed as an extinguished LED indicator.

When the EnerVista software is offline, actual values do not appear.

Actual Values SI Received Value

Range: On, Off

This field, when the EnerVista software is online, indicates the status of the received shared I/O channel. The received channel status can vary from the SI operand status when the channel's received test bit is On.

Actual Values Channel Test

Range: On, Off

This field, when the EnerVista software is online, indicates the status of the received test bit for the shared I/O channel.

Shared output settings


A shared output (SO) is an object that maps a user selected FlexLogic operand to one or two shared I/O channels.

Sixteen SOs are provided for each process card specified by the relay's order code. They are designated by the process card slot code, the SO code "/SO," and an SO sequence number, 1 through 16. Process cards can be in slots F and J. Thus the SOs are designated "F/SO1" through "J/SO16."

To configure shared output settings:

1. In the **Online Window** area of the software, navigate to **Settings > Remote Resources > Shared Outputs**.

Figure 9: Configuring shared output settings.



Each SO is provided with settings to assign a logical name, an operate operand, destination field units, and channel numbers, and whether changes of state are recorded by the event recorder. These settings are described as follows.

ID

Range: up to 20 characters

Default: blank

The text entered here displays in settings and actual values. Typically, the text describes the information being communicated (for example, "Bkr 1 BF Init Tx").

Operate operand

Range: any FlexLogic™ operand

Default: OFF

This setting selects an operand to control the SO command. When the selected operand is "On" and there is no major self-test, the SO command is On. If the associated field unit communications status is OK, the Brick shared I/O channel is driven on. If the relay test mode is either isolated or forcible, the test bit sent to the Brick is turned on, which prevents the associated shared input operands from responding to this operate operand unless the receiving relay's test mode is also either isolated or forcible.

Destination 1 Field Unit, Destination 2 Field Unit

Range: None, any field unit on the same process card as the shared output (for example, for process card F shared outputs, range is F1 ...8)

Default: None

These settings map the SO to two field units.

Destination 1 Channel #, Destination 2 Channel #

Range: 1 to 15 in steps of 1

Default: 1

These settings each map the SO to a particular shared I/O channel on the destination field unit.

Shared output actual values

There are two ways to view actual values: in the settings window or the actual values window.

To view shared output information in the settings window:

1. In the **Online Window** area of the software, navigate to **Settings > Remote Resources > Shared Outputs**.
2. Click the **Actual Values** field to expand the content.

To view shared output information in the actual values window:

1. In the **Online Window** area of the software, navigate to **Actual Values > Remote Resources > Shared Outputs**.

The following information displays.

Actual Values Output Command

Range: On, Off

This field, when the EnerVista software is online, indicates the status of the outgoing SO command. This is not a setting.

A value of "On" signifies the SO command is On and is displayed as an illuminated red LED indicator. A value of "Off" signifies the SO command is Off and is displayed as an extinguished LED indicator.

When the EnerVista software is offline, this field does not appear.

FlexLogic operands

FLEXLOGIC OPERANDS - SHARED INPUTS, SHARED OUTPUTS

Shared In F/S11 On: This operand is asserted when the received shared I/O channel is On, and either the channel test bit is Off or the relay is in the test isolated or test forcible mode.

Shared In F/S11 Off: This operand is the complement of the On operand.

F/S12 to J/S116: The operand listed above is also available for all other shared inputs.

Multilin B95^{Plus} Bus Protection System

Chapter 8: Protection

This section describes how to configure the B95^{Plus} protection features.

Bus protection overview

The Multilin B95^{Plus} Bus Protection System is designed to accommodate large, dynamically reconfigurable buses. To render setting the relay simple, the relay includes several features:

- **Bus source** — Each models a bay with a CT bank, breaker, bus isolators, and bypass isolator. Each combines the phase current related features of UR/UR^{Plus} AC source, of a breaker failure, IOC, TOC, and end-fault elements
- **Bus zone** — Each combines an independent bus differential protection comparator for each phase of a bus segment and a trip bus that allows the bus zone and other protection configured by the user to trip all bus sources connected to the bus segment
- **Dynamic bus replica function** — Coordinates the signal flow between bus sources and bus zones, between user selected protection and trip buses, and between trip busses and bus source trips
- **Voltage source** — Each models a bus VT bank. Each combines the phase voltage related features of a UR/UR^{Plus} AC source and of an undervoltage element for supervising the differential protections


Each is explained as follows.

Bus source concept

Each B95^{Plus} bus source component models a power system bus source. A power system bus source is either a primary connection to the bus from a network element, or a primary connection to a bus segment from another bus segment via a bus coupler (bus tie breaker, section breaker, transfer bus breaker). A network element is a feeder, incomer, transformer, capacitor, reactor, generator, and so on. Bus source primary equipment can include current transformers measuring the current flow to/from the network element or the other bus segment, a breaker that when tripped interrupts that current, isolators that dynamically connect the current to various bus zones, and a bypass isolator..

The figure depicts the model of a single B95^{Plus} bus source for a network element and the associated portion of the bus zones. The bus source model for a bus coupler is the same except that instead of the network element there is a connection to another bus source that is used to model the connection to the coupled bus zone.

Figure 1: Bus source model - part of the power system bus




870799A1.cdr

Bus zone concept

The bus sources are connected together as shown in the following figure to form the bus zones. The actual power system bus is mapped to this model, which can directly accommodate the bus arrangements in common use. See the Bus Replica Application Guide chapter.

Figure 2: Complete bus replica - a mode of a power system bus



Bus replica concept

The main function of the dynamic bus replica is to determine moment-by-moment which bus sources are connected to which bus zones.

The bus replica implements a trip bus for each zone. Activating the trip bus of a zone initiates tripping of all bus source breakers presently connected to that zone, as shown in the bus source logic diagram in the Zone Trip Bus Settings section. Typically the bus zone's differential directly initiates its associated trip bus (Zone Z1 in the bus differential logic diagram in the Supervision Settings section). The bus replica also has logic operand inputs for each bus source that initiate the trip bus of each bus zone presently connected to that bus source. Typically, the bus source's breaker failure and any other protection that needs to clear the bus side of a bus source are configured to these inputs.

Descriptions and settings for the bus replica setting related to individual bus sources are outlined in the Bus Sources section later in this document. Similar information for individual bus zones are outlined in the Bus Differential section later in this document.

Direct connections

According to the bus replica, a bus source is connected to a bus zone when the isolator model corresponding to that connection is closed. This is called here a direct connection. When a bus source is connected to a bus zone, the bus source's currents are normally included in the bus zone's differential calculations, and the zone trip bus trips the bus source's breaker.

Bus parallels

In addition to these direct connections, the bus replica determines whether a bus source is indirectly connected to a bus zone via bus parallels. A bus parallel is the condition where two isolators of a given bus source are both closed, allowing a current to flow out of one bus segment into the bus source via one closed isolator, and out through a second closed isolator onto the second bus segment. This current cannot be measured.

It is common for two isolators of a bus source to both be closed at the same time during network element transfers between bus segments. For example, if a bus source X's isolator connects it to bus zone 1, and some other bus source Y has isolators connecting Y to both bus zone 1 and to bus zone 2, then bus source X is also connected to both bus zone 1 and bus zone 2. The connection of bus source X to bus zone 2 is via the bus parallel in bus source Y. The B95^{Plus} bus replica also detects indirect connections formed by a chain of bus parallels. For example, if bus source X parallels zone 1 to zone 3 and bus source Y parallels zone 1 to zone 2, then the bus replica recognizes that zone 2 is paralleled with zone 3.

When two or more busses are paralleled, they together form an electrically continuous composite bus. In order that the differential functions operate properly for this condition, the currents of all of the bus sources connected to the composite bus are redistributed to the first of the paralleled bus zones that make up the composite bus. The first paralleled bus zone's differential thus has all the composite bus currents so that it properly protects the composite bus; the other paralleled bus zone's differentials thus have no currents so they do not operate incorrectly or otherwise. The bus replica also arranges that each paralleled zone's trip bus trips the entire composite bus.

Zone expansion / reduction

The bus replica also implements a zone expansion/reduction feature whereby the bus zone measurement boundary is moved to provide proper bus differential coverage of so-called dead-zones. A dead-zone consists of the primary conductors between the bus source's CT and the open main contacts of its breaker. The zone expansion/reduction feature moves the zone boundary from the CT's location to the open breaker contacts by removing the CT's input to the zone when the breaker's model indicates that the breaker is standing open. See the End Fault Protection Content settings section for more on this zone expansion/reduction feature.

Bypass isolators

The bus replica also provides for bypass isolators. Bypass isolators are often used to allow a network element to remain in-service while the breaker and CT are taken out-of-service for maintenance or repair. Isolators or drops not modelled nor shown in the bus source model figure are opened to isolate the breaker and the CT after the bypass is closed.

As the bypass isolator bypasses the CT, while the bypass is closed the current entering or leaving any connected bus zone is not measured, so correct differential protection of that zone is not possible. Load currents and external fault currents in bypassed bus sources may appear as spurious differential current that may be above the trip threshold. The bus replica therefore blocks the zone differential operate of each non-check-zone bus zone when any bus source directly or indirectly connected to that zone is bypassed.

Check zones

Check zones are differential functions intended to supervise the segment protections of dynamic buses and thereby prevent undesired operation due to incorrect isolator or breaker status input to the relay. Check zones measure all currents incident to the bus without regard to isolator or breaker status, and so do not operate for status input error that can cause present dynamic arrangement of the bus to be misrepresented, and thus spurious differential currents to be calculated. Each B95^{Plus} bus zone can be configured to be a check zone.

Bus zones that are configured as check zones are handled quite differently from others. This is because check zones do not model actual primary connections, but are just improvisations to form a differential zone encompassing the entire bus, and can include multiple bus segments that are not actually galvanically connected. For check zones, the zone isolators are "virtual" isolators, because they do not represent connections to a bus segment, rather are indications of which bus source currents are to be measured by the check zone.

As such, check zones do not participate in bus paralleling. Bus source currents are never redistributed to or away from other zones; the check zone always measures just those bus sources where the "virtual" isolator is closed.

Check zones do not participate in zone expansion/reduction; bus source breaker status has no impact on a check zone. The differential functions of check zones do not initiate their trip buses. As the virtual isolators do not represent actual connections, the trip bus of a check zone cannot initiate tripping of any bus source.

Because check zones do not expand, check zone supervised bus zones are defeated for dead zone faults where the CT is located on the bus side of the breaker. The end fault protection is required to handle this situation.

Check zones are outlined in more detail later in the Bus Replica Application Guide chapter.

Bus sources

Each B95^{Plus} bus source component models a power system bus source. A power system bus source is either a primary connection to the bus from a network element or a primary connection to a bus segment from another bus segment via a bus coupler (bus tie breaker, section breaker, transfer bus breaker). A network element is a feeder, incomer, transformer, capacitor, reactor, generator, and so on. Bus source primary equipment can include current transformers measuring the current flow to/from the network element or the other bus segment, a breaker that when tripped interrupts that current, isolators that dynamically connect the current to various bus zones, and a bypass isolator.

Each bus source element includes in addition to the interface to the bus replica:

- A breaker failure function for the breaker associated with this bus source

- A three-phase instantaneous overcurrent function using the bus source phase currents
- A three-phase inverse time overcurrent function using the bus source phase currents
- End fault protection (also known as blind spot protection) using the breaker status and bus source phase currents

Twelve bus sources are provided for each process card specified by the relay's order code. They are designated by the process card slot number, the bus source code "/Src," and a bus source sequence number, 1 through 12. Process cards can be in slots F and J. Thus the first bus source designation on the first process card is "F/Src1," while the last bus source on the last process card is designated "J/Src12."

Each bus source is provided with settings to assign a logical name, and to select CT input origins, CT rating, and polarity, various device position inputs, settings for operating thresholds and delays, settings to enable, block, supervise and force bus source operation, and a setting to enable changes of state to be recorded by the events recorder. These settings are described in the following sections. More information on use of these settings can be found in the Bus Replica Application Guide chapter.

The bus sources implement the setting group feature: Each is provided with two alternate sets of threshold-related settings, in setting groups numbered 1 and 2. Grouped settings are contained in the software under **Settings > Protection > Group n > Bus Sources**, where n is the group number. Settings not threshold-related are not grouped, and are contained under **Settings > Protection > General > Bus Sources**. The performance of a bus source is defined by the setting group that is active at a given time. Multiple setting groups allow the user to conveniently change protection settings for different operating situations (for example, altered power system configuration or season of the year). The active setting group can be preset or dynamically selected via the **Settings > Protection > Setting Group Control** window.

General settings

To configure bus source settings:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > General > Bus Sources**
2. Click the **General Settings** button to expand the content.

Figure 3: Bus sources settings

PARAMETER	F/SRC 1	F/SRC 2	F/SRC 3
ID			
General Settings			
Function	Disabled	Disabled	Disabled
Block	OFF	OFF	OFF
Events	Enabled	Enabled	Enabled
HMI Template	1	1	1
CT Settings			
Bus Configuration Settings			
Bus Trip Settings			
ACTUAL VALUES			

The following settings are available.

ID

Range: up to 20 characters

Default: blank

The text entered here displays in settings and actual values displays. Typically, the text is a description of the network element or breaker current, for example "Markham Fdr 23" or "Bus Coupler to B Bus."

Function

Range: Enabled, Disabled

Default: Disabled

When disabled, all bus source operands are forced to Off/zero, trip bus initiation is disabled, all memory is cleared, and timers are held reset. The bus source's "Z1...6 Connection" and "Bypass Connection" inputs to the bus replica are also forced to Off.

Otherwise the bus replica operates as usual, including its F, J/Src1...12 CT in Z1...6 operands and its Zones Paralleled operand.

When re-enabled, operand updating and events are suppressed for up to two power system cycles while the bus source measuring algorithms stabilize.



Bus source Src11 on each process card shares internal resources with the undervoltage element UV1. Thus the EnerVista software does not allow saving Src11 enabled while VS1 is enabled and vice-versa. Similarly, Src12 and VS2 share resources and both cannot be enabled.



Changing the value of this setting in the relay reconfigures the transient recorder and clears all transient records.

Block

Range: any FlexLogic operand

Default: Off

This setting selects an operand to control the bus source block feature. When the selected operand is "On," the breaker failure, IOC, TOC, and end fault comparators are forced to Off. Other bus source functions such as current measurement for the differential function operate normally.

Events

Range: Enabled, Disabled

Default: Enabled

When enabled, any activation of any of the bus source FlexLogic operands generates an event in the event record.

HMI Template

Range: 1, 2, 3

Default: 1

The setting selects the template the front panel is to use to display the mimic diagram of this bus source. See the Bus Source Template Editor section for more information.

CT settings

Each bus source almost invariably requires a three-phase set of measurements of the current through that bus source. These currents can be from a single Brick or dual redundant Bricks. Redundant Bricks provide extra high reliability of measurement of currents; if one origin's Brick is lost or a Brick internal self-test fails, the relay instantaneously transfers to the other.

If measurements from two Bricks are received and neither indicates any Brick internal self-test fail, yet the two measurements disagree, a discrepancy operand is activated. This operand can be used to block or otherwise appropriately modify relay behavior. In addition, if the disagreement persists, the Crosschecking Error self-test is raised.

Note that the crosschecking feature does not by default block any protection or other relay function. However, individual or all protection and control functions can be blocked on detection of crosschecking error by setting the appropriate protection block settings and/or the Configurable Major Self-Test setting to the logical OR of the appropriate discrepancy operands.

Current transformer (CT) settings determine which Brick(s) and AC current inputs on the Brick(s) are used, the primary and secondary rating of the primary CTs, and their polarity (direction).

To configure bus source current transformation settings:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > General > Bus Sources**.
2. Click the **CT Settings** button to expand the content.

Figure 4: Configuring current transformer settings

PARAMETER	F/SRC 1	F/SRC 2	F/SRC 3
General Settings			
ID			
CT Settings			
Origin 1	None	None	None
Origin 2	None	None	None
Primary	1 A	1 A	1 A
Secondary	1 A	1 A	1 A
Polarity	In	In	In
Bus Configuration Settings			
Bus Trip Settings			
Breaker Failure Inputs			
ACTUAL VALUES			

Origin 1 , Origin 2

Range: None, any current bank of any field unit on the same card as the bus source (for example for card F, range is F1/AC1..3, F1/AC5..7, F2/AC1..3, F2/AC5..7, ..., F8/AC5..7)

Default: None

These settings specify the field unit and the AC inputs of the corresponding Brick that are the origins of the phase current inputs for the bus source.




NOTE

The EnerVista B95^{Plus} Setup software does not allow the saving of an origin setting where the field unit order code setting indicates that the proposed origin's AC inputs are not current type.

The B95^{Plus} provides extra high reliability of current measurement by allowing dual origins. The auto-transfer logic shown in the figure is described as follows. An origin is considered available when the origin is set other than to "None," the selected field unit is enabled, communications with its Brick are up, and the Brick reports no self-test alarms potentially affecting the AC inputs. If origin 1 is available, the relay uses the values from origin 1. Otherwise, if origin 2 is available, the relay uses the values from origin 2. If neither origin is available, then the current values are forced to zero to prevent any ambiguity of measurement, and the bus source fail operand is activated. Zero is most often the preferred failsafe value. Bus source end fault protection, instantaneous overcurrent, timed overcurrent and breaker failure current do not operate with zero input.

When connecting to only one Brick, the Brick can be mapped to either origin.

Figure 5: AC input auto-transfer logic



The auto-transfer is not controlled by failures or switching in the AC current signals upstream from the Bricks. For instance, a transfer to origin 2 is not initiated by the shorting/opening of origin 1 test switches. Detection of such events is problematic, so instead the crosschecking feature described later in the actual values section is provided.

Primary

Range: 1 to 65000 in steps of 1
 Default: 1 A

This setting is used for ratio matching when multiple current inputs are combined or compared, and is used to determine the base for primary per-unit current values. Configure the setting to be the connected primary rating of the CTs associated with this bus source. Where dual origins are employed, both must have the same primary rating.

Secondary

Range: 1 A, 5 A
 Default: 1 A

This setting is used to determine the CT ratio for ratio matching when multiple current inputs are combined or compared, and is the base for secondary per-unit current values.



The EnerVista B95^{Plus} Setup software does not allow the saving of a CT secondary setting where the field unit order code setting indicates that the nominal rating of the originating Brick AC inputs is other than the proposed setting.

Configure the setting to be the secondary current rating of the CTs associated with this bus source. Where dual origins are employed, both must have the same secondary rating.

Polarity

Range: In, Out

Default: In

This setting determines whether the relay inverts the current input signal, producing the same effect as reversing the CT secondary connections. This feature allows the option of using the same set of primary CT cores for the protection measuring zones on both sides of the CT.

Where the connection of the CTs is such that current flowing into the bus from this bus source produces a current into the marked terminal of the Brick, configure this setting to “In.” Where the connection is such that current flowing out of the bus produces a current into the marked terminal of the Brick, configure this setting to “Out.”

Bus configuration settings

The bus configuration settings dynamically fit the bus replica’s model of the power system bus to the actual power system bus. They communicate to the bus replica which bus sources each bus zone is at present directly connected to. The replica uses this information in instructing the bus zone differential elements which currents to use, and in determining which bus source breaker trip to initiate when a zone protection operates. See the Bus Replica Application Guide chapter.

To change bus configuration settings:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > General > Bus Sources**
2. Click the **Bus Configuration Settings** button to expand the content.

Figure 6: Configuring bus configuration settings

PARAMETER	F/SRC 1	F/SRC 2	F/SRC 3
ID			
General Settings			
CT Settings			
Bus Configuration Settings			
(Z1) Connection	OFF	OFF	OFF
(Z2) Connection	OFF	OFF	OFF
(Z3) Connection	OFF	OFF	OFF
(Z4) Connection	OFF	OFF	OFF
(Z5) Connection	OFF	OFF	OFF
(Z6) Connection	OFF	OFF	OFF
Bypass Connection	OFF	OFF	OFF
Breaker Open 1	OFF	OFF	OFF
Breaker Open 2	OFF	OFF	OFF
Breaker Open Delay	0.400 s	0.400 s	0.400 s
Manual Close 1	OFF	OFF	OFF
Manual Close 2	OFF	OFF	OFF
Bus Trip Settings			
ACTUAL VALUES			



NOTE

An error in connection input can result in a bus zone unnecessarily tripping for a fault not in its zone, for example when the failsafe setting on a Brick is Off and the Brick goes offline. It is also possible for a bus zone to fail to trip on an internal fault due to erroneous connection inputs. Correct connection status is vital.

The following settings are available.

Z1...6 Connection*Range: any FlexLogic operand**Default: OFF*

For zones that are not configured as check zones, when the set operand is On, the replica behaves as if there is a direct primary electrical connection between the corresponding bus source and the corresponding bus zone. When the operand is Off, the replica behaves as if there is no such direct connection. For zones that are configured as check zones, when the set operand is On, the bus source current is included in the zone's differential function's calculations.

For the majority of possible connections provided by the bus replica, there is no corresponding connection in the actual power system bus. The setting for these is set to the OFF operand, so the replica behaves in the same way as if these are absent from the model. In most of the remaining connections provided by the bus replica, there is a physical isolator that when closed makes an actual direct electrical connection between the corresponding bus source and bus zone. Where the physical isolator has position status inputs to the relay, these can be consolidated and validated by an isolator function, and the isolator function's status operand used as the connection setting. Where there is a physical isolator without position status inputs, the output operand of a FlexLogic non-volatile latch can be used, and the latch manually commanded to represent the physical isolator's position. For the few remaining bus replica connections, where the actual bus arrangement has a solid connection between the source and zone, the corresponding setting is set to the ON operand.

NOTICE

If the state of an operand selected for a bus source to zone connection setting is incorrect, due for instance to brick communications failure or failure of isolator auxiliary contacts, the differential protection incorrectly includes or excludes the current of this connection. The differential comparator then sees a spurious difference current, and when sufficiently large, operates. It is strongly recommended that the relay be configured to prevent such an operation tripping the bus. This can include use of undervoltage supervision, use of check zone supervision, use of brick and isolator auxiliary contact redundancy, and/or use of connection status failure, for example Field Unit Off operand) to block the differential. See the isolators Settings section to implement redundancy.

Connection settings of a bus zone used as check-zone require special setting treatment, as a check zone does not correspond to physical connections. A bus zone setting is used to declare a bus zone to be a check zone. See the Check Zones section later for more information. For a check-zone, all connection settings to the zone from network element bus sources are set to ON so that all currents into the overall bus are measured. Check zone connection settings to bus sources that are used for bus couplers, bus ties, section breakers and so on are typically set to OFF, as are the settings for any bus sources that are not used or are not used for bus protection.



The EnerVista software prefixes these setting's names with the present value of the corresponding zone's ID.

Bypass Connection*Range: any FlexLogic operand**Default: OFF*

When the selected operand is On, the zone differential operation of connected non-check-zone bus zones is blocked.

When the actual bypass isolator is closed and bypasses the primary CT, the CT does not produce an accurate measurement of the bus source current. This can cause undesired operation of any bus differential element using that current.

Configure this setting to OFF if there is no actual physical bypass isolator, or to an operand reflecting the position status of the bypass isolator where a bypass isolator exists.

Breaker Open 1, Breaker Open 2

Default: OFF

Range: any FlexLogic operand

Either of the selected operands being On results in the bus source CTs being dropped from any non-check-zones after breaker open delay timeout. This is the zone expansion/reduction feature that moves the differential zone measuring boundary to the breaker open point, thus properly handling the dead-zone between breaker and CT.

Leaving these settings at OFF disables the zone expansion/reduction. Zone expansion/reduction is described further in the end fault protection settings section.

To use zone expansion/reduction, select operands that represent the protected breaker's normally-closed auxiliary switch contact (52b), that is, operands that are On when the breaker is open. Also, complete the manual close and breaker open delay settings.

Two breaker open settings are provided to accommodate redundant/dual Bricks. See the description for the breaker failure breaker early position settings for guidance.

Breaker Open Delay

Default: 0.400 s

Range: 0.100 to 60.000 s in steps of 0.001 s

This setting is the time following breaker opening at which end fault protection is armed and zone extension/reduction occurs.

Configure this setting to be at least as long as is required to avoid spurious operation due to any delays between the breaker position inputs changing to open and main contacts opening.

Manual Close 1, Manual Close 2

Default: OFF


Range: any FlexLogic operand

Either of the selected operands being On disables zone expansion/reduction, overriding breaker open status.

To avoid undesired zone extension/reduction on breaker closing, where the main breaker contacts may touch before the auxiliary contacts open and are recognized by the relay, select operands representing the manual breaker close command.

Two settings are provided to accommodate redundant/dual Bricks. See the description for the breaker early position settings for guidance

Figure 7: Zone trip bus logic diagram



Zone trip bus settings

The B95^{Plus} implements features called zone trip buses to inter-communicate between bus sources and bus zones. There is one zone trip bus for each bus zone. When a zone trip bus is initiated by its bus zone protection or by one of the operands selected by a bus source connected zone trip setting, all of the bus sources electrically connected to that zone according to the bus replica's model of the power system bus make their breaker trip initiate operands On. Configure the breaker trip field contact outputs and the appropriate breaker failure initiates with the appropriate bus source breaker trip initiate operands.

To configure zone trip buses:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > General > Bus Sources**.
2. Click the **Bus Trip Settings** button to expand the content.

Figure 8: Configuring zone trip buses

PARAMETER	F/SRC 1	F/SRC 2	F/SRC 3
ID			
General Settings			
CT Settings			
Bus Configuration Settings			
Bus Trip Settings			
Connected Zone Trip 1	OFF	OFF	OFF
Connected Zone Trip 2	OFF	OFF	OFF
Connected Zone Trip 3	OFF	OFF	OFF
Aux Breaker Trip 1	OFF	OFF	OFF
Aux Breaker Trip 2	OFF	OFF	OFF
Aux Breaker Trip 3	OFF	OFF	OFF
Blkr Trip Dropout Delay	0.500 s	0.500 s	0.500 s
ACTUAL VALUES			

The following settings are available.

Connected Zone Trip 1...3

Default: OFF

Range: any FlexLogic operand

The operands selected by these settings trip all bus sources to which this bus source is at present connected according to the bus replica. As check zones do not have physical connections, the connected zone trip feature cannot result in tripping a check-zone.

Protections that typically are required to trip all connected zones include breaker failure, end fault protection where the CTs are located on the bus side of the breaker, and protections external to the B95^{Plus} such as flashover (frame leakage) protection, and gas density relays of breakers and their adjacent SF6 compartments.

Aux. Breaker Trip 1...3

Default: OFF

Range: any FlexLogic operand

The operands selected by these settings trip just the breaker of this bus source.

Do not allow the breaker failure re-trip to use this feature when breaker failure is initiated by the bus source breaker trip operand, as the combination creates a feedback loop that seals-in the trip initiate signal, while accomplishing no extra reliability.


Bkr Trip Initiate Dropout Delay

Default: 0.500 s

Range: 0.000 to 60.000 s in steps of 0.001 s

This sets the period of time for which the breaker trip initiate operand is sealed-in. This timer is intended to stretch the trip duration so that even with a transient initiation the trip output is maintained throughout the breaker trip sequence. It can also be used to cancel automatic reclosing that potentially have been initiated by the neighboring zone's protection.

Figure 9: Bus source logic diagram for F/Src1



870783A1.vsd


End fault protection settings

The end fault protection is intended for dead-zone faults; that is, faults between the CT and an open circuit breaker. Such faults occur with low but significant frequency, often resulting from procedural errors made during circuit breaker maintenance preparation

and restoration. Since a bus measuring zone terminates on the CTs while its tripping zone terminates at the breaker's open contacts, faults between the CT and breaker require special consideration.

With a bus-side CT (part a in the figure), a fault between the open circuit breaker and the CT is normally outside the bus measuring zone, but can only be cleared by tripping the bus zone. The fault is inside the network element zone, which initiates breaker failure, which in turn trips the bus clearing the fault in breaker failure time. Fault current is the same as for a bus fault, typically quite large, so timed clearance is undesirable. When the circuit breaker is standing open, arming end fault protection, the end fault protection operates immediately on current detection. Use the end fault protection operate operand to trip the bus, to clear the fault in instantaneous time. In addition, while the delayed breaker open signal is On, the bus replica removes the bus source currents from the bus differential, effectively extending the bus zone to the open breaker and thus encompassing the dead-zone. As a result the bus differential also operates in instantaneous time.

Figure 10: Application of end fault protection



With a line-side CT (part b in the figure), a fault between the open circuit breaker and the CT is normally inside the bus measuring zone, but can only be cleared by tripping the network element. Clearing the bus is unnecessary and undesirable. While the delayed breaker open signal is On, the bus replica removes the bus source currents from the bus differential, effectively reducing the bus zone to the open breaker, and preventing the aforesaid undesirable bus tripping. In addition, when the circuit breaker is standing open arming end fault protection, the end fault protection operates immediately on current detection. Use the end fault protection operate operand to trip the network element, to clear the fault in instantaneous time.

To avoid undesired end fault protection operation and extension/reduction activation from race conditions on breaker opening/tripping, a time delay for the breaker open signal is provided in the bus replica. To avoid undesired operation on breaker closing, the end fault protection is disarmed and zone extension/reduction removed by the manual breaker close command.

To configure group n end fault protection:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > Group n > Bus Source Threshold**.
2. Click the **End Fault Settings** button to expand the content.

Figure 11: Configuring end fault protection

PARAMETER (GROUP 1)	F/SRC 1	F/SRC 2	F/SRC 3	
ID				
End Fault Settings				
Current Pickup	0.10 pu (1 A base)	0.10 pu (1 A base)	0.10 pu (1 A base)	0.11
Trip Dropout Time	45.000 s	45.000 s	45.000 s	
IOC/TOC Settings				

The following settings are available.

Current Pickup

Default: 0.10 pu

Range: 0.01 through 30.00 pu in steps of 0.01 pu

This setting is the current level above which end fault protection operates if the breaker is standing open.

This setting is set below the lowest expected fault current through the CT to the dead-zone, but high enough to assure dropout when the breaker opens.

The base current used by this per unit setting is the bus source CT primary setting.

Trip Dropout Time

Default: 45.000 s

Range: 0.000 to 60.000 s in steps of 0.001 s


This sets the period of time for which the end fault trip output is sealed-in.

This timer is intended to make the trip duration long enough that it can be communicated to the network element protection and cancel automatic reclosing.



The currents used by the end fault function are subject to the cutoff setting. See **Settings > General > Power System > Current Cutoff Level** for details.

Figure 12: End fault protection logic diagram



Breaker failure settings

Each bus source includes a breaker failure function, intended for use with the bus source breaker. The function’s current inputs are the bus source currents, and the function is disabled by the bus source function and block settings. Otherwise, breaker inputs and outputs are assigned by settings.

In general, a breaker failure scheme determines that a breaker signalled to trip has not cleared the fault within a definite time, so further tripping action must be performed. This tripping needs to trip all breakers, both local and remote, that can supply current to either side of the breaker. The bus side of the breaker can conveniently be configured to be tripped by selecting the breaker failure operate operand as one of the bus replica connected zone trip settings.

The operation of a breaker failure element includes the following three stages: initiation; determination of a breaker failure condition; and output.

Stage 1: Initiation

FlexLogic operands must be selected to initiate the scheme. Generally, this is the bus source’s breaker trip initiate operand and an operand representing the network element protection operation.

The initiating signal can be sealed-in by the breaker failure function for cases where the initiating signal can reset before the breaker failure timers have finished timing, yet it is still good to clear the zones if the breaker fails. The seal-in is supervised by current level, so seal-in is reset when the fault clears.


Breaker failure can be initiated either directly or with current supervision. Current-supervised initiation results in breaker failure not being initiated and timers not starting until current flows through the breaker. Current supervision can be used to handle applications where a trip can occur immediately after a breaker close is initiated, and the breaker design is such that it must complete the close cycle before beginning the tripping sequence, lengthening the total clearing time compared to a normal trip. For instance, tripping can occur immediately after close when the breaker auto-recloses shortly after a line-test breaker closes, and there is delayed fault re-ignition. Ensure that with current-supervised initiation, the current supervisory pickup level is lower than any fault for which breaker failure operation is required. Current-supervised initiation is not suitable for cases where there is little or no fault current, such as a transformer that while sitting on potential suffers insulation deterioration detected by sudden gas pressure.

When breaker failure is initiated, a breaker failure re-trip operand is immediately activated. The re-trip operand can be used to send a trip signal to the breaker to be sure that the breaker trip has indeed been issued. Re-trip is intended for applications where improper use of test facilities can result in inadvertent breaker failure initiation without simultaneous breaker trip initiation. It prevents such initiation causing declaration of a failed breaker and the resulting wider tripping.

Stage 2: Determination of a breaker failure condition

Three paths lead to a determination of a breaker failure condition. They are associated with breaker failure timers 1, 2, and 3.

Figure 13: Breaker failure timing during a typical breaker trip sequence



Timer 1 logic (the early path) is supervised by an early-opening breaker auxiliary contact, and by current detection. The early-opening contact opens as soon as the breaker mechanism starts to move, typically before the power contacts have parted. If the breaker mechanism has not moved as indicated by the early-opening contact and fault current is still detected after the timer 1 delay interval, breaker failure operates. Non-opening of the early-opening breaker auxiliary switch by timer 1 timeout time indicates that the breaker mechanism has failed, so current interruption cannot occur.

Timer 2 logic (the main path) is supervised only by current. If fault current is still detected after the timer 2 delay interval, breaker failure operates. This path is intended to detect a breaker that operated mechanically passing timer 1 logic, but fails to interrupt the fault current.

The timer 2 logic provides two levels of current supervision for use with breakers that initially insert an opening resistor into the fault circuit, then some time later open the main contacts. Breaker failure operates if the resistor has not reduced the fault current to below the high-set current setting when timer 2 times out, an indication of resistor insertion failure. Breaker failure also operates if at some additional time after timer 2 times out contact opening has not reduced the current to zero, or at least to below the low-set setting, indicating main contact failure. Timer 1 path does not use the low-set detector as it either is blocked by the early-opening breaker auxiliary contact or operates before resistor insertion occurs.

Timer 3 logic (the slow path) is supervised by a normal-opening breaker auxiliary contact. There is no current supervision because this path is intended to detect low magnitude faults. Because low magnitude faults have smaller impact on the power system, this timer is typically set for a long delay, although where there are no contact multiplying relays it can safely be set faster than timer 2. As this path does not have current supervision, it can undesirably operate when the breaker's service disconnects are open and the breaker is out-of-service for maintenance. Thus, this path can be supervised by a control switch that is intended to be opened while the breaker is in test and isolated for maintenance.

Stage 3: Output

The outputs from the schemes are as follows:

- The FlexLogic operand used to re-trip the protected breaker. This operand is useful in applications where a breaker failure initiate originates outside of the B95^{Plus}, such as from network element protection.
- The FlexLogic operate operand used to initiate the tripping required to clear the faulted zone. Selecting this operate operand for one of the bus source's connected zone trip settings is sufficient to clear the bus. Also use this operand to trip the zone on the other side of the breaker, typically a network element. The breaker failure trip output can be sealed-in for an adjustable period, to cancel reclosing for example or to ensure communications signals reach remote destinations.

The breaker failure settings are configured in the Bus Sources and Bus Source Thresholds panels. Both procedures follow.

To configure breaker failure settings:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > General > Bus Sources**.

Figure 14: Configuring breaker failure settings

PARAMETER	F/SRC 1	F/SRC 2	F/SRC 3
ID			
General Settings			
CT Settings			
Bus Configuration Settings			
Bus Trip Settings			
Breaker Failure Inputs			
Initiate 1	OFF	OFF	OFF
Initiate 2	OFF	OFF	OFF
Initiate 3	OFF	OFF	OFF
Seal-In Initiates	No	No	No
Current-Supervise Initiates	No	No	No
Breaker Early Position 1	OFF	OFF	OFF
Breaker Early Position 2	OFF	OFF	OFF
Breaker Position 1	OFF	OFF	OFF
Breaker Position 2	OFF	OFF	OFF
Breaker In Test 1	OFF	OFF	OFF
Breaker In Test 2	OFF	OFF	OFF
ACTUAL VALUES			

The following settings are available.

Initiate 1...3

Range: any FlexLogic operand

Default: OFF

These settings select the operands that initiate breaker failure. When breaker failure is not needed, set these to OFF.

Typically, one initiate setting is set to the bus source's breaker trip operand, and another initiate is set to a communications operand configured to activate when the network element protection operates.

Seal-In Initiates

Range: No, Yes

Default: No

When set to Yes, breaker failure initiate is sealed-in while current flowing through the breaker is above the current-supervisory pickup level.

Current-Supervise Initiates

Range: No, Yes

Default: No

When set to Yes, breaker failure timers only run when current is flowing through the breaker above the current-supervisory pickup level.

Breaker Early Position 1, Breaker Early Position 2

Range: any FlexLogic operand

Default: OFF

Leaving these settings at OFF disables the timer 1 path. To use the timer 1 path, select the FlexLogic operands that represent the protected breaker's early-opening auxiliary switch contact (52aa). This contact can monitor the breaker latch-closed position, or it can be a non-multiplied form-a contact adjusted to have the shortest open time possible without losing reliable closing.

Two breaker early position settings are provided to accommodate dual redundant Bricks. For applications with dual Bricks, set the "Breaker Early Position 1" setting to the breaker early position FCI on one of the Bricks, and the "Breaker Early Position 2" setting

to the FCI on the other Brick. Set the failsafe settings for these FCIs to Off, so if one Brick becomes unavailable, the breaker position reported by the other rules. A failsafe setting of Off also results in the timer 1 path being disabled if both Bricks become unavailable.

For applications with a single Brick, set one of these settings to the breaker early position FCI of that Brick, and leave the other set to OFF. Again, set the FCI failsafe setting to Off so the timer 1 path is disabled if the Brick becomes unavailable.

Breaker Position 1, Breaker Position 2

*Range: any FlexLogic operand
Default: OFF*

Leaving these settings at OFF disables the timer 3 path. To use the timer 3 path, select the FlexLogic operands that represent the protected breaker’s normally-open auxiliary switch contact (52a).

Two breaker position settings are provided to accommodate redundant/dual Bricks. See the description for the Breaker Early Position settings earlier for guidance.

Breaker In Test 1, Breaker In Test 2

*Range: any FlexLogic operand
Default: OFF*


When either of the operands selected is On, the timer 3 path is disabled. These are intended for operands that are On when the breaker is isolated and undergoing maintenance. When the breaker is isolated, it is inappropriate for breaker failure protection to operate. Unlike the other paths, timer 3 path is not blocked by undercurrent, so except for this feature timer 3 path is able to operate with the breaker isolated.

Two breaker-in-test settings are provided to accommodate redundant/dual Bricks. See the description for the Breaker Early Position settings earlier for guidance. However, the On failsafe mode in this case does not disable the timer 3 path.

To configure group n breaker failure threshold settings:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > Group n > Bus Source Thresholds**.

Figure 15: Configuring breaker failure thresholds



The following settings are available.

Current-Supervisory Pickup

Range: 0.01 through 30.00 pu in steps of 0.01 pu

Default: 0.10 pu

This setting is used to set the level for initiation current-supervision and for seal-in reset. If the seal-in initiates setting or the current-supervise initiates setting is set to yes, configure this setting to detect with margin the lowest expected fault current through the protected breaker. Set it high enough to ensure dropout when the breaker opens. It can be set lower than inserted breaker resistor current and lower than load current because the high-set and low-set current supervision provide for correct breaker failure operation.

The base current used by this per unit setting is the bus source CT primary setting.

High-Set Current Pickup

Range: 0.01 through 30.00 pu in steps of 0.01 pu

Default: 0.10 pu

This setting is the current level below which breaker current must fall before timer 2 delay timeout to avoid breaker failure operation.

Configure this setting below the lowest expected current through the protected breaker on timer 2 timeout, but high enough to assure dropout when the breaker opens. Where dual current-threshold is used, configure it instead above the current expected at timer 2 timeout with the opening resistor inserted.

Making this setting above load prevents an undesired breaker failure operation via paths 1 and 2 if breaker failure somehow is initiated in error without trip being sent to the breaker by either the initiator or re-trip. However, setting above load does not prevent timer 3 path operation. In the past when electromechanical current sensors were used, the equivalent to this setting was generally set above load to prevent life-shortening relay chatter; however, chatter is not a concern with microprocessor-based relays. Therefore, there is little need to consider load levels when choosing this setting.

The base current used by this per unit setting is the bus source CT primary setting.

Low-Set Current Pickup

Range: 0.01 through 30.00 pu in steps of 0.01 pu

Default: 0.10 pu

This setting is the current level below which breaker current must fall before timer 2 delay timeout then low-set delay timeout to avoid breaker failure operation.

Configure this setting below the lowest expected current through the protected breaker with the breaker opening resistor inserted on low-set time-out, but high enough to assure dropout when the breaker opens. Where the dual current-threshold feature is not used, configure it the same as the high-set pickup setting.

The base current used by this per unit setting is the bus source CT primary setting.

Timer 1 Delay

Range: 0.000 to 60.000 s in steps of 0.001 s

Default: 0.075 s

This setting is the time following breaker failure initiation by which the breaker's early-opening auxiliary switch contact (52aa) must be received open to avoid breaker failure operation.

Configure it to the longest time required for the breaker's early-opening auxiliary switch contact (52aa) to open under worse case circumstances, plus a safety margin.

Timer 2 Delay

Range: 0.000 to 60.000 s in steps of 0.001 s

Default: 0.150 s

This setting is the time following breaker failure initiation by which the high-set current detector must be reset to avoid breaker failure operation.

Typically it is set to the longest time required to interrupt fault current under worse case circumstances, plus the relay's rated current detector dropout time, plus a safety margin. Where the low-set current detector and timer are used, the timer 2 delay is set to the longest time required to reduce the fault current to below the high-set current detector setting, plus the relay's rated current detector dropout time, plus a safety margin.

Note that in bulk oil circuit breakers, the interrupting time for currents less than 25% of the interrupting rating can be significantly longer than the rated interrupting time.

Low-Set Delay

Range: 0.000 to 60.000 s in steps of 0.001 s

Default: 0.000 s

This setting is the time following timer 2 timeout by which the low-set current detector must be reset to avoid breaker failure operation.

Typically it is set so that its sum with the timer 2 delay setting is the longest time required to completely interrupt fault current under worse case circumstances, plus the relay's rated current detector dropout time, plus a safety margin. If dual current-threshold is not required for timer 2 path, leave this setting at zero.

Timer 3 Delay

Range: 0.000 to 60.000 s in steps of 0.001 s

Default: 0.500 s

This setting is the time following breaker failure initiation by which the breaker's normal auxiliary switch contact must be received open to avoid breaker failure operation.

Because this path is intended to operate only for low-level faults, the delay can be set quite long.

BF Trip Dropout Time

Range: 0.000 to 60.000 s in steps of 0.001 s

Default: 45.000 s


This sets the period of time for which the breaker failure trip output is sealed-in.

This timer is intended to make the trip duration long enough that it can be communicated to the network element protection, and can cancel automatic reclosing.

The currents used for breaker failure protection are subject to the cutoff setting. See **Settings > General > Power System > Current Cutoff Level** for details.



Figure 16: Bus source breaker failure logic diagram for bus source F/Src1



870794A1.vsd


Instantaneous overcurrent settings

Each bus source includes a three-phase instantaneous overcurrent with definite time operate and reset delays, which can be used for trip supervision or backup tripping.

To configure group n instantaneous overcurrent settings:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > Group n > Bus Source Threshold**.
2. Click the **IOC / TOC Settings** button to expand the content.

Figure 17: Configuring instantaneous overcurrent settings



The following settings are available.

IOC Pickup

Range: 0.01 through 30.00 pu in steps of 0.01 pu

Default: 1.20 pu

This setting is the current level above which the IOC operates.

The base current used by this per unit setting is the bus source CT primary setting.

IOC Pickup Delay

IOC Reset Delay

Range: 0.000 to 60.000 s in steps of 0.001 s


Default: 0.000 s

These settings specify the IOC operate and reset time delay.



The currents used by the instantaneous overcurrent function are subject to the cutoff setting. See **Settings > General > Power System > Current Cutoff Level** for details.

Figure 18: Bus sources instantaneous overcurrent logic diagram



Inverse time overcurrent settings

The inverse time overcurrent curves used by the time overcurrent elements are the IEEE, IEC, GE Type IAC, and I2t standard curve shapes. This allows for simplified coordination with downstream devices.

The IEEE time overcurrent curve shapes conform to industry standards and the IEEE C37.112-1996 curve classifications for extremely, very, and moderately inverse. The IEC curves conform to IEC 255-4 and British standard BS142 for IEC Curve A, IEC Curve B, IEC Curve C, and IEC Short Inverse.

A time dial multiplier setting allows selection of a multiple of the base curve shape (where the time dial multiplier = 1) with the curve shape setting. Unlike the electromechanical time dial equivalent, operate times are directly proportional to the time multiplier setting value. For example, all times for a multiplier of 10 are 10 times the multiplier 1 or base curve values. Setting the multiplier to zero results in an instantaneous response to all current levels above pickup.

Time overcurrent time calculations are made with an internal accumulation variable. When this variable indicates that the accumulation has reached 100%, a time overcurrent element operates. If less than 100% is accumulated in this variable and the current falls below the dropout threshold of 97 to 98% of the pickup value, the variable must be reduced. Two methods of this resetting operation are available: instantaneous and timed. The instantaneous selection is intended for applications that need to coordinate with other relays that set the accumulation directly to zero when the current falls below the reset threshold. The timed selection can be used where the relay must coordinate with electromechanical relays.

To configure group n inverse time overcurrent settings:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > Group n > Bus Source Threshold**.
2. Click the **IOC / TOC Settings** button to expand the content.

Figure 19: Configuring inverse time overcurrent settings

PARAMETER (GROUP 1)	F/SRC 1	F/SRC 2	F/SRC 3	
ID				
End Fault Settings				
IOC/TOC Settings				
IOC Pickup	1.20 pu (1 A base)	1.20 pu (1 A base)	1.20 pu (1 A base)	1
IOC Pickup Delay	0.000 s	0.000 s	0.000 s	
IOC Reset Delay	0.000 s	0.000 s	0.000 s	
TOC Pickup	1.20 pu (1 A base)	1.20 pu (1 A base)	1.20 pu (1 A base)	1
TOC Curve	IEEE Mod Inv	IEEE Mod Inv	IEEE Mod Inv	
TOC TD Multiplier	1.00	1.00	1.00	
TOC Reset	Instantaneous	Instantaneous	Instantaneous	

The following settings are available.

TOC Pickup

Range: 0.01 to 30.00 pu in steps of 0.01

Default: 1.20 pu

This setting is the current level above which the TOC begins timing and eventually operates.

The base current used by this per unit setting is the bus source CT primary setting.

TOC Curve

Range: IEEE Moderately Inverse, IEEE Very Inverse, IEEE Extremely Inverse, IEC Curve A (BS142), IEC Curve B (BS142), IEC Curve C (BS142), IEC Short Inverse, IAC Extremely Inverse, IAC Very Inverse, IAC Inverse, IAC Short Inverse, I2t, Definite Time
 Default: IEEE Moderately Inverse

This setting selects the inverse time curve shape.

TOC TD Multiplier

Range: 0.00 to 600.00 in steps of 0.01
 Default: 1.00

This setting multiplies the time of the selected base curve.

TOC Reset

Range: Instantaneous, Timed
 Default: Instantaneous

This setting selects whether resetting of the internal energy accumulation variable is instantaneous or models an electromechanical relay.



The currents used by the inverse time overcurrent function are subject to the cutoff setting. See **Settings > General > Power System > Current Cutoff Level** for details.

Figure 20: Bus sources inverse time overcurrent logic diagram



Actual values

When the EnerVista software is online, these fields indicate the status (blocked/disabled/running), origins being used at present, the crosschecking status, the actual values of the currents, bypass isolator status, status of the end fault protection, breaker failure protection, instantaneous protection, inverse time overcurrent protection, and breaker trip initiate. The currents are shown as phasors in numerical polar representation, and can also be shown on a vector graph.

When the EnerVista software is offline, actual values do not appear.]

There are two ways to view actual values: in the settings window or the actual values window.

To view bus source information in the settings window:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > General > Bus Sources**.
2. Click the **Actual Values** field to expand the content.
3. Click a **View** button to display the phasors graphically.

To view bus source information in the actual values window:

1. In the **Online Window** area of the software, navigate to **Actual Values > Protection > Bus Sources**.
2. Click a **View** button to display the phasors graphically.

Figure 21: Viewing bus source information

PARAMETER	F/SRC 1	F/SRC 2	F/SRC 3	Disab
ID				
Function	<input checked="" type="radio"/> Disabled	<input checked="" type="radio"/> Disabled	<input checked="" type="radio"/> Disabled	<input checked="" type="radio"/> Disab
PHASORS	View	View	View	
Phasor Ia	0.000 A 0.0 deg	0.000 A 0.0 deg	0.000 A 0.0 deg	
Phasor Ib	0.000 A 0.0 deg	0.000 A 0.0 deg	0.000 A 0.0 deg	
Phasor Ic	0.000 A 0.0 deg	0.000 A 0.0 deg	0.000 A 0.0 deg	
Origin Selected	<input checked="" type="radio"/> None	<input checked="" type="radio"/> None	<input checked="" type="radio"/> None	<input checked="" type="radio"/> None
Crosschecking Status	<input checked="" type="radio"/> OK	<input checked="" type="radio"/> OK	<input checked="" type="radio"/> OK	<input checked="" type="radio"/> OK
Bypassed	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off
End Fault Protection Op	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off
Breaker Failure Op	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off
IOC Op	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off
TOC Op	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off
Breaker Trip Init	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off	<input checked="" type="radio"/> Off



NOTE

The currents used by the actual values function are subject to the cutoff setting. See **Settings > General > Power System > Current Cutoff Level** for details.

The following information can be viewed.

Function

Range: *Running, Blocked, Disabled*

Indicates whether the bus source is at present Disabled (Function setting is Disabled), or Blocked (Function is Enabled but the block input or fail operand is On), or Running (Function setting is Enabled, the block input and fail operand are Off).

A...C Phase Current

Range: *0.00 to 999999.999 A, -359.9 to 0.0 deg*

Indicates the phase currents' magnitude and angle.

Origin Selected

Range: *Origin 1, Origin 2, None*

Indicates the origin presently being used.

Crosschecking Status

Range: *OK, Discrepant*

Indicates the crosschecking status of redundant origins. When two three-phase sets of currents are being received without diagnostic flags, the two inputs of each phase are compared to each other on a sample-by-sample basis. When all pairs are substantially the same, OK is displayed in green. When any pairs are substantially different, Discrepant is displayed in red.

Bypassed

Range: *On (lit LED), Off (extinguished LED)*

Indicates if the bus source CT is bypassed, so any connected zone is disabled.

End Fault Protection Op

Range: *On (lit LED), Off (extinguished LED)*

Indicates if the bus source's end fault protection is operating.

Breaker Failure Op

Range: On (lit LED), Off (extinguished LED)

Indicates if the bus source’s breaker failure protection operate operand is On.

IOC Op

Range: On (lit LED), Off (extinguished LED)

Indicates if the bus source’s instantaneous overcurrent protection operate operand is On.

TOC Op

Range: On (lit LED), Off (extinguished LED)

Indicates if the bus source’s timed overcurrent protection operate operand is On.

Breaker Trip Init

Range: On (lit LED), Off (extinguished LED)

Indicates if the bus source’s breaker failure protection is initiated.

FlexLogic operands

FLEXLOGIC OPERANDS - BUS SOURCE LOGIC OPERANDS

F, J/Src1...12 Fail:.....	Logic operands that are On when at least one origin is selected to an enabled field unit, but no measurements are being received without brick self-test flags that might affect AC inputs set.
F, J/Src1...12 Discrepancy:.....	Logic operands that are On when current measurements are being received from both origins with no brick self-test flags that might affect AC inputs set, but the two measurements are substantially different.
F, J/Src1...12 Bkr Open:.....	Logic operands that are On when the breaker is standing open. See the bus source logic diagram sheet 1 for details.
F, J/Src1...12 CT in Z1...6:.....	Logic operands that are On when the bus replica has determined that the indicated bus source currents need to be included in the indicated bus zone.
Zones Paralleled:.....	Logic operand that is On when the bus replica has determined that two or more bus zones are paralleled. This can be used to select a setting that has less sensitive bus differential settings.
F, J/Src1...12 Bkr Trp Init:.....	Logic operands that are On when the trip bus of a zone to which the indicated bus zone is connected has become activated, and/or one or more of the auxiliary breaker trip inputs has become activated.
F, J/Src1...12 EF Op:	Logic operands that are On when the end fault protection is operated.
F, J/Src1...12 BF Retrip:	Logic operands that are On when the breaker failure protection is initiated and, if the current supervise initiates setting is yes, current level is above the current supervisory pickup.
F, J/Src1...12 BF Op:.....	Logic operands that are On when the breaker failure protection is operated.
F, J/Src1...12 IOC Op:.....	Logic operands that are On when the instantaneous phase overcurrent protection is operated.
F, J/Src1...12 TOC Op:	Logic operands that are On when the inverse time phase overcurrent protection is operated.

Analog operands

BUS SOURCE - ANALOG OPERANDS

- F, J/Src1...12 Ia...c Mag:.....Analog operands that contain the primary phase fundamental frequency current magnitude. The units are amperes.
- F, J/Src1...12 Ia...c Angle:Analog operands that contain the primary phase fundamental frequency current angle. The units are degrees leading the frequency reference.

The currents used by the analog operands are subject to the cutoff setting. See **Settings > General > Power System > Current Cutoff Level** for details.

Voltage sources

The voltage source function provides a logical connection of a voltage transformer (VT) bank to the relay, and implements supervision undervoltage (fault detection) of the main bus differential protection to prevent undesired operation in the event of current transformer (CT) trouble or incorrect isolator state information.

With the undervoltage operate operand selected as a bus differential supervision setting, normal voltage level prevents differential element tripping in case of erroneous current or status input. An actual bus fault reduces bus voltage, operating the undervoltage function, thereby allowing the differential element to trip if it determines that a bus fault exists. Trouble in a CT or isolator position input can result in normal load current causing operation of the bus differential comparator. Under these non-fault conditions, voltage remains normal and the undervoltage supervision prevents bus tripping. This voltage supervision alone does not guarantee security because a CT or isolator trouble can be followed by an external fault causing a low-voltage condition. CT troubles require prompt attention.

With wye connected VTs, the undervoltage comparators measure both phase-to-ground and phase-to-phase voltages as shown in the logic diagram. With delta connected VTs, the phase-to-ground undervoltage comparators are unused. When using delta connected VTs, take care in choosing an undervoltage setting so that it covers with appropriate margin the phase-to-phase voltage depression expected for the highest impedance bus ground faults respected. Do not use undervoltage supervision with a single VT input, be it phase-to-phase, phase-to-ground, or zero sequence, because these cannot reliably detect all possible bus faults.

An alarm operand is provided that indicates when one but not all comparators have operated for a sustained period, a condition that can result with the primary energized but some VT trouble. Trouble developing in one or more of the VTs or voltage inputs can result in sustained operation of the undervoltage function, defeating the bus differential supervision. Attend to this condition promptly.

Two bus sources are provided for each process card specified by the relay's order code. They are designated by the process card slot number, the voltage source code "/VS," and a voltage source sequence number, 1 or 2. Process cards can be in slots F and J. Thus the first voltage source designation on the first process card is "F/VS1," while the last voltage source on the last process card is designated "J/VS2."

Each voltage source has settings to assign a logical name, to select VT input origins, VT rating and connection, operating thresholds, to enable and block voltage source operation, and to enable changes of state to be recorded by the event recorder. These settings are described in the following sections.


The voltage sources implement the setting group feature. Each is provided with two sets of threshold related settings, in setting groups numbered 1 and 2. Grouped settings are contained in the menu structure under **Settings > Protection > Group n > Bus Sources**, where n is the group number. Settings not threshold-related are not grouped, and are contained in the menu structure under **Settings > Protection > General > Bus Sources**. The performance of a voltage source is defined by the setting group that is active at a given time. Multiple setting groups allow the user to conveniently change protection settings for different operating situations (for example, altered power system configuration or season of the year). The active setting group can be preset or dynamically selected in the **Settings > Protection > Setting Group Control** panel.

General settings

To configure voltage sources:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > General > Voltage Sources**.
2. Click the **General Settings** button to expand the content.

Figure 22: Configuring voltage sources



The following settings are available.

ID

Range: up to 20 characters
Default: blank

The text entered here is displayed in settings and actual values displays.

Typically, the text is a description of the system element monitored, for example "A Bus."

Function

Range: Enabled, Disabled
Default: Disabled

When disabled, all operands are forced to Off/zero, all memory is cleared, and timers are held reset. When re-enabled, operand updating and events are suppressed for up to two power system cycles while the voltage source measuring algorithms stabilize.



Bus source Src11 on each process card shares internal resources with the voltage source element VS1. Thus the EnerVista software does not allow saving VS1 enabled while Src11 is enabled, and vice-versa. Similarly, VS2 and Src12 share resources and cannot both be enabled.



Changing the value of this setting in the relay reconfigures the transient recorder and clears all transient records.

Block

Range: any FlexLogic operand

Default: Off

When the selected operand is “On,” the undervoltage comparators are forced to off. Other voltage source functions operate normally.

Events

Range: Enabled, Disabled

Default: Enabled

When enabled, activation of any of the voltage source operands (including DPO) generates an event in the event record.

Voltage sources settings

Each voltage source requires a three-phase set of measurements of the voltages on a bus segment. These voltages can be from a single Brick, or from dual redundant Bricks. Redundant Bricks provide for high reliability of measurement of voltages: when one origin's Brick is lost or fails a Brick internal self-test, the relay instantaneously transfers to the other.

When measurements from two Bricks are received and neither indicates any Brick self-test failure yet the two measurements disagree, discrepancy operand is activated. This operand can be used to block or otherwise appropriately modify relay behavior. In addition, if the disagreement persists, the Crosschecking Error self-test is raised.



NOTE

The crosschecking feature does not by default block protection or other relay function. However, individual or all protection and control functions can be blocked on detection of crosschecking error by setting the appropriate protection block settings and/or configurable major self-test setting to the logical OR of the appropriate discrepancy operands.

Voltage source settings determine which Brick(s) are used by the voltage source, the ratio and secondary rating of the primary VTs, and their connection (wye/delta).

To configure VT settings:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > General > Voltage Sources**.
2. Click the **VT Settings** button to expand the content.

Figure 23: Configuring voltage sources

PARAMETER	F/V S 1	F/V S 2	J/V S 1
ID			
General Settings			
VT Settings			
Origin 1	None	None	None
Origin 2	None	None	None
Ratio	1.00	1.00	1.00
Secondary	66.4 V	66.4 V	66.4 V
Connection	Wye	Wye	Wye
ACTUAL VALUES			

The following settings are available.

Origin 1 , Origin 2

Range: None, any voltage bank of any field unit on the same card as the voltage source (for example for card F, the range is F1/AC5...7, F2/AC5...7, F3/AC5...7, ..., F8/AC5...7)

Default: None

These settings specify the field unit and the AC inputs of the corresponding Brick that are the origins of the voltage inputs for the voltage source.




The EnerVista software does not allow the saving of an origin setting where the field unit order code setting indicates that the proposed origin's AC inputs are not voltage type.

The B95^{Plus} provides for high reliability of voltage measurement by allowing dual origins. The auto-transfer logic is shown in the following figure, and is described as follows. An origin is considered available when the origin is set other than to "None," the selected field unit is enabled, communications with its Brick are up, and the Brick reports no self-test alarms potentially affecting the AC inputs. If origin 1 is available, the relay uses the values from origin 1. Otherwise, if origin 2 is available, the relay uses the values from origin 2. If neither origin is available, then the voltage values are forced to zero to prevent any ambiguity of measurement, and the voltage source fail operand is activated. Zero voltage forces operation of the undervoltage functions. Where undervoltage operation on voltage source fail is inappropriate, the fail operand can be selected as undervoltage block input.

When connecting to only one Brick, the Brick can be mapped to either origin.

Figure 24: AC input auto-transfer logic diagram



870797A1.vsd



The auto-transfer is not controlled by failures or switching in the AC voltage signals upstream from the Bricks. For instance, a transfer to origin 2 is not initiated by the opening of origin 1 test switches. Detection of such events is problematic, so instead the crosschecking feature described earlier is provided.

The following settings are available.

Ratio

Default: 1.00:1

Range: 1.00 to 24000.00 V in steps of 0.01

This setting specifies the ratio of the VTs associated with this bank. This value is used to calculate primary values for metering and to calculate the primary per-unit base voltage.

Secondary

Default: 66.4 V

Range: 25.0 to 240.0 in steps of 0.1

The relay uses the VT secondary setting as the per-unit secondary base voltage for this voltage source, and the product of the VT ratio and VT secondary settings as the corresponding primary per-unit base voltage. The VT input can be connected to either a phase-to-ground or a phase-to-phase voltage, so these base voltages are correspondingly either a phase-to-ground base voltage or a phase-to-phase base voltage. The phase-to-phase base voltage is the square-root of three times the phase-to-ground base voltage.

Normally the ratio settings are set to the overall ratio of the external VT circuits, and the secondary settings are set to the voltage that appears across the Brick VT input terminals when power system voltage is at the power system's nominal voltage (that is, 1 pu on a system base).

For example, on a 13.8 kV power system, with three 8400/70V wye-connected VTs, the ratio setting is configured as $8400/70 = 120$, and the secondary voltage setting is configured as

$$(13800/\sqrt{3})/(8400/70)=66.4\text{ V}$$

With these settings, a 1 pu voltage measurement in the relay corresponds to 13.8 kV phase-to-phase primary, or 7.968 kV phase-to-ground primary, or 115 V phase-to-phase secondary, or 66.4 V phase-to-ground secondary. On the same 13.8 kV power system but with two 14400/120V open-delta connected VTs, the ratio setting is configured as $14400/120 = 120$, and the secondary voltage setting configured as $13800/(14400/120) = 115.0\text{ V}$. With these settings, a 1 pu phase voltage measurement in the relay corresponds to 13.8 kV phase-to-phase primary or 115 V phase-to-phase secondary; phase-to-ground voltages are not measurable.

Connection

Default: wye

Range: wye, delta

This setting specifies the connection from the Brick to the phase VTs associated with this voltage source.

With a wye setting value, the three phase inputs AC5, AC6, and AC7 are assumed to be phase-to-ground voltages (that is, V_{ag} , V_{bg} and V_{cg} respectively) when calculating phase-to-phase voltages. With a delta setting value, the three phase inputs are assumed to be phase-to-phase voltages (that is, V_{ab} , V_{bc} and V_{ca} respectively).

With delta connected VTs, the relay does not have sufficient information to measure either zero sequence or phase-to-ground voltages. Without phase-to-ground voltages, undervoltage supervision is not as sensitive to high-impedance ground faults.



Changing the value of this setting in the relay reconfigures the transient recorder and clears all transient records.

Undervoltage settings

When valid voltage inputs are not available to the undervoltage function, it is blocked. If the undervoltage operand is used to supervise the bus differential function, and it is the only source of supervision, the differential is unable to operate while the voltage inputs are unavailable. If required, to allow differential operation in the absence of valid voltage inputs, the voltage source fail operand can also be assigned as a bus differential zone supervision input.

To configure group n undervoltage settings:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > Group n > Voltage Sources**.
2. Click the **Undervoltage Settings** button to expand the content.

Figure 25: Configuring undervoltage settings

PARAMETER	GROUP 1	F/V S 1	F/V S 2	J/V S 1	
Undervoltage Settings					
UV Phase Gnd Pickup		0.50 pu (66.4 V base)	0.50 pu (66.4 V base)	0.50 pu (66.4 V base)	0.50 pu
UV Phase Phase Pickup		0.50 pu (115.008 V base)	0.50 pu (115.008 V base)	0.50 pu (115.008 V base)	0.50 pu

The following settings are available.

UV Phase-Gnd Pickup

Default: 0.50 pu

Range: 0.50 through 1.50 pu in steps of 0.01 pu

This setting is the voltage level below which a phase-to-ground voltage must be for the undervoltage function to operate. Where the undervoltage element is used to supervise bus zones, this is the maximum voltage at which bus differential tripping occurs. If the VT connection setting is Delta, the phase-to-ground undervoltage function is not available and this setting has no effect.

Configure this setting to be above the maximum phase-to-ground voltage expected for an internal phase-to-ground bus fault, with maximum fault impedance and worst-case source impedance.

UV Phase-Phase Pickup

Default: 0.50 pu

Range: 0.50 through 1.50 pu in steps of 0.01 pu

This setting is the voltage level below which a phase-to-phase voltage must fall for the undervoltage function to operate. Where the undervoltage element is used to supervise bus zones, this is the maximum voltage at which bus differential tripping occurs.

When used with wye connected VTs, configure this setting to be above the maximum phase-to-phase voltage expected for an internal phase-to-phase or three-phase bus fault, with maximum fault impedance and worst-case source impedance.

When used with delta connected VTs, configure this setting to be above the maximum phase-phase voltage expected for an internal phase-to-ground, phase-to-phase or three-phase bus fault, with maximum fault impedance and worst-case source


impedance, but below the minimum expected voltage under normal operating conditions. Where this is not possible, do not use the undervoltage element for differential supervision.



NOTE

The currents used by the undervoltage function are subject to the cutoff setting. See **Settings > General > Power System > Current Cutoff Level** for details.

Figure 26: Undervoltage logic diagram



Actual values

When the EnerVista software is online, these fields indicate the functional status (blocked/disabled/running), origins being used at present, the crosschecking status, the phase-to-phase voltages, the status of the undervoltage operate, and the status of the VT trouble operands. If the VT connection is wye, the phase-to-ground voltages are also shown. The voltages are shown as phasors in numerical polar representation, and can also be shown on a vector graph.

When the EnerVista software is offline, actual values do not appear.

There are two ways to view actual values: in the settings window or the actual values window.


To view voltage source information in the settings window:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > General > Voltage Sources**.
2. Click the **Actual Values** field to expand the content.
3. Click a **View** button to display the phasors graphically.

To view voltage source information in the actual values window:

1. In the **Online Window** area of the software, navigate to **Actual Values > Protection > Voltage Sources**.
2. Click a **View** button to display the phasors graphically.

Figure 27: Viewing voltage source information



The following information can be viewed.



The currents used by the actual values function are subject to the cutoff setting. See **Settings > General > Power System > Current Cutoff Level** for details.

Function

Range: *Running, Blocked, Disabled*

Indicates whether the voltage source is Disabled (Function setting is Disabled), Blocked (Function is Enabled but the block operand is On), or Running (Function setting is Enabled, the block operand is Off).

Phasor Vag...cg

Range: *0.00 to 999999.999 V, -359.9 to 0.0 deg*

Indicates the phase to ground voltages' magnitude and angle. Not displayed when the Connection setting is Delta.

Phasor Vab...ca

Range: *0.00 to 999999.999 V, -359.9 to 0.0 deg*

Indicates the phase to phase voltages' magnitude and angle.

Origin Selected

Range: *Origin 1, Origin 2, None*

Indicates the origin presently being used.

Crosschecking Status

Range: *OK, Discrepant*

Indicate the crosschecking status of redundant origins. When two three-phase sets of voltages are being received without diagnostic flags, the two inputs of each phase are compared on a sample-by-sample basis. When all pairs are substantially the same, OK is displayed in green. When any pair is substantially different, Discrepant is displayed in red.

Undervoltage Op

Range: *On (lit LED), Off (extinguished LED)*

Indicates if the voltage source's undervoltage protection is operating.

VT Trouble

Range: *On (lit LED), Off (extinguished LED)*

Indicates if voltage source VT trouble is detected.

FlexLogic operands

FLEXLOGIC OPERANDS - VOLTAGE SOURCE LOGIC OPERANDS

F, J/VS1...2 Fail:	Logic operands that are On when at least one origin is selected to an enabled field unit, but no measurements are being received without brick self-test flags that can affect AC inputs set.
F, J/VS1...2 Discrepancy:	Logic operands that are On when voltage measurements are being received from both origins with no brick self-test flags that can affect AC inputs set, but the two measurements are substantially different.
F, J/VS1...2 UV Op:	Logic operands that are On when the undervoltage function is operating.
F, J/VS1...2 UV Dpo:	Logic operands that are On when the undervoltage function is not operating.
F, J/VS1...2 VT Trbl:	Logic operands that are On when some but not all measured voltages are below their setting for more than 1 second.

Analog operands

VOLTAGE SOURCES - ANALOG OPERANDS

F, J/VS1...2 Va...c Mag:	Analog operands that when the VT configuration is wye, contain the primary phase-to-ground fundamental frequency voltage magnitude. The units are volts.
F, J/VS1...2 Va...c Angle:	Analog operands that when the VT configuration is wye, contain the primary phase-to-ground fundamental frequency voltage angle. The units are degrees leading the frequency reference.
F, J/VS1...2 Vab Mag:	Analog operands that when the VT configuration is wye, contain the primary phase-to-phase fundamental frequency voltage magnitude. The units are volts. Vbc and Vca are similar.
F, J/VS1...2 Vab Angle:	Analog operand that when the VT configuration is wye, contain the primary phase-to-ground fundamental frequency voltage angle. The units are degrees leading the frequency reference. Vbc and Vca are similar.

The currents used by the analog operands are subject to the cutoff settings. See **Settings > General > Power System > Current Cutoff Level** for details.

Bus differential

The bus differential element provides primary protection for six bus zones. A bus zone includes three single-phase bus differential comparators and fixed integration logic.

A bus zone typically protects a single bus segment. A bus segment is a solid section of bus connected through circuit breakers and/or isolators to network elements and/or to other bus segments. A network element is a feeder, incomer, transformer, capacitor, reactor, generator, and so on. Any bus zone can instead be used as a check zone, covering the overall bus for the purpose of supervising and/or backing-up the individual bus segment protections.




NOTE

Bus differential element operation is completely dependent on the dynamic bus replica function implemented by the B95^{Plus} in bus source elements. The bus source elements must be configured to achieve proper bus differential operation.

Both restrained (biased) and unrestrained (unbiased) bus differential protection functions are provided for each bus differential comparator in each bus zone.

The biased bus differential protection function has a dual-slope operating characteristic (see figure). The differential current is the magnitude of the vector sum of all bus source currents dynamically connected to the bus zone. The dynamically connected bus source current with the highest magnitude is used as the restraining current. The restraint characteristic provides stability by requiring higher differential currents to operate when fault and thus measurement error levels are higher. In other words, measuring how high the fault is (restraint) can be used to determine how bad the differential error is and how much differential current is to be expected for an internal fault.

Figure 28: Biased differential operating characteristic



Additional stability during heavy external faults is achieved by dynamic CT saturation detection and current direction supervision. This is done in a way that does not affect sensitivity or speed of operation for internal faults.

The saturation detector is an integral part of the biased bus differential protection function. It has no associated settings, but uses some of the differential characteristic parameters.

The current directional supervision is also an integral part of the biased bus differential protection function, and has no associated settings. The directional comparator dynamically identifies what appears to be the faulted bus source and compares its current angle with that of the sum of the remaining currents of the bus zone. The current direction comparator declares an internal fault if the angle difference is less than 90°.

The biased differential protection function's operating characteristic is divided into two regions. In the region of low differential currents and lower slope, the element operates on a 2-out-of-2 basis, applying both the biased differential and current direction tests. In the region of high differential currents, the element operates on a dynamic 1-out-of-2 / 2-out-of-2 basis. If the differential current is in this region and CT saturation is detected, both the

biased differential and current direction tests are applied. If CT saturation is ruled out by the saturation detector, the biased differential protection principle alone is capable of causing the element to operate.

The unbiased bus differential protection function checks the magnitude of the differential current against a settable threshold. Neither restraint (bias), nor current directional, nor CT saturation are used.



The currents used by the bus differential are not subject to the cutoff setting. See **Settings > General > Power System > Current Cutoff Level** for details.

The bus differential element provides six identical bus zone protections. They are designated Z1 through Z6.

Each bus zone is provided with settings to assign a logical name, settings for various thresholds, slopes and delays, settings to enable, block, supervise and force bus zone operation, and a setting to enable changes of state to be recorded by the events recorder. These settings are described in the following sections.

The bus zones implement the setting group feature. Each is provided with two alternate sets of threshold-related settings, in setting groups numbered 1 and 2. Grouped settings are contained in the software under **Settings > Protection > Group n > Bus Sources**, where n is the group number. Settings not threshold-related are not grouped, and are contained under **Settings > Protection > General > Bus Sources**. The performance of a bus zone is defined by the setting group that is active at a given time. Multiple setting groups allow the user to conveniently change protection settings for different operating situations (for example, altered power system configuration or season of the year). The active setting group can be preset or dynamically selected via the **Settings > Protection > Setting Group Control** menu item.

General settings

To configure bus differential settings:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > General > Bus Differential**.
2. Click the **General Settings** button to expand the content.

Figure 29: Bus differential settings

PARAMETER	Z1	Z2	Z3
ID			
General Settings			
Function	Disabled	Disabled	Disabled
Block	OFF	OFF	OFF
Auxiliary Zone Trip	OFF	OFF	OFF
Check-Zone	No	No	No
Events	Enabled	Enabled	Enabled
ACTUAL VALUES			
F CT in Zone			
J CT in Zone			

The following settings are available.

ID

Range: up to 20 characters

Default: blank

The text entered here appears in settings and actual values displays where the bus zone is referenced. Typically, the text is the name of the protected bus segment or the of zone's function (for example, "A1 Bus" or "Check-Zone").

Function

Range: Disabled, Enabled

Default: Disabled

When disabled, the bus zone's differential comparator outputs are forced off and its FlexAnalog outputs are forced to zero. Otherwise, the logic shown here continues to run. Even when disabled, the Auxiliary Zone Trip input becoming On results in trip bus activation and Bkr Trip Init activation of all enabled bus sources either directly connected to the zone or connected through parallel(s).

Block

Range: any FlexLogic operand

Default: Off

This setting selects an operand to control the bus zone block feature. When the selected operand is "On," the element is prevented from initiating the trip bus or the Z Diff Op operand. Otherwise, the logic shown here continues to run.

Auxiliary Zone Trip

Range: any FlexLogic operand

Default: Off

This setting selects an operand to initiate the zone trip bus. When the selected operand is "On," the zone trip bus is initiated. When the zone trip bus is initiated, the bus sources trip the breakers connected to that bus zone. See the logic block diagram. For further information on the zone trip bus, see the Bus Sources section.

This feature allows for instance a loss of insulating gas sensor in a compartment of the associated bus segment to use the bus replica function to trip the appropriate breakers.

Check-Zone

Range: No, Yes

Default: No

When set to yes, the bus zone integration logic operation is modified to implement check-zone functionality: operation of the bus differential protection, Auxiliary Zone Trip or Connected Zone Trip does not initiate the zone trip bus, nor does the bus zone participate in the paralleled bus logic, nor does the bus replica switch CTs to implement zone expansion/contraction, nor does the differential protection block when a CT is bypassed. For further information on check-zone operation, see the discussion on Check Zones in the overview section.

To apply check-zone supervision to another zone, select the check zone's operate operand as one of the zone supervision settings of that other zone. For further information on how to set up check zones, see the Bus Replica Application Guide chapter.

Events

Range: Enabled, Disabled

Default: Enabled

When "Enabled," every activation of the following bus zone operands is logged in the event record:

Z1...6 Op

Z1...6 DPO

Z1...6 A...C Pkp
 Z1...6 A...C CT Trbl
 Z1...6 A...C Direction
 Z1...6 A...C Supervision
 Z1...6 Supvn Trbl
 Z1...6 Trip Bus Op

Operating characteristic settings

To configure group n bus differential settings:

1. In the **Online Window** area, navigate to **Settings > Protection > Group n > Bus Differential Thresholds**.
2. Click the **Characteristics Settings** button to expand the content.

Figure 30: Operating characteristics for bus differential settings

PARAMETER [GROUP 1]	Z1	Z2	Z3
Characteristics Settings			
Pickup	0.100 pu (0 A base)	0.100 pu (0 A base)	0.100 pu (0 A base)
Low Slope	25 %	25 %	25 %
Low Breakpoint	2.00 pu (0 A base)	2.00 pu (0 A base)	2.00 pu (0 A base)
High Breakpoint	8.00 pu (0 A base)	8.00 pu (0 A base)	8.00 pu (0 A base)
High Slope	60 %	60 %	60 %
High Set Enable	Enabled	Enabled	Enabled
High Set	15.00 pu (0 A base)	15.00 pu (0 A base)	15.00 pu (0 A base)
CT Trbl Pickup	0.050 pu (0 A base)	0.050 pu (0 A base)	0.050 pu (0 A base)
CT Trbl Delay	10.0 s	10.0 s	10.0 s
Supervision Settings			

The following settings are available.

Pickup

Range: 0.050 to 2.000 pu in steps of 0.001

Default: 0.100 pu

This setting defines the minimum differential current required for operation of the biased bus differential protection. This prevents undesired operation when the bus carries little current and the restraining signal is too low to provide enough bias in the first slope region of the differential characteristic.

This setting needs to be above the maximum magnitude of the differential current that can be seen under no-through-load conditions, due to for instance a station service transformer tapped to the bus whose current is not measured by the bus protection. This setting can also be set above the maximum load level to provide some security during CT trouble conditions. However, undervoltage supervision or check-zone supervision is typically a better alternative.

The base current used by this per unit setting is displayed following the setting's value by the EnerVista software. It is the largest CT primary setting of those bus sources that are connectable to this bus zone. A bus source is considered connectable to this bus zone if the zone connection setting for that particular bus source is set to other than the OFF operand. A bus source is also considered connectable to this bus zone if it could be paralleled through one or more other bus sources. The EnerVista software calculates and displays the base for the present CT primary and connection settings.

Low Slope

Range: 15 to 100 % in steps of 1

Default: 25%

This setting defines the differential current operating threshold as a percentage of the restraining current when differential current is above pickup and restraint current is below the low breakpoint. Restraining current is the bus source current with the highest magnitude. This setting determines the sensitivity of the relay for low current internal faults.

The value chosen should be high enough to accommodate the spurious differential current resulting from ratio inaccuracy of the CTs operating in their linear mode, for example under load conditions and during distant external faults.

Low Breakpoint

Range: 1.00 to 30.00 pu in steps of 0.01

Default: 2.00 pu

This setting is the restraining current of the low breakpoint of the dual-slope operating characteristic. Restraining current is the bus source current with the highest magnitude.

This setting needs to be set not less than the current for which all the CTs operate without saturation, including the effect of residual magnetism. It is to be preferably above maximum load current on any single bus source. The base current used by this per unit setting is displayed following the setting's value by EnerVista software. It is the largest CT primary setting of those bus sources that are connectable to this bus zone. A bus source is considered connectable to this bus zone if the zone connection setting for that particular bus source is set to other than the OFF operand. A bus source is also considered connectable to this bus zone if it could be paralleled through one or more other bus sources. The EnerVista software calculates and displays the base for the present CT primary and connection settings.

High Breakpoint

Range: 1.00 to 30.00 pu in steps of 0.01

Default: 8.00 pu

This setting is the restraining current of the high breakpoint of the dual-slope operating characteristic. Restraining current is the bus source current with the highest magnitude.

This setting must be at or above the low breakpoint setting and below the minimum current that is likely to saturate the weakest CT that can be used by the bus zone.

The base current used by this per unit setting is displayed following the setting's value by the EnerVista software. It is the largest CT primary setting of those bus sources that are connectable to this bus zone. A bus source is considered connectable to this bus zone if the zone connection setting for that particular zone bus source is set to other than the OFF operand. A bus source is also considered connectable to this bus zone if it could be paralleled through one or more other bus sources. The EnerVista software calculates and displays the base for the present CT primary and connection settings.

High Slope

Range: 50 to 100% in steps of 1

Default: 60%

This setting defines the differential current operating threshold as a percentage of the restraining current when restraint current is above the high breakpoint. Restraining current is the bus source current with the highest magnitude. This setting affects stability of the relay for heavy external faults.

The dual-slope operating characteristic of the biased bus differential protection element is shaped to ensure true percentage bias for high restraining currents (see the earlier figure). This means that the straight line defining the high slope extended intersects the

origin of the differential-restraining plane, and that a discontinuity appears between the low and high slope regions. This discontinuity is handled by connecting the boundary of the characteristic between the high and low slopes with a straight line.

Traditionally, the value chosen for this setting is high enough to accommodate the spurious differential current resulting from saturation of the CTs during heavy external faults. With the B95^{Plus} bus differential protection, that requirement can be relaxed somewhat in favor of sensitivity and speed of operation because upon CT saturation the directional principle is applied to prevent undesired operation.

High Set Enable

Range: Disabled, Enabled

Default: Enabled

When disabled, the high set (unbiased differential) comparator outputs are forced off. Otherwise, the logic shown here continues to run.

High Set Level

Range: 2.00 to 99.99 pu in steps of 0.01

Default: 15.00 pu

This setting defines the minimum differential current required for operation of the unbiased bus differential protection function.

This setting is based on the maximum magnitude of the differential current that can be seen during heavy external faults causing deep CT saturation. When selecting this setting, keep in mind that the unbiased bus differential protection function uses the full-cycle Fourier measuring algorithm and applies it to pre-filtered samples of the input currents. As a result, the transient measuring errors, including the effect of the DC component, are below 2%. During heavy CT saturation when the currents are significantly distorted, the magnitude of the differential current as measured by the relay and used by the unbiased bus differential function is significantly lower than both the peak values of the waveform and the true RMS value. The measured magnitude practically reflects the power system frequency component alone. This allows for lower values of the high set setting.

The base current used by this per unit setting is displayed following the setting's value by the EnerVista software. It is the largest CT primary setting of those bus sources that are connectable to this bus zone. A bus source is considered connectable to this bus zone if the zone connection setting for that particular bus source is set to other than the OFF operand. A bus source is also considered connectable to this bus zone if it can be paralleled through one or more other bus sources. The EnerVista software calculates and displays the base for the present CT primary and connection settings.

CT Trbl Pickup

Range: 0.020 to 2.000 pu in steps of 0.001

Default: 0.050 pu

When the differential current is persistently above the level of this setting, the CT trouble operand is turned on. Persistent differential current may result from interruptions or short circuits in the secondary circuits of current transformers, errors in the CT connections (polarity or phase rotation), errors in the configuration of the bus protection, or erroneous isolator or breaker status input that causes a bus source current to be incorrectly included or excluded by the bus replica function. Although the problem may not cause enough differential current under normal operating conditions to cause a trip, it can at some later time or date cause a trip for an external fault, or trip incorrect bus segments for an internal fault.

The CT trouble operand is used to generate an alarm, so immediate corrective action can be initiated. It can also be used to block bus tripping, or to delay bus tripping to coordinate with the expected clearance time for external faults.

Set this setting above the differential current level that is expected under normal operating conditions.

The base current used by this per unit setting is displayed following the setting's value by the EnerVista software. It is the largest CT primary setting of those bus sources that are connectable to this bus zone. A bus source is considered connectable to this bus zone if the zone connection setting for that particular bus source is set to other than the OFF operand. A bus source is also considered connectable to this bus zone if it can be paralleled through one or more other bus sources. The EnerVista software calculates and displays the base for the present CT primary and connection settings.

CT Trbl Delay

Range: 1.0 to 60.0 s in steps of 0.1
Default: 10.0 s

This setting defines the amount of time the differential current must be above the CT trouble pickup setting before CT trouble is declared.


Typically, the time delay is set in the range of 5 to 10 seconds. This allows riding through periods of elevated differential current during bus switching operations, external faults, transformer inrush conditions, and so on.

Supervision settings

To configure group n bus differential settings:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > Group n > Bus Differential Thresholds**.
2. Click the **Supervision Settings** button to expand the content.

Figure 31: Supervision bus differential settings



The following settings are available.

Zone Supervision Voting

Range: AND, OR
Default: OR

These settings select whether the supervision inputs Zone Supervision1 and Zone Supervision 2 are required to be both On (AND) or either to be On (OR) to permit the Zone Differential to operate. See the logic diagram.

Undervoltage supervision or check-zone supervision can be implemented by setting a zone supervision setting to select the appropriate elements' operate operands.

Zone Supervision 1, Zone Supervision 2

Range: any FlexLogic operand
Default: Zone Supervision 1:- ON, Zone Supervision 2:- OFF

These settings select operands to supervise bus zone operation. When the Zone Supervision Voting settings is AND and one or both of the selected operands is "Off," the bus zone differential operand is forced off, as is the input from this bus zone to the zone

trip bus. When the Zone Supervision Setting is OR and both of the selected operands is "Off," the bus zone differential operand and the input to the zone trip bus are again forced off. See the logic diagram.

Undervoltage supervision and/or check-zone supervision can be implemented by setting a zone supervision setting to select the appropriate elements' operate operands.

Supvn Trbl Delay


Range: 0 to 100 ms in steps of 2 ms

Default: 0 ms

This setting defines the amount of time a bus differential comparator can be picked up before zone supervision without the supervision trouble operand being turned on. When undervoltage or check-zone supervision is used to avoid undesired tripping due to scheme problems, it is good to annunciate occasions where the supervision function incorrectly prevented or unduly delayed a trip. This so an alarm can be generated initiating immediate corrective action. Once declared, the condition is sealed in until the differential current has subsided for 1 second, to ensure recognition. See the logic diagram.

Set this time delay to be just longer than the expected maximum time to develop supervision, so that momentary bus differential trip delays can be caught.

Figure 32: Bus differential logic diagram for zone 1



870755A1.vsd

Actual values

When the EnerVista software is online, these fields indicate the status of the CT in zone signals from the bus replica, the differential and restraint currents in primary amperes, and the bus differential operate and CT trouble operands. These are not settings. The differential and restraint values are shown as phasors in numerical polar representation, and can also be shown on a vector graph.

When the EnerVista software is offline, actual values do not appear.



The currents used by the bus differential actual values function are not subject to the cutoff setting. See **Settings > General > Power System > Current Cutoff Level** for details.

There are two ways to view actual values: in the settings window or the actual values window.

To view bus differential information in the settings window:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > General > Bus Differential**.
2. Click the **Actual Values** field to expand the content.
3. Click a **View** button to display the phasors graphically.

To view bus differential information in the actual values window:

1. In the **Online Window** area of the software, navigate to **Actual Values > Protection > Bus Differential**.
2. Click a **CT in Zone** button to expand the content.
3. Click a **View** button to display the phasors graphically.

Figure 33: Bus differential information

PARAMETER	Z1	Z2	Z3
Function	Disabled	Disabled	Disabled
PHASORS	View	View	View
Phase A Bus Diff Current	0.000 A 0.0 deg	0.000 A 0.0 deg	0.000 A 0.0 deg
Phase A Bus Rest	0.000 A 0.0 deg	0.000 A 0.0 deg	0.000 A 0.0 deg
Phase B Bus Diff Current	0.000 A 0.0 deg	0.000 A 0.0 deg	0.000 A 0.0 deg
Phase B Bus Rest	0.000 A 0.0 deg	0.000 A 0.0 deg	0.000 A 0.0 deg
Phase C Bus Diff Current	0.000 A 0.0 deg	0.000 A 0.0 deg	0.000 A 0.0 deg
Phase C Bus Rest	0.000 A 0.0 deg	0.000 A 0.0 deg	0.000 A 0.0 deg
Bus Diff Op	Off	Off	Off
Bus Diff CT Trouble	Off	Off	Off
F CT in Zone			
F/Src 1 CT in Zone	Off	Off	Off
F/Src 2 CT in Zone	Off	Off	Off
F/Src 3 CT in Zone	Off	Off	Off
F/Src 4 CT in Zone	Off	Off	Off
F/Src 5 CT in Zone	Off	Off	Off
F/Src 6 CT in Zone	Off	Off	Off
F/Src 7 CT in Zone	Off	Off	Off
F/Src 8 CT in Zone	Off	Off	Off

The following information displays.

Function

Range: Running, Blocked, Disabled

Indicates whether the bus source is at present Disabled (Function setting is Disabled), or Blocked (Function setting is Enabled but a CT it uses is bypassed, the block input is active, or one of the current inputs required at present is unavailable), or Running (Function setting is Enabled, no CT used is bypassed).

Phase A...C Diff Current

Range: 0.00 to 999999.999 A, -359.9 to 0.0 deg

Indicates the differential currents' magnitude and angle.

Phase A...C Rest Current

Range: 0.00 to 999999.999 A, -359.9 to 0.0 deg

Indicates the magnitude and angle of the current used for restraint.

Bus Diff Op

Range: On (lit LED), Off (extinguished LED)

Indicates if the bus differential is operating.

Bus Diff CT Trbl

Range: On (lit LED), Off (extinguished LED)

Indicates if a bus source CT trouble is detected.

CT in Zone

Range: On (lit LED), Off (extinguished LED)

Indicates which CTs are included in this differential zone.

FlexLogic operands

FLEXLOGIC OPERANDS - BUS DIFFERENTIAL LOGIC OPERANDS

Z1...6 Op:	Logic operands that are On when the differential is operated.
Z1...6 DPO:	Logic operands that are On when the differential is not operated.
Z1...6 A...C Pkp:	Logic operands that are On when the indicated phase differential comparator is operated.
Z1...6 A...C Direction:	Logic operands that are On when the indicated phase differential comparator's directional feature is detecting an internal fault.
Z1...6 A...C Saturation:	Logic operands that are On when the indicated phase differential comparator's CT saturation detector is operated.
Z1...6 A...C Diff Low:	Logic operands that are On when the indicated phase is detecting currents within the lower portion of the differential operating characteristic.
Z1...6 A...C Diff High:	Logic operands that are On when the indicated phase is detecting currents within the upper portion of the differential operating characteristic.
Z1...6 A...C Biased:	Logic operands that are On when the indicated phase is detecting currents within the differential operating characteristic, either high or low, and direction and saturation supervision conditions are met.
Z1...6 A...C Unbiased:	Logic operands that are On when the indicated phase is detecting differential current above the high set level.
Z1...6 A...C CT Trbl:	Logic operands that are On when the indicated phase differential comparator CT trouble detector is operated.
Z1...6 CT Trbl:	Logic operands that are On when any phase's differential comparator CT trouble detector is operated.
Z1...6 Supvn Trbl:	Logic operands that are On when the differential has picked up but lack of supervision is preventing operation.
Z1...6 Trip Bus Op:	Logic operands that are On when the bus zone's trip bus is operated.

Analog operands

BUS DIFFERENTIAL - ANALOG OPERANDS

Z1...6 Ia...c Diff Mag:	Analog operands that contain the differential current magnitude. The units are primary amperes.
Z1...6 Ia...c Diff Angle:.....	Analog operands that contain the differential current angle. The units are degrees leading the frequency reference.
Z1...6 Ia...c Rest Mag:	Analog operands that contain the magnitude of the current used for differential restraint. The units are primary amperes.
Z1...6 Ia...c Rest Angle:.....	Analog operands that contain the angle of the current used for differential restraint. The units are degrees leading the frequency reference.

The currents used by the bus differential analog operands are not subject to the cutoff setting. See **Settings > General > Power System > Current Cutoff Level** for details.

Bus replica graphical editor

The bus replica graphical editor provides a graphical interface to the bus replica related settings described previously.

To access the bus replica and graphical editor:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > General > Bus Replica Graphical Editor**.

See the EnerVista Software chapter for instructions on how to use this editor.

FlexLogic

FlexLogic refers to executable code that you can develop in order to customize the relay's behavior to suit your application.

The states of all digital signals used in the B95^{Plus} are represented by FlexLogic operands. Operands are created and their state driven by the relay's protection elements, remote resources, communications protocols, and so on. Operands are either in the "On" state or the "Off" state. The state is On when the condition described by the operand's name is active. For example, an operand named "J/VS1 Fail" is On when the voltage source has failed. Operands are listed in the manual section dealing with the function that drives them. In addition, there are ON and OFF operands, which have the fixed value of On and Off respectively.

The protection elements, remote resources, communications protocols, and so on also have settings that accept any one of the operands as an input to a control the behavior of that feature. For example, an operand can be selected for the "Operate Operand" setting of a Field Contact Output, which results in the associated Brick's contact output being closed while the operand is in the On state. The state of any operand can be displayed on the annunciator by selecting it in an alarm input setting. The state of any operand can also be transmitted by a communications protocol to control behavior in another relay by selecting it in the appropriate communication profile's setting. In many cases, an operand's state is displayed as an "Actual Value" in the EnerVista software.

If more complex logic than that outlined is required, it is implemented using FlexLogic. FlexLogic employs a series of equations that are defined by a list of operators and operands. The operands are as described in the preceding paragraph. The operators are logic gates, timers, latches, and assignment operators. Eight times per power system

cycle, the FlexLogic engine executes this list in order. Whenever an operand is encountered in the list, the value of its state (On or Off) is pushed on a first-in-last-out stack. Whenever an operator is encountered in the list, the number of operand values that operator requires are popped from the stack, operated on according to that operator's function, and the result of the operation pushed back on the stack. The assignment operator has a special behavior in that it pops one operand value from the stack, and assigns that value to the selected Virtual Output operand; it does not push a value on the stack.


As an example, a site has a SF₆ gas monitor contact connected to the 10th contact input of the Brick connected to B95^{Plus} process bus port J7, and a second SF₆ gas monitor connected to the 10th contact input of the Brick connected to B95^{Plus} process bus port J8. It is required to trip high voltage bus segment BU1 when either of these gas monitors close their contact. Similar logic is required for bus segment BU2. To do this, the FlexLogic Editor is used to make the FlexLogic entries shown in the figure, and the Auxiliary Zone Trip settings for the BU1 and BU2 bus segments selected to virtual outputs 1 and 2 respectively.

Figure 34: Sample FlexLogic equations

MAIN CARD FLEXLOGIC ENTRY	TYPE	SYNTAX	COMMENTS
View Graphic	View		
FlexLogic Entry 1	J Field Contact Inputs	BU1-63G[1] On (J7/FCI10)	
FlexLogic Entry 2	J Field Contact Inputs	BU1-63G[2] On (J8/FCI10)	
FlexLogic Entry 3	OR	2 Input	
FlexLogic Entry 4	Assign Virtual Output	= BU1-63G (M/V01)	
FlexLogic Entry 5	J Field Contact Inputs	BU2-63G[1] On (J7/FCI11)	
FlexLogic Entry 6	J Field Contact Inputs	BU1-63G[2] On (J8/FCI11)	
FlexLogic Entry 7	OR	2 Input	
FlexLogic Entry 8	Assign Virtual Output	= BU2-63G (M/V02)	
FlexLogic Entry 9	End of List		
FlexLogic Entry 10	End of List		

FlexLogic equations can be displayed in a graphical form by clicking the **View** button in the editor. The following figure shows how the above list is displayed graphically.

Figure 35: Schematic of same FlexLogic equations



The FlexLogic engine begins with an empty stack, then executes the list as follows:

- **Entry 1**—Push the value of the operand corresponding to the first BU1 gas monitor (J7/FCI10) on the stack. The stack now has one entry, the state value of the first BU1 gas monitor.

- **Entry 2**—Push the value of the operand corresponding to the second BU1 gas monitor (J7/FCI10) on the stack. The stack now has two entries, the state value of the second BU1 gas monitor followed by the value of the first.
- **Entry 3**—Pop the top value from the stack (second monitor), pop the next value (first monitor), logically OR the two popped values, and push the result on the stack. The stack now has one entry, which is the On if either monitor was On.
- **Entry 4**—Pop the top value from the stack (the result of the OR), and force Virtual Output 1 (with user designation BU1-63G) to assume that value. The stack is now empty.
- **Entry 5-8**—Repeat for bus BU2.

When the execution of this FlexLogic equation makes the state value of one of these virtual outputs On, when next the bus differential element runs it sees its Auxiliary Zone Trip input in the On state and initiates a trip of the bus segment.

FlexLogic rules

The B95^{Plus} contains a FlexLogic engine in the main card and in each process card. Each FlexLogic engine's list can contain up to 512 entries, including the end operator. Each FlexLogic engine can use as input operands for any of the cards, but can assign only to virtual outputs on its own card.

When forming a FlexLogic equation, the sequence in the linear array of parameters must follow these general rules:

- Operands must precede the operator that uses the operands as inputs
- Operators have only one output. The output drives a virtual output operand for the assignment operator; all other operators push their outputs back onto the stack.
- The output of an operator must be assigned to a virtual output if it is to be used as an input to two or more operators
- Assigning the output of an operator to a virtual output terminates the equation. The value assigned to the virtual output is used on all following lines.
- All operands can be used in equations, including the virtual output that the equation assigns. This can be used to implement seal-in or other type of feedback.
- A timer operator (for example, "TIMER 1") or virtual output assignment (for example, "= M/VO1") can only be used once. When this rule is broken, a syntax error is declared.
- Each equation is evaluated in the order in which the parameters have been entered. Each equation is evaluated in the order entered in the list.

FlexLogic provides latches that have a memory action, remaining in the state set after the set input has been asserted. However, they are volatile and reset on the re-application of control power. When making changes to settings, all FlexLogic equations are recompiled whenever any new setting value is saved, so that latches are automatically reset. When re-initialization of FlexLogic is required during testing, for example, power the unit off then on.

Some operands can be renamed. See the Renaming FlexLogic Operands section in the Communications chapter.

FlexLogic gates and operators

The characteristics of logic gates used in FlexLogic equations are tabled here.

Table 1: Protection FlexLogic gate characteristics

Gate	Number of inputs	Output is On if	Output is Off if
NOT	1	input is Off	input is On
OR	1 to 16	any input is On	all inputs are Off
AND	1 to 16	all inputs are On	any input is Off
NOR	1 to 16	all inputs are Off	any input is On
NAND	1 to 16	any input is Off	all inputs are On
XOR	2	one input is On, other input is Off	both inputs are On or both inputs are Off

The following operators are available for use in protection FlexLogic equations.

Table 2: FlexLogic operators

Type	Syntax	Description	Operation
End	END	The first END operator signifies the last entry in the list	Terminates execution of this pass.
One shots	POSITIVE ONE SHOT	One shot that corresponds to a positive-going edge	A <i>one shot</i> refers to a single input gate that generates a pulse in response to an edge on the input. The output from a one shot is true (positive) for only one pass through the FlexLogic equation. There are a maximum of 64 one shots.
	NEGATIVE ONE SHOT	One shot that corresponds to a negative-going edge	
	DUAL ONE SHOT	One shot that responds to both the positive and negative-going edges	
Logic gates	NOT	A logical NOT gate	Operates on the previous parameter
	AND(<i>n</i>)	An <i>n</i> -input AND gate, <i>n</i> = 1 to 16	Operates on the previous <i>n</i> parameters
	OR(<i>n</i>)	An <i>n</i> -input OR gate, <i>n</i> = 1 to 16	Operates on the previous <i>n</i> parameters
	NOR(<i>n</i>)	An <i>n</i> -input NOR gate, <i>n</i> = 1 to 16	Operates on the previous <i>n</i> parameters
	NAND(<i>n</i>)	An <i>n</i> -input NAND gate, <i>n</i> = 1 to 16	Operates on the previous <i>n</i> parameters
	XOR(2)	A two-input exclusive OR gate	Operates on the previous 2 parameters
	LATCH(S,R)	Latch (set, reset), reset-dominant	Operates on the previous 2 parameters. The parameter preceding LATCH(S,R) is the reset input. The parameter preceding the reset input is the set input.
Timers	TIMER <i>n</i>	Timer set with the settings programmed for FlexLogic timer <i>n</i> , where <i>n</i> = 1 to 32	The timer is started by the preceding parameter. The output of the timer is TIMER #.
Assign virtual outputs	VIRT OP <i>n</i>	Assigns the previous FlexLogic parameter to virtual output <i>n</i> , where <i>n</i> = 1 to 96	The virtual output is set by the preceding parameter. FlexLogic of a particular card can only assign the virtual outputs of that card.

FlexLogic equation editor

The FlexLogic equation editor is used to build and edit the list of operands and operators that define the equations.

To enter or edit main card or process card FlexLogic equations:

1. For the main card, in the **Online Window** area of the software, navigate to **Settings > Protection > Main Card FlexLogic > FlexLogic Equation Editor**. Process card FlexLogic is accessed similarly.

- By default, all FlexLogic entries are "End Of List." To enter an equation, change the default to the required operands and operators one-by-one. For each, click on the TYPE setting and select the required type from the drop-down list. Then click on the SYNTAX setting and select the required operand, or for operators select the number of operands required.
- By right clicking an entry in the TYPE or SYNTAX columns, the entry can be copied to the paste buffer, deleted or a new entry inserted in the list. When entries have been copied to the paste buffer, they can be pasted into to a different location.
- One or more entries can be selected by dragging the mouse over the range in the TYPE or SYNTAX columns with the left button held, or using the keyboard arrow keys with a shift button held. Right clicking on the selection allows copying, pasting, inserting or deleting the entire range.


FlexLogic timers

There are 32 identical protection FlexLogic timers available on the main card and on each process card. These timers can be used as operators in FlexLogic equations.

To configure FlexLogic timers:

- In the **Online Window** area of the software, navigate to **Settings > Protection > Main Card FlexLogic > FlexLogic Timers** to open the main card FlexLogic timers configuration window. Process card timers are similarly accessed.

Figure 36: FlexLogic timers configuration settings



The following settings are available for each protection FlexLogic timer.

Pickup Delay

Range: 0 to 3600000000 ms in steps of 1

Default: 0

This setting specifies the time delay to pickup. If a pickup delay is not required, set this value to "0."

Dropout Delay

Range: 0 to 3600000000 ms in steps of 1

Default: 0

This setting specifies the time delay to dropout. If a dropout delay is not required, set this value to "0."


Non-volatile latches

The non-volatile latches provide a permanent logical flag that is stored safely and is not reset upon reboot after the relay is powered down. Typical applications include sustaining operator commands or permanent block of relay functions until a deliberate interface action resets the latch. There are 16 non-volatile latches available for use in the main card and 16 in each of the process cards.

To configure the latches:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > Main Card FlexLogic > Non-Volatile Latches** to open the non-volatile latches configuration window. Process cards are accessed similarly.

Figure 37: Non-volatile latches configuration settings



The following settings are available.

Function

Range: Enabled, Disabled
Default: Disabled

This setting enables and disables the corresponding non-volatile latch.

Type

Range: Reset Dominant, Set Dominant
Default: Reset Dominant

This setting selects the non-volatile latch as set-dominant or reset-dominant. When both Set and Reset inputs are active at the same time, a Reset Dominant latch is reset (Off) and a Set Dominant latch is set (On).

Set

Range: any FlexLogic™ operand
Default: OFF

When the operand assigned to this setting is asserted, the non-volatile latch is set (On).

Reset

Range: any FlexLogic™ operand
Default: OFF

When the operand assigned to this setting is asserted, the non-volatile latch is reset (Off).

Events

Range: Enabled, Disabled
Default: Disabled

This setting enables and disables the logging of non-volatile latch events in the sequence of events recorder.


The following table summarizes the operation of the non-volatile latches.

Table 3: Non-volatile latch operation table

Type	Latch operation			
	Set	Reset	On	Off
Reset-dominant	ON	OFF	ON	OFF
	OFF	OFF	Previous state	Previous state
	ON	ON	OFF	ON
	OFF	ON	OFF	ON
Set-dominant	ON	OFF	ON	OFF
	ON	ON	ON	OFF
	OFF	OFF	Previous state	Previous state
	OFF	ON	OFF	ON

The logic for non-volatile latches is shown as follows.

Figure 38: Non-volatile latches scheme logic




Setting group control

The setting groups control function activates and deactivates of two setting groups.

To configure group control:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > Setting Group Control** to access the setting group control settings.

Figure 39: Setting group control configuration



The following settings are available.

Function

Range: Enabled, Disabled

Default: Disabled

This setting is used to enable and disable the setting groups control functionality.

Block*Range: any FlexLogic operand**Default: OFF*

This setting prevents the active setting group from changing when the assigned operand is asserted. This can be useful in applications where it is undesirable to change the settings under certain conditions.

Group 2 Activate On*Range: any FlexLogic operand**Default: OFF*

This setting selects an operand which, when set, activates the group 2 settings.

Events*Range: Enabled, Disabled**Default: Disabled*

This setting enables and disables the logging of setting group control events in the sequence of events recorder.

Current Setting Group

This is an actual value.

Isolators


In dynamic buses, physical isolators (disconnects) dynamically control the bus configuration, that is, to which bus zone or zones a bus source is dynamically connected. The bus replica uses isolator position information to determine from moment-to-moment which CTs each bus zone differential function is to use, and which breakers are to be tripped when a differential or some other protection needs to trip the zone.

**NOTE**

An error in isolator position input can result in a bus zone unnecessarily tripping for a fault not in its zone. It is also possible for a bus zone to fail to trip on an internal fault due to erroneous isolator inputs. Correct isolator position status is vital. Therefore the B95^{Plus} provides a pool of isolator logic functions to process redundant isolator position contact inputs, to force a failsafe isolator position when appropriate, and to alarm inconsistent position inputs.

To reduce the risk of incorrect isolator position status, frequently two auxiliary contacts are used to sense each isolator's position. One of these is designed to be in the closed state when the isolator is fully closed, referred to here as the "isolator closed" contact (IEEE C37.2 function number: 89a). The other is designed to be in the closed state when the isolator is fully open, referred to here as the "isolator opened" contact (89b). This allows the detection of some of the troubles that can cause position input error, including failure of a single contact in the isolator's auxiliary contact stack.

Figure 40: Isolator auxiliary contact operation



Normally an isolator is in either the “opened” or “closed” position. When moving between these two positions, it is briefly in the “travelling” state—neither fully open nor fully closed. When in the travelling state, the isolator may or may not be able to conduct primary current, depending on the mechanical setup of the auxiliary contacts, which can vary over time. Indication of open and closed at the same instant never occurs in a healthy system.

With both isolator opened and isolator closed auxiliary contacts, there are four possible combinations, which are named as outlined in the table.

Table 4: Isolator opened and closed auxiliary contacts

“Isolator Closed” (89a) contact state	“Isolator Opened” (89b) contact state	Isolator position/state
Off (contact opened)	Off (contact opened)	Travelling
On (contact closed)	Off (contact opened)	Closed
Off (contact opened)	On (contact closed)	Opened
On (contact closed)	On (contact closed)	Error

When in the travelling or error state, the isolator output operand assumes the position of the failsafe position setting.

Another strategy to reduce this risk is the use of redundant/dual Bricks, both of which measure and report to the B95^{Plus} the state of one or both contacts.

Note that neither of these measures is effective against failures in the linkage between the primary contacts of the isolator and its auxiliary contacts. Often the primary contacts are ten meters or more above the auxiliary switches, connected by a comparatively fragile linkage that is shared with the isolator drive motor. A common failure mechanism is linkage shearing due to the drive attempting to move a frozen or welded isolator. With the linkage failed, the position of the auxiliary switches may have no relation to the primary switch position.

Forty-eight isolator functions are provided for each process card specified by the relay’s order code. They are designated by the process card slot number, the isolator code “/Iso,” and an isolator sequence number, 1 through 48. Process cards can be in slots F and J. Thus the first isolator designation on the first process card is “F/Iso1,” while the last bus source on the last process card is designated “J/Iso48.”


Settings

Each isolator function has settings to assign a logical name, and select dual redundant 89a and 89b position status inputs. All isolator functions share a common setting to assign failsafe position, a common setting to set the trouble alarm delay, and a common setting to enable changes of state to be recorded by the event recorder.

To configure isolator settings:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > Isolators**.

Figure 41: Configuring isolator settings



The following settings are available.

ID

Range: up to 20 characters

Default: blank

The text entered here is displayed in settings and actual values displays.

Typically, the text is a description of the physical isolator, for example, "Markham Fdr 23/A Bus."

Opened 1, Opened 2, Closed 1, Closed 2

Range: any FlexLogic operand

Default: OFF

These settings attach the isolator to operands determining the isolator's dynamic position. The isolator logic accommodates both of the redundancy schemes described earlier.

For applications with dual Bricks and both normally open (89a) and normally closed (89b) contacts, configure the "Isolator Opened 1" and "Isolator Closed 1" settings to the corresponding FCIs of one of the Bricks, and configure the "Isolator Opened 2" and "Isolator Closed 2" settings to FCIs of the other Brick. Set the failsafe settings for all of these FCIs to Off, so if one Brick becomes unavailable, the isolator position reported by the other rules. If both Bricks are available but through race condition or error one is reporting travelling state and other is not, the position of the other, whether open, closed or error, rules. Otherwise, if the two Bricks are reporting different isolator positions, error is detected.

For applications with a single Brick, leave the closed 2 and opened 2 settings set to OFF. For applications where only a single position status contact is used, leave the setting(s) for the opposite contact set to OFF.

With the failsafe settings for all of the FCIs set to Off, if none of the Bricks are available, then the isolator position defaults to the position selected by the isolator failsafe position setting.

Failsafe Position

Range: Closed, Opened, Last Valid

Default: Closed

This setting determines the isolator position assumed by the isolator output operand when the reported Opened and Closed auxiliary contact states are indeterminate (travelling or error). The Last Valid selection uses the last valid isolator state reported as saved in non-volatile memory. All isolators share the same failsafe position setting.

A setting value of Closed is least likely to result in an incorrect trip, but can result in over-tripping in the unlikely event that a bus fault occurs while an isolator position is indeterminate.

Trouble Alarm Delay

Range: 0.0...60.0s in steps of 0.1s

Default: 10.0s

This setting defines the amount of time an isolator position can be in the error or travelling state without trouble being declared. It also defines the amount of time for the trouble declaration to clear following clearing of the travelling/error state. All isolators share the same trouble delay setting.

Configure this time delay to be longer than the maximum expected travelling time of the slowest isolator. Set it short enough so that when trouble occurs because of isolator operation, an alarm can be sent to the operator or control interlocks as required before the operator initiates additional switching.

Events

Range: Enabled, Disabled

Default: Enabled

When enabled, any activation of any of the isolator operands other than the "Any Iso Alarm" operand generates an event in the event record. All isolators share the same events setting.

Actual values

There are two ways to view actual values: in the settings window or the actual values window.


To view information about the isolators in the settings window:

1. In the **Online Window** area of the software, navigate to **Settings > Protection > Isolators**.
2. Click the **Actual Values** field to expand the content.

To view information about the isolators in the actual values window:

1. In the **Online Window** area of the software, navigate to **Actual Values > Protection > Isolators**.

Figure 42: Viewing isolator information



Isolator Closed

Range: On, Off

When the EnerVista software is online, this field indicates the status of the isolator closed operand. This is not a setting.

When the EnerVista software is offline, actual values do not appear.


Isolator Alarm Values

Range: On, Off

When the EnerVista software is online, this field indicates the status of the isolator alarm operand. This is not a setting.

When the EnerVista software is offline, this field does not appear.

Figure 43: Bus source isolator logic diagram



870802A1.vsd



Logic not shown in the block diagram causes the isolator position logic to output the state indicated by the opened inputs if both closed settings are set to OFF, and to output the state indicated by the closed inputs if both opened settings are set to OFF. If all opened and all closed settings are set to OFF, the output state is Off (Opened).

Logic not shown in the block diagram causes the isolator alarm to be blocked when both opened and/or both closed settings be set to OFF.

FlexLogic operands

FLEXLOGIC OPERANDS - ISOLATORS

F/Iso1 Closed:	This operand is asserted when the isolator state is deemed closed.
F/Iso1 Opened :	This operand is asserted when the isolator state is deemed opened.
F/Iso1 Alm On :	This operand is asserted when the isolator's inputs are persistently in the error or travelling position.
F/Iso1 Alm Off :	This operand is asserted when the isolator's inputs are not persistently in the error or travelling position.
F/Iso2 to F/Iso48:	The operands listed above are also available for the other isolator functions.
J :	The operands listed above are also available for the other process cards.
Any Iso Alarm :	This operand is asserted when any of the isolator inputs on any process card are persistently in the error or travelling position.

Multilin B95^{Plus} Bus Protection System

Chapter 9: Digital fault recorder (DFR)

The digital fault recorder captures detailed information regarding abnormal occurrences in the power system. The information captured is stored in the Multilin B95^{Plus} Bus Protection System in non-volatile memory and can be accessed through the front panel interface.

The DFR has the following two primary functions:

- An events recorder that provides a time-stamped record of the operation of breakers, protection elements, and alarms. The recording of events is enabled on a per-element basis.
- A transient recorder that records detailed analog and digital signals for short durations.

Event recorder

The sequence of events recorder provides a time-stamped record of state changes of signals monitored by the B95^{Plus}. These signals can include the state of circuit breakers and disconnect switches, external alarms and indications, and any of the internal functions of the intelligent electronic device (IED). The B95^{Plus} can store a total of 4,096 events on the main card and an additional 4,096 events on each process card. Once the memory is filled, the oldest events are overwritten.

Most B95^{Plus} elements contain an **Events** setting. When this setting is enabled, state changes for FlexLogic operands associated with the element are written to the event recorder. When this setting is disabled, state changes for the element are not recorded.

Viewing records

The event records are viewable on the B95^{Plus} front panel and in the EnerVista software. For the former, you access the digital fault recorder (DFR) page and use the navigation keys to scroll or page through the event list. Two cursors are provided for measurement of the time difference between events.

Figure 1: Event record on the front panel

DFR – SEQUENCE OF EVENTS		
Delta	0 day, 00:00:00.000000	Event# 8194 & 8194
Event#	Date/Time	Cause
8194	Mar 20 2012 13:26:16.806077	PROCESS BUS J8 TRBL
8193	Mar 20 2012 13:26:16.806074	PROCESS BUS J7 TRBL
8192	Mar 20 2012 13:26:16.806071	PROCESS BUS J5 TRBL
8191	Mar 20 2012 13:26:16.806067	PROCESS BUS J4 TRBL
8190	Mar 20 2012 13:26:16.806064	PROCESS BUS J3 TRBL
8189	Mar 20 2012 13:26:16.806053	PROCESS BUS J1 TRBL
8188	Mar 20 2012 13:26:16.755458	FIRMWARE UPGRADED
8187	Mar 20 2012 13:26:16.755458	EVENTS CLEARED
8186	Mar 20 2012 13:26:16.274368	MMVirt Op 2 On
8185	Mar 20 2012 13:26:15.845173	Z5 C Direction

Up Down Refresh LockCursor more >>

To view event records on the B95^{Plus} front panel:

1. Press the **DFR** button below the HMI window.
2. Press the **SOE** button twice below the HMI window.
3. Navigate through the list using the **Up** and **Down** buttons, or press the **More** button and use the **Page Up**, **Page Down**, **Last Event**, and **First Event** buttons. To go back in the menu, press the round **Back** button on the front of the unit.
4. Press the **Refresh** button to update the display.

To view time difference using the lock cursor feature on the B95^{Plus} front panel:


1. Navigate to place the cursor on a record entry.
2. Press the **Lock Cursor** button.
3. Navigate to place the cursor on a second record entry. The Delta line at the top of the window displays the time difference between the two records in days, hours, minutes, seconds, and fractions of seconds.
4. Press the **Lock Cursor** button a second time to unlock.

To view event records in the EnerVista software:

1. In the **Online Window** area, navigate to **Actual Values > DFR > Event Record**.

To view time difference using the lock cursor feature in the EnerVista software:

1. In the **Online Window** area of the software, navigate to **Actual Values > DFR > Event Record**.



2. Click the first required record entry, then the 1 clock button
3. Click the second required record entry, then the 2 clock button.
4. The yellow window beside the buttons displays the time difference between the two records in days, hours, minutes, seconds, and fractions of seconds.

Transient recorder

The transient recorder captures short duration events, such as faults, in detail. Under normal operation, the transient recorder continuously captures pre-trigger data and stores this data in memory. When a trigger is received, the transient recorder captures post-trigger data for the balance of the record. Both the pre-trigger and post-trigger data are stored as records in non-volatile memory within the relay.

The transient recorder captures the instantaneous values, magnitudes, and angles of all enabled voltage source voltages and all enabled bus source currents. Phase-to-ground voltages are captured for voltage sources with the connection setting set to "wye," phase-to-phase voltages with the connection set to "delta."

In addition, the user can configure digital channels, each of which can be used to trigger or retrigger the transient recorder.

A trigger occurs on the activation of any digital channel set to trigger. A trigger produces a record spanning the number of cycles equal to the "basic record length." A retrigger occurs when any digital channel set to retrigger is active (On) at the end of a basic record length. Each retrigger extends the record by an additional basic record length.

The value of the basic record length is dependent on the number of records setting and the sample rate setting. The relay automatically calculates the basic record length based on these user-defined settings and the amount of non-volatile memory allocated for transient records, assuming no retrigger events. The result is displayed on the settings screen, and is shown in the table.

Table 1: Transient record internal storage capacity in cycles

Number of basic records Sample rate	50	40	30	20	10	5	2	1
8 samples/cycle	50	60	80	110	200	350	600	800
16 samples/cycle	35	45	60	90	160	250	500	600
32 samples/cycle	25	30	40	60	100	180	300	400
64 samples/cycle	15	18	25	35	60	100	200	250
128 samples/cycle	8	10	12	20	30	60	100	150


The transient recorder has two storage modes: protected and automatic overwrite. When the memory is filled, either no new records are written to memory (protected mode) or the oldest record is overwritten (automatic overwrite mode).

Settings

To configure transient record settings:

1. In the **Online Window** area of the software, navigate to **Settings > DFR > Transient Record** menu item to open the transient recorder function configuration window.

Figure 2: Transient recorder function settings



The following settings are available.

Function

Range: Enabled, Disabled

Default: Enabled

This setting enables and disables the transient recorder function.

Number Of Basic Records

Range: 1, 2, 5, 10, 20, 30, 40, 50

Default: 40

This setting specifies the total number of basic records that can be stored in the B95^{Plus}. A larger setting results in a shorter record length, and vice-versa. Each retrigger extends the record by one basic record length.

Trigger Mode

Range: Automatic Overwrite, Protected

Default: Automatic Overwrite

When set at "Automatic Overwrite," the oldest record is overwritten once the number of stored records reaches the setting value. When set to "Protected," no new records are stored once the number of records reaches the maximum value.

Trigger Position

Range: 1 to 100% in steps of 1

Default: 50%

This setting specifies the amount of pre-trigger data stored in a record expressed as a percentage of the basic record length.

Maximum Retriggers

Range: 1 to 4 in steps of 1

Default: 2

This setting selects the maximum number of retrigger records that are accepted for an event.

Sample Rate

Range: 8, 16, 32, 64, or 128 samples per cycle

Default: 32

This setting selects the time-resolution of the transient record. A larger setting necessarily results in a shorter record length.

Number Of Cycles Per Record

Range: 1 to 800 cycles in steps of 1

This value is the calculated basic record length for the present number of records setting and the sample rate setting. The trigger position setting is a percentage of this value. It is the length of a record that has no retriggers. It is the amount that a record is extended when a record is retriggered.



NOTE

When changes are made to the transient recorder settings, all existing transient records are cleared. Records are also cleared when any bus source function setting, voltage source setting, or voltage source connection setting is changed.




NOTE

The transient recorder starts collecting data on power up or after the recorder is cleared. When a trigger occurs immediately after a power up or the clearing of transient records, and there is not enough pre-trigger data, the pre-trigger is the amount of data collected and does not reflect the value specified by the setting.

The transient recorder trigger logic diagram follows.

Figure 3: Transient recorder trigger logic diagram



These inputs are defined in the digital channel logic diagrams below.

870033A2.vsd

Transient recorder digital channels

The main card and each installed process card can assign up to 128 of its logic operands to transient recorder digital channels. Each channel can be individually configured.

To configure transient record digital channels:

1. In the **Online Window** area of the software, navigate to **Settings > DFR > Transient Record** menu item to open the transient recorder function configuration window.
2. Click the appropriate **Select** button to open the configuration window.

Figure 4: Digital channel configuration settings for the main card

Main Card Channel	Signals	Trigger
Digital Channel 1	OFF	OFF
Digital Channel 2	OFF	OFF
Digital Channel 3	OFF	OFF
Digital Channel 4	OFF	OFF
Digital Channel 5	OFF	OFF
Digital Channel 6	OFF	OFF
Digital Channel 7	OFF	OFF
Digital Channel 8	OFF	OFF
Digital Channel 9	OFF	OFF
Digital Channel 10	OFF	OFF
Digital Channel 11	OFF	OFF
Digital Channel 12	OFF	OFF
Digital Channel 13	OFF	OFF

The following settings are available for each digital channel.

Digital Channel Signal 1...128

Range: any FlexLogic operand
 Default: Off

Each digital channel signal setting specifies an operand to use as a transient recorder digital channel. Channels set to OFF are not recorded.


Digital Channel Trigger 1...128

Range: Off, Trigger Only, Trigger/Retrigger, Retrigger Only
 Default: Trigger/Retrigger

Each digital channel trigger setting selects the trigger function of the digital channel. When set to "Trigger Only" or "Trigger/Retrigger," the transient recorder captures a record when the state of the channel signal transitions from Off to On. The resulting record contains both pre-trigger and post-trigger data. The channel must return to the Off state before it can generate a subsequent trigger.

When set to "Retrigger Only" or "Trigger/Retrigger," the transient recorder extends the record by one basic record length if at the end of the current record the signal is still asserted and the number of retriggers is less than the value specified by the maximum retriggers setting. The extension contains post-trigger data only.

Figure 5: Digital channel triggering logic diagram



These outputs are used in the trigger logic diagram above. 870030A2.vsd

Viewing records

Transient records are detailed data records for short periods of time. The B95^{Plus} records up to 8,192 details per second to create the transient records. The feature includes the ability to view oscillography waveform traces and digital states in a visual display of power system and relay operation data captured during specific triggered events.


Transient records are viewable on the B95^{Plus} and in the EnerVista software.

On the B95^{Plus}, there is a summary screen that indicates that the transient recorder is ready to capture data and has memory available. There is also a screen listing transient records.

To view the DFR summary on the B95^{Plus}:

1. Press the **DFR** button below the HMI window. To go back in the menu, press the round button on the front of the unit.

Figure 6: Digital fault recorder summary on the B95Plus



The **Ready to Capture** LED is green when all of the following conditions hold:

- The transient recorder is enabled
- The block trigger input is not asserted
- Memory is available or the recorder is in the overwrite mode
- A record capture is not currently in progress

Otherwise the LED is red.

The **Memory Available** LED is green when less than 80% of the memory is filled. It is yellow when the amount of memory filled is between 80% and 99%, and it is red when 100% of the memory is filled.

The transient recorder screen shows the individual records stored on the device. This screen also has an indication of any active triggers (red indication) for the transient recorders.

The user can also force triggering of the recorder from this screen.

To view the transient records on the B95^{Plus} front panel:

1. Press the **DFR** button below the HMI window.
2. Press the **Transients** button below the HMI window.
Clicking the **Force Trigger** button manually triggers and record and increments the count by 1.

Figure 7: Transient record screen on the B95^{Plus}

DFR – TRANSIENT RECORDER	
	Channel Active 
Record	Date
6	Feb 27 2012 10:22:38
5	Feb 27 2012 10:22:36
4	Feb 27 2012 10:22:34
3	Feb 27 2012 10:22:29
2	Feb 27 2012 10:22:23
1	Feb 27 2012 10:22:22

Up	Down	Retrieve	Clear All	Force Trig
----	------	----------	-----------	------------

- Press the **Up** or **Down** button to select a record.

All transient records are erased with a single press of the **Clear All** button.



NOTE



NOTE

The **Retrieve** button is not operational at this time.

To view transient records in the EnerVista software:


- In the **Online Window** area, navigate to **Actual Values > DFR > Transient Record**. Clicking the **Force Trigger** button manually triggers a record and increments the record count by 1.

Figure 8: Transient record summary

Transient Records	
Newest Record Number:	<input type="text" value="1"/>
Available Records In Device:	<input type="text" value="1"/>
Select Record:	<input type="text" value="1"/>
Cycles Per Record:	<input type="text" value="30"/>
<input type="button" value="Force Trigger"/>	
<input type="button" value="Read"/>	<input type="button" value="Cancel"/>

- To view the data, click the **Read** button.

Figure 9: Transient record data



Transient records can also be retrieved in the EnerVista software event record screen by double-clicking the transient record's icon next to the event that generated the record.

FlexLogic operands

FLEXLOGIC OPERANDS - TRANSIENT RECORDER

- Tr Channel Trigger:..... Active for one protection pass when the transient recorder is triggered.
- Tr Channel Retrigger:..... Active for one protection pass when the transient recorder is retriggered.
- TR Channel Active:..... Active when any digital or analog channel is active.
- Tr Retriggers = Max: Activated when the number of retriggered records has reached the Maximum Retriggers setting. Reset on the next trigger.

Multilin B95^{Plus} Bus Protection System


Chapter 10: Front panel

This chapter explains how to use features on the B95^{Plus} front panel. The Event Recorder and Transient Recorder are documented earlier in this document, for example.

Front panel overview

The front panel of the Multilin B95^{Plus} Bus Protection System provides a color LCD annunciator alarm panel functionality with a second LCD display for front panel HMI functions that include user configurable metering pages and access to the digital fault recorder. The keys/button below each display are used for navigation and those at the sides are unused.

Figure 1: Front panel



Status LED

A status LED on the upper left-hand corner of the front panel shows the in-service status and test mode of the relay. Red indicates that the relay outputs are blocked, and green indicates normal conditions. Details are outlined in the table. In cases where multiple conditions are present, the first listed in the table controls the LED.

Table 1: LED Status

LED State	Condition	Outputs Blocked
Off	Relay power off	Yes
Off	Front panel power off	Unknown
Flashing green	Front panel powering up	Unknown
Solid orange	Front panel not communicating with relay	Unknown
Solid red	Any major self-test	Yes
Flashing red	Test mode is test-isolated	Yes
Flashing orange	Test mode is test-forcible	No
Solid green	Any minor self-test	No
Solid green	None of the above. Relay status is normal and in service.	No

Annunciator panel

The annunciator is the color panel on the left side of the unit. It emulates the functionality found in a conventional annunciator unit. It provides indications on the status of system alarm points and actual values. It also displays self-test messages and product information for the unit.

Operation

The annunciator display consists of multiple pages, each a matrix of indicators. The indicators are configurable as alarms and/or actual values.


The annunciator supports three types of alarms: self-reset, latched, and acknowledgeable. Each indicator can be configured to be one of the three alarm types and can also display an optional metered actual value. The value of each self-reset alarm is refreshed approximately every half second.

Alarms are organized in a table and numbered increasing from left to right and then top to bottom. The first location in the top left corner of the first page is denoted as indicator 1 by the EnerVista software. The top left location of the next page is the bottom right location's indicator number on the previous page plus one. Up to 288 individual alarms or metered values can be configured.

Each location in the alarm table can be configured as an alarm only, metering only, or mixed content. With the exception of metering only table entries, a FlexLogic input operand is required for each alarm table location. Selecting the OFF operand of an alarm indicator blanks out the indicator text.

Indicators can display up to three lines of text using a specified foreground and background color. A configured metering value replaces the specified line of text. The following figure shows a typical annunciator display.

Figure 2: Typical annunciator display




There are control buttons at the bottom of the display.

- The Next Page button cycles through the pages of indicators and to the info pages.
- The Next Alarm button cycles through the active alarms, paging as required.
- The Ack button acknowledges all alarms on the displayed page.
- The Reset button resets any latched alarms on the displayed page.

The annunciator alarm sequence conforms to ISA 18.1-1979 (R1992) standard, type R.

Figure 3: Annunciator alarm sequence



870754A2.CDR

The annunciator states are described in the following table.

Table 2: Acknowledgeable alarm states

Sequence (initial state)	Process (status)	Pushbutton (input)	Sequence (final state)	Visual indication
Normal	Normal	N/A	N/A	Off
Normal	Abnormal	N/A	Alarm	Fast flash
Alarm	Normal	N/A	Alarm	Fast flash
Alarm	Normal	Acknowledged	Normal	Off
Alarm	Abnormal	Acknowledged	Acknowledged	On
Acknowledged	Abnormal	N/A	Acknowledged	On
Acknowledged	Normal	N/A	Ringback	Slow flash
Ringback	Normal	Reset	Normal	Off
Ringback	Abnormal	N/A	Acknowledged	On

In the event of an alarm, the page containing the alarm is promoted to active page. If there are multiple pages with alarms, the page with the lowest page number is promoted.


If there are alarms on multiple pages, and alarms on some pages have already been acknowledged (but not cleared) by the user, then the pages with active alarms move ahead of the pages that have acknowledged alarms. The user has to navigate through the pages of alarms to view them.

Settings

To configure the annunciator display:

1. In the **Online Window** area of the software, navigate to **Settings > Front Panel > Annunciator** to open the annunciator configuration page.

Figure 4: Configuring annunciator settings



The following settings are available. The settings descriptions apply to all 288 alarms.

Clear Latched

Range: any FlexLogic operand or shared operand

Default: OFF

This setting allows the user to designate a B95^{Plus} operand to clear all the latched alarms when the operand transitions to an active state. For example, a central station HMI can simultaneously clear all IED alarms remotely by assigning this value to a virtual input.

Layout and Navigation

Range: 3 × 4, 4 × 6, 6 × 8

Default: 3 × 4

This setting specifies the number of indicators shown per page. This setting applies globally to all annunciator pages. For example, if “4 × 6” is selected, then 288 indicators can be displayed on 12 pages. Note that annunciator pages that do not contain at least one configured indicator are automatically hidden.

Content

Range: Actual, Alarm, Mixed

Default: Alarm

This setting specifies if the corresponding indicator consists of a single metered value (set to “Actual”), contains a single alarm indication (set to “Alarm”), or contains both a metered value and an alarm indication (set to “Mixed”).

For details on configuring the alarm when **Content** is set to “Actual” or “Mixed,” see [Metering values](#) on page 194.

Alarm Input

Range: any FlexLogic operand or shared operand

Default: Off

This setting specifies the input signal connected to the alarm.

Alarm Type

Range: Acknowledgeable, Latched, Self-Reset

Default: Acknowledgeable

This setting specifies the alarm type. Self-reset alarms track the state of the corresponding input operand. Latched alarms can be reset using the Ack/Reset button at the bottom of the display. Acknowledgeable alarms follow the state transitions listed in the previous section.

Text (Line 1), Text (Line 2), Text (Line 3)

Range: up to 10 characters

Default: blank

These settings specify the displayed text on the corresponding line in the alarm indicator. Three lines can be displayed if the page layout is 3 × 4 or 4 × 6. For 6 × 8 layouts, only the first two lines are displayed. Note that a specified metering value replaces the text for the selected line.

Text Color

Range: Black, Red, Yellow, Blue, Green, Teal, Purple, White, Dark Red, Dark Yellow, Dark Blue, Dark Green, Dark Teal, Dark Purple, Grey

Default: White

This setting specifies the color of the indicator text.

Back Color

Range: Black, Red, Yellow, Blue, Green, Teal, Purple, White, Dark Red, Dark Yellow, Dark Blue, Dark Green, Dark Teal, Dark Purple, Grey


Default: Red

This setting specifies the color of the alarm indicator background when in the alarm state. For Actual indicators, specifies the static background color.

The **Preview** button displays a static image of the front panel alarm page (as it appears when active) so that the user can verify the layout and color of the indicators.

The **Navigation** button allows the user to specify which annunciator page displays. Deselect the **Use Default** check box to customize.

Figure 5: Annunciator navigation dialog



When the **Use Default** check box is selected and the **Default Page** is set to “None,” selection of the alarm page to display follows the following sequence:

- In the event of a new alarm, the page containing the alarm is promoted to the active page. If there are multiple pages with alarms, the lowest numbered page is promoted.
- If there are alarms on multiple pages, and alarms on some pages have already been acknowledged but not reset by the user, then the lowest numbered page with an alarm is promoted above any page that has an acknowledged alarm.

When the **Use Default** check box is not selected, when the first alarm in the **Condition** column is active, the page selected in the **Activate Page** column is promoted.

The **Default Page** menu item allows the user to select the page that is displayed after the user-specified period of inactivity has elapsed.

Metering values

The following dialog box displays when the **Configure** button is pressed for metered value indicators. Use it to configure metering values.

Figure 6: Metering value properties

The following settings are available.

Parameter

Range: any FlexAnalog parameter

Default: Active settings group

This setting selects a FlexAnalog parameter that specifies the metered value to display in the annunciator alarm.

Units

Range: up to 4 characters

Default: ---

This setting specifies a four-character string that is used in the annunciator display of the corresponding metered value.

Scale Factor

Range: None, k (kilo)

Default: None

This setting allows the user to specify the scaling factor for the metering units value.

Multiplier

Range: dependent on selected analog value

Default: 1.0

This setting allows the user to specify a multiplier for the metering parameter value. The range is restricted to correspond to the selected actual value parameter.

Number of Decimals

Range: 1 to 10 in steps of 1

Default: 3

This setting specifies the number of digits displayed to the right of the decimal in the analog value.

Display in Line

Range: 1, 2, 3

Default: 1

This setting specifies which line in the annunciator alarm to display the metered value. It can be displayed in lines 1, 2, or 3 if the page layout is 3 x 4 or 4 x 6. For 6 x 8 layouts, it can only be displayed in lines 1 or 2.

Self-test summary display operation

All self-test activations are recorded in the digital fault recorder (DFR) events record. Self-tests in the alarm state are displayed on the front panel and in the EnerVista software.

In addition, major self-tests alarms result in the following:

- The critical fail relay on the power supply card is de-energized.
- All field contact outputs and shared outputs are de-activated and prevented from operating the actual Brick contact outputs or shared I/O. This does not prevent other relays connected to a Brick from operating the Brick's contacts and shared I/O.
- Protection element operands revert to the state they are in when the element is disabled. Events are not generated for operands changing state due to major self-test activation.
- The front panel LED, located above the annunciator, is solid red.
- A RELAY OUT OF SERVICE event is recorded.

Self-tests in alarm are displayed on the front panel as follows:

- All pages of the front panel annunciator show the number of self-test ("Tests") that are at present in alarm state (alarmed) in the lower left hand corner. When one or more self-tests are alarmed, repeatedly pressing the annunciator Next Page button cycles through the various annunciator pages until the self-test summary page is reached. The self-test summary page displays the title of each alarmed self-test, including the date and time it alarmed. A red block on the left side indicates a major self-test; a yellow block indicates a minor self-test.

Up and Down buttons allow scrolling through the alarmed self-tests. A Detail button displays information on the selected self-test. If the detailed self-test is one that latches transient activations until manually acknowledged, an annunciator button on the self-test detail page displays Ack. Pressing it clears the latch provided that the initiating condition has cleared.


Bus diagram operation

The bus source diagrams created with the Bus Sources Template Editor are viewable on the HMI panel of the B95^{Plus}. Configuration is required (next sections).

To view the bus sources on the B95^{Plus} front panel:

1. Press the **Diagram** button below the HMI panel.
2. Press the **Next Bus/Src** button to view the bus sources in sequence. The unit skips over disabled bus sources. Use the **Prev Bus/Src** to go back.

Figure 7: Bus source displayed on unit




Bus source template editor

A mimic diagram is a representation of a circuit, in this case of a bus source. Rather than creating a unique mimic diagram for each bus source, with the B95^{Plus} you create a small number of templates. The dynamic components in a template, a breaker for instance, rather than representing a specific breaker, represent the breaker of the bus source currently on display. As you scroll through the bus sources on the front panel as described in the previous section, the status of the single template breaker is automatically relinked to successive bus source breakers. Where the Breaker Open settings are both selected to the OFF operand, indication that there is no dynamic status available for that breaker, the breaker symbol is not displayed. Otherwise, the breaker symbol displays as open or closed according to the present status of the bus source's Bkr Open operand. Template isolators operate similarly, but using the operand selected by the bus source's Z# Connection setting.

Three templates are provided to allow mimic diagrams for three types of bus source. Set each bus source's "HMI Template" setting to the number of the template appropriate for that bus source.


Use the Bus Source Template Editor to create templates for single line diagrams (mimic diagrams) for the front panel display. You draw templates for these diagrams in the EnerVista software, typically starting with one of the predefined bus source template files, which are outlined later.

Figure 8: Creating a mimic diagram in the Bus Source Template Editor



A components library is included in the EnerVista software. It includes dynamic power components, static power components, and text blocks.

Figure 9: Mimic diagram components library



The following functions are available. Placing the cursor over the box in the software displays its function. Boxes grey-out are not selectable.

- Isolators
- Disconnect and earthing switches
- Busbars
- Transformers
- Capacitor banks
- Reactors
- CTs and VTs
- Transmission lines
- Grounding

The circuit breakers, isolators, and bypass switches can be configured to automatically display the actual status of these devices. All other devices are static. As such, they are used for information only and cannot dynamically change states.

To create a mimic diagram:

1. In the **Online Window** area of the software, navigate to **Settings > Front Panel > Bus Source Template Editor** to open the mimic diagram editing window.
2. Click a block on the right side, then click in the diagram window to place the component in the diagram.
3. Double-click the component to configure it, for example to rotate a breaker from horizontal to vertical position.

The following sections provide more detail on using the editor.

Dynamic symbols

The following dynamic symbols are available. The symbols can be displayed in the standard B95^{Plus} and UR^{Plus}-series format or as IEC style symbols.


Figure 10: Mimic diagram editor dynamic symbols

Components	Symbols		Notes
	Standard	IEC	
Circuit breakers in the open position			 : Only this symbol is defined in the IEC standard; the others are created
Circuit breakers in the closed position			Created symbols
Switches in the open position			 : Only this symbol is defined in the IEC standard; the others are created
Switches in the closed position			Created symbols

870860A4.CDR

Double-clicking a dynamic symbol allows configuration. For a breaker symbol, adjust its orientation or color scheme. For an isolator, set which of the six zone connections or bypass connection it represents for the selected bus source. The orientation and color scheme are similarly set.


Figure 11: Isolator configuration



Static symbols

The following static symbols are available. The symbols can be displayed in the standard B95^{Plus} and UR^{Plus}-series format or as IEC style symbols.

Figure 12: Mimic diagram editor static symbols


Components	Symbols	
	Standard	IEC
Transformer		
Autotransformer		
Transformer with tap changer		
Autotransformer with tap changer		
Capacitor bank		
Reactor		
VT		
CT		
Grounding		
Busbar and transmission lines		

870861A2.CDR

For more information on these symbols, see the ANSI/IEEE 315A and IEC 617 standards. There is no limit on the number of static symbols per screen, provided that they fit within the screen dimensions.

Double-clicking a static symbol and selecting **Properties** allows the user to specify the orientation of the device. The name of a static device cannot be changed. For example, the figure shows the transformer properties window.

Figure 13: Transformer properties device configuration



Pre-configured mimic diagrams

The EnerVista software contains a library of pre-configured mimic diagram templates that can be loaded into the template editor.

To load a pre-configured set of mimic diagram templates:

1. Click the **Load** button at the top of the window.
2. Select the file and click **Open**. All three of the templates (displayed in tabs) are replaced using the selected file.

Metering summary

This feature allows you to display voltage and currents on the HMI panel of the B95^{Plus}. You configure the display in the software, then view it on the B95^{Plus}. These actions are presented in reverse order here.


To view the metering summary on the B95^{Plus} front panel:

1. Press the **Metering** button below the HMI display.
2. Press the **Page** buttons to view successive pages.

METERING – SUMMARY PAGE 1			
Phase AB	Phase BC	Phase CA	
0.000 V			V
Phase A	Phase B	Phase C	
0.000 A			A

Page <» Phasors


Figure 14: Metering summary configuration



To configure the editor:

1. In the **Online Window** area of the software, navigate to **Settings > Front Panel > Metering Summary Editor** to open the metering configuration window.
2. Click a metering location button, to open the configuration window (see figure). Enter header text of a selected font size and color, or select a metered quantity from the drop-down list. A metered quantity can be a system voltage, current, or zone for any configured source.

Figure 15: Metering configuration window



Text

Range: up to 20 characters

Default: ---

This setting defines the selected metering cell as a text box. These are typically used as headings. Specify up to 10 characters.

Parameter

Range: any FlexAnalog parameter

Default: Ia Mag of the first source

This setting selects a FlexAnalog parameter that specifies the metered value to display in the metering cell.

Units

Range: up to 4 characters

Default: ---

This setting specifies a four-character string that is used in the metering cell display for the corresponding metered value.

Scale Factor

Range: k (kilo), None

Default: None

This setting allows the user to select a scaling factor for displayed metered value.

Multiplier*Range: dependent on selected analog value**Default: ---*

This setting allows the user to specify a multiplier for the metering parameter value if the scaling factor is set to "None." The range is restricted to correspond to the selected actual value parameter.

Number of Integers*Range: 1 to 6 in steps of 1**Default: 1*

This setting specifies the number of integers in the displayed metering cell. Leave it at the default value.

Number of Decimals*Range: 1 to 6 in steps of 1**Default: 3*

This setting specifies the number of digits displayed to the right of the decimal in the metering cell.

Font Size*Range: 8, 10, 12**Default: 10*

This setting specifies the font size to use for the displayed metering cell.

Text Color*Range: available system colors**Default: Black*

This setting specifies the text color to use for the foreground text in the displayed metering cell.

Background Color*Range: available system colors**Default: White*

This setting specifies the color to use in the background for the displayed metering cell.


Display properties

This feature allows you to specify a timeout value to return the HMI display to its first page.

To configure the HMI panel timeout:

1. In the **Online Window** area of the software, navigate to **Settings > Front Panel > Display Properties**.
2. Specify the time in minutes in the field.

Figure 16: HMI default page timing configuration



Default Front Panel Timeout

Range:
 Default: 60 min

This setting specifies the amount of time in minutes before the HMI display returns to its first page.

Phasor display

This feature allows the display of voltages and bus sources on the HMI display of the front panel. You simply view the phasor diagrams; there are no settings to configure. The bus zone differential currents and bus zone restraint currents can also be displayed.

To view phasor diagrams on the B95^{Plus}:


1. Press the **Metering** button below the HMI display.
2. Press the **Phasors** button below the HMI display.
3. To view voltages, press the **Voltages** button.
 To view the bus sources, press the **Currents** button.
 To view the zone **Differential** or zone **Restraint** currents, press those buttons.

When a voltage source, bus sources, or bus zone ID is configured, its ID displays over the phasor diagram. When the ID is not configured, the source or zone designation displays, such as F/VS1, F/Src1, Z1.

Only the enabled sources display.

4. To display the next diagram, press the same button again, for example **Voltages**. To go back, press the **Previous** button.

Figure 17: Bus source (Currents) phasor diagram



Multilin B95^{Plus} Bus Protection System

Chapter 11: Security

This chapter explains how to use the Multilin B95^{Plus} Bus Protection System security features, meaning set user access and passwords. User accounts can be added in the software, and passwords can be used to control local and remote access to the unit.

User and password management


An Administrator account is added by default in the EnerVista software. The default Administrator password is "B95plus," though its entry is not required by default.

You can manage user accounts and access. As shown, access can be controlled to actual values (data), settings, commands, even recorder, FlexLogic equations, general information, and administration. The default password for user accounts is "password."

Password requirement can be enabled and disabled.

This section outlines how to add user accounts, requiring password entry, and changing the password for the account logged in.

Figure 1: Adding user accounts, managing access, and password requirement



To add a user account:

1. In the EnerVista software, select **Security > User Management** from the top menu.
2. Click a blank field in the **User** column.
3. Type the user name and enable the access level check boxes. The security levels are explained at the end of the section.
4. Click **OK**.

To require password entry:

1. In the EnerVista software, select **Security > User Management** from the top menu.
2. Enable the **Enable Security** check box.
3. Click **OK**.



If you force password entry by using this feature, ensure that you know the Administrator password (default is "B95plus"). Otherwise, you can be locked out of the software.

To change the password of the account logged in:

1. In the EnerVista software, select **Security > Change Password** from the top menu.

The security levels are explained as follows.

Settings

The setting access level allows the user to make any changes to any of the setting values and operate in test mode.

Commands

The command access level restricts the user from making any settings changes, but allows the user to perform the following operations:

- Change the state of virtual inputs
- Clear event records
- Clear oscillography records
- Change the system date and time

Local and remote passwords

Passwords can be changed in the software (previous section) and set for local and remote access to the B95^{Plus} (this section).

The B95^{Plus} supports password entry from a local or remote connection. Local access is using the faceplate interface, by keypad entry or USB connection. Remote access is defined as access using a rear Ethernet port. Any changes to the local or remote passwords enables this functionality.

When entering a settings or command password, the user must enter the corresponding password level shown in the table.

Table 1: Required password levels by connection type

Connection type	Password required
Front panel or USB	Local
Rear Ethernet port	Remote

To configure local and remote password settings:

1. In the **Online Window** area of the software, navigate to **Settings > Security > Password Security** to open the password security settings window.

Figure 2: Password security configuration settings

PARAMETER	ENCRYPTED PASSWORD	ENTER NEW PASSWORD	CONFIRM NEW PASSWORD	CHANGE PASSWORD
Local Command Password Setting	0:0:0			Change
Local Setting Password Setting	0:0:0			Change
Remote Command Password Setting	0:0:0			Change
Remote Setting Password Setting	0:0:0			Change
Command Password Access Timeout	5 min			
Setting Password Access Timeout	30 min			
Invalid Password Attempts	3			
Password Lockout Duration	5 min			
Password Access Events	Enabled			
Local Setting Auth	ON			
Remote Setting Auth	ON			
Access Auth Timeout	30 min			

Passwords can consist of up to 12 alphanumeric characters, excluding all non-printing characters and the following:

“ ` ” (ASCII code 60), “ \ ” (ASCII code 92), “ / ” (ASCII code 47), and “ | ” (ASCII code 124)

The password cannot be programmed as “0.”

The following settings are available. See the previous section for the difference between command and setting password types.

Local Command Password Setting

Range: up to 12 visible ASCII characters (see restrictions above)

Default: null

The value of the local command password is specified here. For the password to be successfully entered, the values in the **Enter New Password** and **Confirm New Password** fields must be identical.

If an entered password is lost (or forgotten), consult the factory with the corresponding **Encrypted Password** value.

Local Setting Password Setting

Range: up to 12 visible ASCII characters (see restrictions above)

Default: null

The value of the local setting password is specified here. For the password to be successfully entered, the values in the **Enter New Password** and **Confirm New Password** fields must be identical.

If an entered password is lost (or forgotten), consult the factory with the corresponding **Encrypted Password** value.

Remote Command Password Setting

Range: up to 12 visible ASCII characters (see restrictions above)

Default: null

The value of the remote command password is specified here. For the password to be successfully entered, the values in the **Enter New Password** and **Confirm New Password** fields must be identical.

If an entered password is lost (or forgotten), consult the factory with the corresponding **Encrypted Password** value.

Remote Setting Password Setting

Range: up to 12 visible ASCII characters (see restrictions above)

Default: null

The value of the remote setting password is specified here. For the password to be successfully entered, the values in the **Enter New Password** and **Confirm New Password** fields must be identical.

If an entered password is lost (or forgotten), consult the factory with the corresponding **Encrypted Password** value.

The access supervision settings allow the user to specify the length of inactivity required before returning to the restricted access level. The following access supervision settings are available.

Command Password Access Timeout

Range: 5 to 480 minutes in steps of 1

Default: 5 minutes

This setting specifies the length of inactivity (no local or remote access) required to return to restricted access from the command password level.

Setting Password Access Timeout

Range: 5 to 480 minutes in steps of 1

Default: 30 minutes

This setting specifies the length of inactivity (no local or remote access) required to return to restricted access from the setting password level.

Invalid Password Attempts

Range: 2 to 5 in steps of 1

Default: 3

This setting specifies the number of times an incorrect password can be entered within a three-minute time span before lockout occurs and applies to both the setting and command passwords.

When lockout occurs for the command password level, the **ACCESS LOC CMND DENY** and **ACCESS REM CMND DENY** communication operands are set to "On." These operands are returned to the "Off" state upon expiration of the lockout. Likewise, when lockout occurs for the setting password level, the **ACCESS LOC SETG DENY** and **ACCESS REM SETG DENY** communication operands are set to "On." These operands are also returned to the "Off" state upon expiration of the lockout.

Password Lockout Duration

Range: 5 to 60 minutes in steps of 1

Default: 5 minutes

This setting specifies the time that the B95^{Plus} locks out command password access after the number of invalid password entries specified by the **Invalid Password Attempts** setting have occurred.

Password Access Events

Range: Enabled, Disabled

Default: Disabled

This setting enables and disables the logging of password access supervision events in the sequence of events recorder.

The dual permission security access feature provides a mechanism for customers to prevent unauthorized or unintended upload of settings to a device through the local or remote interfaces. The following dual permission security access settings are available.

Local Setting Auth*Range: selected operands**Default: ON*

This setting is used for local (front panel USB) setting access supervision. Valid operand values are either "ON" (default) or any physical contact input value.

If this setting is "ON," then local setting access functions as normal; that is, a local setting password is required. If this setting value is any contact input operand, then the operand must be asserted (set as on) prior to providing the local setting password to gain setting access.

Remote Setting Auth*Range: any operand**Default: ON*

This setting is used for remote (Ethernet) setting access supervision.

If this setting is "ON" (the default setting), then remote setting access functions as normal; that is, a remote password is required. If this setting is "OFF," then remote setting access is blocked even if the correct remote setting password is provided. If this setting is any other operand, then the operand must be asserted (set as on) prior to providing the remote setting password to gain setting access.

Access Auth Timeout*Range: 5 to 480 minutes in steps of 1**Default: 30 minutes*

This setting specifies the timeout delay for setting access. This setting is applicable when the [Local Setting Authorization](#) or [Remote Setting Authorization](#) settings are programmed to any operand except "ON" or "OFF." The states of any selected operands are continuously monitored for an off-to-on transition. When this occurs, setting access is permitted and the timer programmed with this setting value is started. When this timer expires, setting access is immediately denied. If access is permitted and an off-to-on transition of the selected operand is detected, the timeout is restarted. The status of this timer is updated every five seconds.

Password Access Events*Range: Enabled, Disabled**Default: Disabled*

This setting enables and disables the logging of dual permission security access events in the event recorder.

Access alarms

In the event that an incorrect command or setting password has been entered three times within a three-minute time span (default), the [ACCESS DENIED](#) operand is asserted and the B95^{Plus} disallows setting or command access for the set Password Lockout Duration. The operand is de-asserted after expiry of the five minute timeout.

The B95^{Plus} provides a means to raise an alarm upon failed password entry. When password verification fails while accessing a password-protected level of the relay (either settings or commands), the [UNAUTHORIZED ACCESS](#) operand is asserted. The operand can be programmed to raise an alarm via contact outputs or communications. This feature can be used to protect against both unauthorized and accidental access attempts. Therefore, to apply this feature with security, the command level needs to be password-protected. The operand does not generate events.

Multilin B95^{Plus} Bus Protection System

Chapter 12: Configure FlexOperands

The names of some FlexLogic operands can be changed.


Configure FlexOperands

At most 1024 operands can be renamed.

To change the name of a FlexLogic operand:

1. In the **Online Window** area of the software, navigate to **Settings > Configure FlexOperands** to open the user-configurable operands window.

Figure 1: User-configurable protection FlexLogic operands window



The left side of this screen displays all operands that are currently available for renaming in the B95^{Plus}. Displayed operands can be renamed with a user-specified value to provide additional information or match specific applications.

User Configured Event Name

Range: up to 20 characters

Default: ---

Each available FlexLogic operand can be renamed to a user-specified value. This feature allows users to rename operands to allow for clearer identification or to match specific applications. The new operand name appears in settings that take operands as their value, and in event reports. These settings take effect when the B95^{Plus} is restarted.

Multilin B95^{Plus} Bus Protection System

Chapter 13: Product information

This chapter outlines how to view the serial number of the unit. Viewing the order code, settings file information, and changing the unit name are outlined elsewhere.

Serial number

There are three ways to view the serial number: on the back of the unit; on the annunciator display; and in the EnerVista software.

To view the serial number on the B95^{Plus}:

1. Look for the bar code sticker on the back of the unit. Or page down on the annunciator display on the front of the unit to the product information page to view the number.

To view the serial number in the EnerVista software:

1. In the **Online Window** area, navigate to **Actual Values > Product Information > Model Information**.

Multilin B95^{Plus} Bus Protection System

Chapter 14: Maintenance

This chapter describes testing and general maintenance, including setting the date and time.

Test mode

The B95^{Plus} provides test settings to verify functionality using simulated conditions for contact inputs and outputs. To initiate the test mode, you set the **Test Mode Function** to Isolated or Forcible.


Test mode can be in any of following three states:

- **Disabled** — Relay operation is normal. The test features are disabled.
- **Isolated** — The relay is prevented from performing control actions (for example, tripping) via the process bus. The test bit accompanying shared I/O outputs and GOOSE messages is set on, which signals recipients to take no action other than logging changes of logic state, unless they too are in a test mode other than disabled.
- **Forcible** — The process bus configuration locking feature is suppressed so that the relay operates with substitute Bricks. The test bit operates as described for the isolated mode.

To access test settings in the software:

1. In the **Online Window** area, navigate to **Maintenance > Testing**.
2. To initiate test mode through the B95^{Plus} settings, set the **Test Mode Function** to Forcible or Isolated.

Figure 1: Running the unit in test mode



The test mode state is indicated on the relay faceplate by a flashing LED indicator and by the critical fail relay, as shown in the table.

Table 1: Test mode state

Test Mode	Front Panel LED	Critical Fail Relay	Configuration Locking	Test Bit	I/O Behavior
Disabled		Normal	Locked	Sent Off	Normal
Isolated	Flashing red	De-energized	Locked	Sent On	Contact Outputs Disabled
Forcible	Flashing orange	De-energized	Unlocked	Sent On	Normal

The Test Mode Function can only be changed by direct user command and only when in the setting security access level. Following a restart or on power up, and following settings upload or firmware upgrade, the state is as last selected by the user. This is so that a user that has placed the relay in isolated mode can rely on the relay to stay isolated during test and/or maintenance activities.

When the relay test mode is Isolated, all FCO and FLO output commands are forced to Off. When the relay test mode is Isolated or Forcible, unlike FCOs, all shared output (SO) commands continue to operate normally. However, the outgoing test bit is set On, which prevents the associated shared input operands from responding unless the receiving relay's test mode is either isolated or forcible.

GOOSE implements the test bit in transmitted messages: Outgoing messages set the test bit if the test mode is Isolated or Forcible. Test bits in incoming GOOSE messages are ignored.

Self-tests

The B95^{Plus} performs a number of self-test diagnostic checks to verify relay integrity. There are two types of tests: major and minor. They are itemized separately in the following sections.

All self-text activations are recorded in the digital fault recorder (DFR). Self-tests in the alarm state are displayed on the front panel and in the EnerVista software.


Major self-tests alarms result in the following:

- The critical fail relay on the power supply card is de-energized.
- All field contact outputs and shared outputs are de-activated and prevented from operating the actual Brick contact outputs or shared I/O. This does not prevent other relays connected to a Brick from operating the Brick's contacts and shared I/O.
- Protection element operands revert to the state they are in when the element is disabled. Events are not generated for operands changing state due to major self-test activation.
- The front panel LED, located above the annunciator, is solid red. See the Status LED section in the Front Panel chapter for information on LED status.
- A RELAY OUT OF SERVICE event is recorded.

To view the self-test summary:

1. In the **Online Window** area of the software, navigate to **Actual Values > Front Panel > Self Test**. The alarmed self-tests can be viewed and acknowledged. Clicking an **Acknowledge** button removes the item from the display.

Figure 2: Self-test results displayed in the software



Each self-test has a logic operand containing the status of the self-test for use in communication protocols, FlexLogic, or wherever a logic operand can be used. There is also an ANY MAJOR ERROR operand that is active when any major self-test operand is active, an ANY MINOR ERROR operand when any minor self-test operand is active, and an ANY SELF-TESTS operand when any self-test operand is active.

It is recommended that communication messages where invalid message content can result in undesired tripping by the subscribers be configured to include the ANY MAJOR ERROR operand status. Subscribers need to be configured to handle the message content as of questionable validity when the received ANY MAJOR ERROR status is On.

All major self-test alarms are reported automatically with their corresponding FlexLogic operands. If wanted, most of the minor alarms can be disabled as described in the User Programmable Self-Tests section in the Settings - General chapter.

Major self-tests

This section outlines major self-tests. For the self-tests, the ellipsis symbol (...) indicates that there is a similar self-test for each one of the items in the range. For example Brick F1...8 Trouble indicates there are eight similar self-tests: Brick F1 Trouble, Brick F2 Trouble, and so on to Brick F8 Trouble.

COMMS CARD TRBL

Description: The communications card is not fully operational.

Severity: Communications may be compromised both on communications card ports and on main card ports.

The critical failure relay is de-energized.

All field contact outputs and shared outputs are disabled.

Protection is not available.

Actions: If the alarm does not clear when acknowledged, cycle relay control power. If the condition persists, contact GE Digital Energy.

CONFIGURBLE SELF-TEST

Description: The logic operand selected by the **Settings > General > User Programmable Self-Test > Configurable Self-Test** setting is On.

Severity: Condition detected by user programming is present.

Critical failure relay is de-energized.

All field contact outputs and shared outputs are disabled.

Protection is not available.

Actions: Correct the condition detected by the operand selected for this self-test.

EQUIPMENT MISMATCH

Description: The order code stored in the CPU main card does not match the cards or front panel installed.

Severity: Critical failure relay is de-energized.
All field contact outputs and shared outputs are disabled.
Communications services are likely affected.
Protection is not available.

Actions: Check that all cards are installed properly and according to the order code, then cycle control power. If the condition persists, contact GE Digital Energy.

MAIN CARD TRBL

Description: The CPU main card is not fully operational.

Severity: Critical failure relay is de-energized.
All field contact outputs and shared outputs are disabled.
Communications services are likely affected.
Protection is not available.

Actions: Cycle relay control power. If the condition persists, contact GE Digital Energy.

PROCESS CARD F TRBL

Description: The process card is not fully operational.

Severity: Critical failure relay is de-energized.
All field contact outputs and shared outputs are disabled.
Communications services are likely affected.
Protection is not available.

Actions: Cycle relay control power. If the condition persists, contact GE Digital Energy.

PROCESS CARD J TRBL

Description: The process card is not fully operational.

Severity: Critical failure relay is de-energized.
All field contact outputs and shared outputs are disabled.
Communications services are likely affected.
Protection is not available.

Actions: Cycle relay control power. If the condition persists, contact GE Digital Energy.

UNIT NOT PROGRAMMED

Description: The setting **General > Installation > Relay Settings** is set to Not Programmed. This setting is accessible when online with the relay.

Severity: Critical failure relay is de-energized.
All field contact outputs and shared outputs are disabled.
Protection is not available.

Actions: When the relay is ready for service, or when the relay outputs are isolated, go online with the relay and change the **Settings > General > Installation > Relay Settings** to Programmed

Minor self-tests

This section outlines the minor self-tests. For information on disabling them, see the User-Programmable Self-Tests section earlier in the document.

BRICK F1...F8 TROUBLE

Description: Brick internal self-testing has detected a trouble internal to the Brick.

Severity: Some or all of the affected Brick inputs and outputs may not be accessible.

Actions: Ensure Brick auxiliary power supply voltage is correct. Ensure the Brick temperature environment is within specifications. Troubles resulting from a Brick output failing to respond to an output command can only be detected while the command is active; clearance of the self-test when the initiating command has ended and then acknowledged does not imply a contact output failure has cleared.

BRICK J1...J8 TROUBLE

Description: Brick internal self-testing has detected a trouble internal to the Brick.

Severity: Some or all of the affected Brick inputs and outputs may not be accessible.

Actions: Ensure Brick auxiliary power supply voltage is correct. Ensure the Brick temperature environment is within specifications. Troubles resulting from a Brick output failing to respond to an output command can only be detected while the command is active; clearance of the self-test when the initiating command has ended and then acknowledged does not imply a contact output failure has cleared.

CONTACT CHATTER

Description: Contact chatter is being detected.

Severity: Affected field contact input operands are forced to their failsafe states.

Actions: Correct any abnormal chattering of the initiating input. If the contact input behavior was normal, revise the **Remote Resources > Field Contact Inputs Chatter Detection** settings.

CROSSCHECKING ERROR

Description: The relay has detected a discrepancy between the measured values of redundant ac current origins of a bus source or between redundant AC voltage origins of a voltage source.

Severity: The relay continues to use the origin 1 quantities of the discrepant pair.

Actions: Ensure that both origin Bricks have the same ac currents/voltages on the same inputs. Where both have the same inputs, replace the Brick where the EnerVista B95^{Plus} Setup's raw data viewer (**Maintenance > Raw Data Viewer > Process Card > Field Unit > Analog Inputs**) does not match the actual ac input currents/voltages.

ETH PORT 1...3 FAILURE

Description: No signal is being received on Ethernet Port 1..3.

Severity: Ethernet communication over Port 1..3 is unavailable.

Actions: Ensure the device connected to the Ethernet port is operational and that the cable is correct and intact.

HIGH TEMPERATURE

Description: The temperature inside the relay is above design limits.

Severity: The relay is aging more rapidly than normal, failure can be imminent.

Actions: Ensure that the ambient temperature outside the relay is within specification. Ensure that there is sufficient clearance around the relay for adequate ventilation. If the alarm does not clear when acknowledged while the thermal environment is normal, contact GE Multilin.

IRIG-B FAILURE

Description: The IRIG-B input signal is not present.

Severity: Event timestamps may not be accurate.

Actions: Ensure that the IRIG-B receiver source is operational and properly configured. Ensure that the signal level at the relay is within specifications. If the alarm does not clear when acknowledged while the signal input is normal, contact GE Multilin.

POWER SUPPLY TRBL

Description: The power supply card has a problem.

Severity: Power supply failure can be eminent.

Actions: If the alarm does not clear when acknowledged, contact GE Multilin.

PROCESS BUS F1...F8 TRBL

Description: Communications problems exist on this process bus port. Either received signal levels at the Brick or Process Card are low, or no responses are being received from the Brick core specified by the process bus settings.

Severity: While no communications from the specified Brick are received, its field contact inputs are forced to their failsafe states, and the commands sent to the Brick are forced off.

Actions: Ensure that the correct digital core of the correct Brick is patched through to the correct process card port, and that the field unit settings are correct. If the field unit actual value is equipment mismatch, correct the discrepancy between the settings and the actual Brick serial number, order code, and/or core number. If the field unit actual value is communications lost, ensure that the Brick has power. Use a professional optical fiber connector cleaning kit to clean both sides of all optical fiber connections from the process card through to the affected Brick. If the problem continues after cleaning, contact GE Multilin.

PROCESS BUS J1...J8 TRBL

Description: Communications problems exist on this process bus port. Either received signal levels at the Brick or Process Card are low, or no responses are being received from the Brick core specified by the process bus settings.

Severity: While no communications from the specified Brick are received, its field contact inputs are forced to their failsafe states, and the commands sent to the Brick are forced off.

Actions: Ensure that the correct digital core of the correct Brick is patched through to the correct process card port and that the field unit settings are correct. If the field unit actual value is equipment mismatch, correct the discrepancy between the settings and the actual Brick serial number, order code, and/or core number. If the field unit actual value is communications lost, ensure that the Brick has power. Use a professional optical fiber connector cleaning kit to clean both sides of all optical fiber connections from the process card through to the affected Brick. If the problem continues after cleaning, contact GE Multilin.

REMOTE DEVICE OFF

Description: A remote device that is specified in the configuration for GOOSE or GSSE messaging is not receiving GOOSE/GSSE messages.

Severity: Remote inputs and GOOSE analog inputs subscribing to the failed device have entered their default state/value.

Actions: Ensure that devices subscribed to are functioning properly, are correctly configured, and are linked through the network to the relay.

SNTP FAILURE

Description: SNTP messages are not being received from the SNTP server.

Severity: Event timestamps may not be accurate.

Actions: Ensure that the SNTP server is operational and correctly configured. Ensure that the SNTP messages are input to the relay.

FlexLogic operands

The following self-test logic operands are available for the B95^{Plus}. They are listed alphabetically by operand syntax.

Self-test logic operands

EQUIPMENT MISMATCH.....This operand is asserted while the EQUIPMENT MISMATCH major self-test condition exists.

CONFIGURBL SELF-TEST.....	This operand is asserted while the CONFIGURBL SELF-TEST major self-test condition exists.
MAIN CARD TRBL.....	This operand is asserted while the MAIN CARD TRBL major self-test condition exists.
PROCESS CARD F TRBL.....	This operand is asserted while the PROCESS CARD F TRBL major self-test condition exists.
PROCESS CARD J TRBL.....	This operand is asserted while the PROCESS CARD J TRBL major self-test condition exists.
UNIT NOT PROGRAMMED.....	This operand is asserted while the UNIT NOT PROGRAMMED major self-test condition exists.
BRICK F1...F8 TROUBLE.....	This operand is asserted while the BRICK F1...F8 TROUBLE minor self-test condition exists.
BRICK J1...J8 TROUBLE.....	This operand is asserted while the BRICK J1...J8 TROUBLE minor self-test condition exists.
COMMS CARD TRBL.....	This operand is asserted while the COMMS CARD TRBL major self-test condition exists.
CONTACT CHATTER.....	This operand is asserted while the CONTACT CHATTER minor self-test condition exists.
CROSSCHECKING ERROR.....	This operand is asserted while the CROSSCHECKING ERROR minor self-test condition exists.
ETH PORT 1...3 FAILURE.....	This operand is asserted while the ETHPORT 1...3 FAILURE minor self-test condition exists.
HIGH TEMPERATURE.....	This operand is asserted while the HIGH TEMPERATURE minor self-test condition exists.
IRIG-B FAILURE.....	This operand is asserted while the IRIG-B FAILURE minor self-test condition exists.
POWER SUPPLY TRBL.....	This operand is asserted while the POWER SUPPLY TRBL minor self-test condition exists.
PROCESS BUS F1...F8 TRBL.....	This operand is asserted while the PROCESS BUS F1...F8 TRBL minor self-test condition exists.
PROCESS BUS J1...J8 TRBL.....	This operand is asserted while the PROCESS BUS J1...J8 TRBL minor self-test condition exists.
REMOTE DEVICE OFF.....	This operand is asserted while the REMOTE DEVICE OFF minor self-test condition exists.
SNTP FAILURE.....	This operand is asserted while the SNTP FAILURE minor self-test condition exists.


Set date and time

The date and time of the device and of the computer can be viewed, and the device can be synchronized manually to the computer. To configure for automatic updating, see the SNTP section or the IRIG-B Port section.

To view the dates and times:

1. Select the **Maintenance > Set Date and Time** menu item to open the date and time commands window.

Figure 3: Date and time actual values and commands



The following actual values display.

Computer Date

Range: date in MM/DD/YY format

This actual value displays the date specified by the computer running the EnerVista software.

Computer Time

Range: time in HH:MM:SS format

This actual value displays the time specified by the computer running the EnerVista software.

Device Date

Range: date in MM/DD/YY format

This actual value displays the date being used for the B95^{Plus}.

Device Time

Range: time in HH:MM:SS format

This actual value displays the time being used for the B95^{Plus}.

The following commands are available.

Sync Relay to Computer

This command sets the B95^{Plus} date and time values to the date and time of the computer running the EnerVista B95^{Plus} Setup software.

Set Manual Date and Time

This command sets the B95^{Plus} date and time values to the date and time values specified by the [Manual Date](#) and [Manual Time](#) entries.

Raw data viewer

The sections that follow outline functions related to the display of raw Brick data using the EnerVista software. This display information exists and is available even when the relay is not configured to consume the data received from the Brick. The raw Brick data viewer can be used during commissioning, routine system tests, and troubleshooting. Effectively, this functionality provides a built-in protocol analyzer for communications received from a Brick.

Analog inputs


To access the raw data viewer Brick analog inputs screen for the nth port on process card X:

1. In the **Online Window** area of the software, navigate to **Maintenance > Raw Data Viewer > X Process Card > Field Unit Xn > Analog Inputs**. This screen shows the analog process values being received on that port. AC inputs are displayed as phasors, using the source selected by the frequency tracking source setting as the zero degree reference.

The **Freeze** button halts updating of all raw data displays on the computer, to allow comparison of various quantities at the same moment. Requests to open additional raw data screens while frozen results in cancellation of the freeze condition.

The fields are described as follows.

Figure 4: Analog inputs screen



AC Input AC1...8 Magnitude/Angle

Range: conversion range of channel

The actual values sensed by and received from the connected Brick. For CT type AC inputs, the value is displayed in rms amps at the Brick terminals. For VT type AC inputs, the value is displayed in rms volts at the Brick terminals. Angles are referenced to the quantity used for frequency tracking, and are in degrees leading the frequency tracking quantity. This information (including units) is decoded from the communication packets received from the Brick connected to the Process Card Port. When no Brick data is being received, zero displays.

Field Unit

Range: U1...8

Each screen contains the field unit designation for the information displayed on that screen.

Field Unit ID

Range: 20 characters

The value of the user settable field unit ID for the information displayed on that screen. This duplicates for user convenience the actual value shown on the Field Unit setting screens.

Field Unit Status

Range: OK, Comms Lost, Equip Mismatch, Trouble, Disabled

Actual value of the field unit status as defined in Configuration of Field Units. This duplicates for user convenience the actual value shown on the Field Unit settings and actual values screens.

Brick Serial Number, Brick Order Code, Brick Digital Core

Range: various

The actual values received from the connected Brick. This information is decoded from each communication packet received from the Brick connected to the Process Card Port. When no Brick data is being received, the value displayed is invalid.

Freeze button

Range: Freeze, Unfreeze

The **Freeze** button allows the updating of all raw data AC input phasors to be suspended in order that their phase and magnitude inter-relationships can be examined. In freeze mode, the button changes to an **Unfreeze** button on all analog input screens.

Contact and shared input/output


The raw data viewer shows Brick contact inputs and shared inputs for the nth port on process card X.

To access the raw data viewer:

1. In the **Online Window** area of the software, navigate to **Maintenance > Raw Data > X Process Card > Field Unit Xn > Contact & Shared I/O**. The screen shows the contact input and shared inputs values being received on that port.

Descriptions of the fields follow.

Figure 5: Contacts and shared inputs screen

**Field Unit***Range: U1...8*

Each screen contains the field unit designation for the information displayed on that screen.

Field Unit ID*Range: 20 characters*

The value of the user settable field unit ID for the information displayed on that screen. This duplicates for user convenience the actual value shown on the Field Units settings screens.

Field Unit Status*Range: OK, Comms Lost, Equip Mismatch, Trouble, Disabled*

Actual value of the field unit status as defined in Configuration of Field Units. This duplicates for user convenience the actual value shown on the Field Units settings and actual values screens.

Brick Serial Number, Brick Order Code, Brick Digital Core

The actual values received from the connected Brick. This information is decoded from each communication packet received from the Brick connected to the Process Card Port. When no Brick data is being received, the value displayed is invalid.

Contact Input Status

Range: On, Off

The actual values sensed by and received from the connected Brick. This information is decoded from each communication packet received from the Brick connected to the Process Card Port. The contact closed state shows as if an illuminated red LED indicator with the text "On," and the contact open state as an extinguished LED indicator with the LED "Off." When no Brick data is being received, the indication is "Off."

Contact Output Status

Range: On, Off

The actual contact output monitoring values sensed by and received from the connected Brick. This information is decoded from each communication packet received from the Brick connected to the Process Card Port. The active or asserted state shows as if an illuminated red LED indicator with the text "On," and the inactive state as an extinguished LED indicator with the text "Off." When no Brick data is being received, the indication is "Off."

Shared Inputs

Range: On, Off

The actual values sensed by and received from the connected Brick. This information is decoded from each communication packet received from the Brick connected to the Process Card Port. The asserted state shows as if an illuminated red LED indicator with the text "On," the unasserted state as an extinguished LED indicator with the text "Off." When no Brick data is being received, the indication is "Off."

Diagnostics

The raw data viewer shows Brick diagnostics for the nth port on process card X.

To access the raw data viewer:

1. In the **Online Window** area of the software, navigate to **Maintenance > Raw Data > X Process Card > Field Unit Xn > Diagnostics**. The screen shows the Brick diagnostic values being received on that port, as well as process card transceiver diagnostics.

Descriptions of the fields follow.

Figure 6: Diagnostics screen

Field Unit	
Field Unit	F1
Field Unit ID	CB3
Field Unit Status	Comms Lost
Brick Serial Number	
Brick Order Code	CC55
Brick Digital Core	0
Brick Transceiver Diagnostics	
adcTemp	0 deg
transceiverTemp	0 deg
transceiverVolts	0.00 V
transceiverCurrent	0 mA
transceiverTxPower	0.0 dBm
transceiverRxPower	0.0 dBm
Process Card Transceiver Diagnostics	
transceiverTemp	58 deg
transceiverVolts	3.26 V
transceiverCurrent	24 mA
transceiverTxPower	94.4 dBm
transceiverRxPower	0.0 dBm
Brick Diagnostic Bits	
diagRunning	<input type="radio"/> Off
syncError	<input type="radio"/> Off
fw_hw_incompatible	<input type="radio"/> Off
lossOfSupply	<input type="radio"/> Off
microRestarted	<input type="radio"/> Off
pldFail	<input type="radio"/> Off
pldCommsError	<input type="radio"/> Off
clockDiscrepancy	<input type="radio"/> Off
wettingFail	<input type="radio"/> Off
dc1AnalogMode	<input type="radio"/> Off
dc2AnalogMode	<input type="radio"/> Off
dc3AnalogMode	<input type="radio"/> Off
hi_lo_RangeDiscrepancy	<input type="radio"/> Off
adcPowerTrouble	<input type="radio"/> Off
adcBusyError	<input type="radio"/> Off
adcTempTrouble	<input type="radio"/> Off
transceiverDiagFail	<input type="radio"/> Off
transceiverTempTrouble	<input type="radio"/> Off
transceiverVoltsTrouble	<input type="radio"/> Off
transceiverCurrentTrouble	<input type="radio"/> Off
transceiverTxPowerTrouble	<input type="radio"/> Off
transceiverRxPowerTrouble	<input type="radio"/> Off

Quick Connect Device | Maintenance: Raw Data: F Process Card: Field Unit F1

Field Unit*Range: U1...8*

Each screen contains the field unit designation for the information displayed on that screen.

Field Unit ID*Range: 20 characters*

The value of the user settable field unit ID for the information displayed on that screen. This duplicates for user convenience the actual value shown on the Field Units setting screens.

Field Unit Status*Range: OK, Comms Lost, Equip Mismatch, Trouble, Disabled*

Actual value of the field unit status as defined in Configuration of Field Units. This duplicates for user convenience the actual value shown on the Field Units settings and actual values screens.

Brick Serial Number, Brick Order Code, Brick Digital Core

The actual values received from the connected Brick. This information is decoded from each communication packet received from the Brick connected to the Process Card Port. When no Brick data is being received, the value displayed is invalid.

Brick Transceiver Diagnostics

The actual values sensed by and received from the connected Brick. These values are detected by the diagnostic hardware in the Brick transceiver. This information is decoded from each communication packet received from the Brick connected to the Process Card Port. When no Brick data is being received, zero is displayed.

Process Card Transceiver Diagnostics

The actual values sensed by the field unit port's process card transceiver. These values are detected by the diagnostic hardware in the process card transceiver.

Brick Diagnostic Bits

Range: On, Off

The actual values sensed by and received from the connected Brick. These bits detail various Brick conditions. See the semantics section in Appendix B: Message Format of the HardFiber System Reference Manual for a description of each bit. This information is decoded from each communication packet received from the Brick connected to the Process Card Port. The alarm/TDR state shows as if an illuminated red LED indicator, the normal/RTD state as an extinguished LED indicator. When no Brick data is being received, "Off" is displayed.

Modbus analyzer

The analyzer applies to the main card and the process cards, such as F and J. It allows you to read and write to the Modbus registers of the B95^{Plus}, meaning it provides another way to read actual values or to change settings. Other ways to view the same information is to view it in other panels of the EnerVista software and by entering the IP address of the unit in a web browser.

Before using the following procedures to read or write the registers, you need to know the memory map address that you want to use, for example 59D0 for the J process card actual values of the bus source. Open the Modbus user map in a web browser by entering the IP address of the B95^{Plus}. To view the IP address of the B95^{Plus}, click the **Next Page** button repeatedly under the annunciator panel on the left side of the unit until the IP address displays. Or in the **Online Window** area of the software, navigate to **Settings > Communications > Network > Ethernet**. When the user map does not display, it probably means that the Web Server Function needs to be enabled under **Settings > Communications > Network > HTTP**.

To read a Modbus register of the B95^{Plus}:

1. In the **Online Window** area of the software, navigate to **Maintenance > Modbus Analyzer**, and select the panel for the main card or one of the process cards.
2. In the **Read From Device** area, in the **Address** field, enter the Modbus memory map address. An example is 59D0 for bus sources or 14E0 for virtual inputs/outputs.
3. For the **Modbus Type** field, select an option from the drop-down list. For this example, leave it set at **Actual Value** to display data. The **Coil** option has not been implemented; do not select it.
4. For the **# of** field, indicate how many values to display. For example, for address 14E0 for virtual input/outputs, actual values for eight inputs and outputs can be displayed (viewable in the web browser), so enter the number 8 in the field.

- Select the format to display from the **Selection** field, for example **Long** or **Int** to display the number, such as 0. Options are explained at the end of this section.

In the example shown here, the panel for process card J was accessed. The eight virtual input/output values are displayed for the B95^{Plus} by entering the Modbus address 14E0 (for virtual I/O) and 8 to display the eight values.

Figure 7: Reading virtual I/O values of a process card

MODBUS - READ FROM DEVICE						
Address (HEX)	Modbus Type	# of ...	Selection	Values		
14E0	Actual Value	8	Int	0, 0, 0, 0, -15616, 0, 0, 0		
	Actual Value		Hex			
	Actual Value		Hex			

To write to a Modbus register of the B95^{Plus}:

- In the **Online Window** area of the software, navigate to **Maintenance > Modbus Analyzer**, and select the panel for the main card or one of the process cards.
- In the **Write to Device** area in the lower portion of the window, enable the **Send** check box.
- In the **Address** field, enter the Modbus memory map address. An example is 43E0.
- In the **# of Char** field, indicate how many values to write. An example is entering 1 to send either 0 or 1 to the unit by entering it in the **Values** field.
- Select the format to display from the **Selection** field. Options are explained at the end of this section.
- In the **Values** field, enter the value to write to the unit, for example 0 to take the unit offline.

In the example shown here, the panel for the main card was accessed. The B95^{Plus} was taken offline by entering the address of 43E0, a value of 0, and clicking the **Save** button to write to the unit, which became “Not Programmed” and thereby offline. This action is the same as taking the unit offline by navigating to **Settings > General > Installation**. The unit can be forced online by entering a value of 1 and clicking the **Save** button.

Figure 8: Taking the unit offline by writing to the main card

MODBUS - WRITE TO DEVICE						
Send	Address (HEX)	Modbus Type	# of Char	Selection	Values	Last Status
<input checked="" type="checkbox"/>	43e0	Both (S/M)	1	UInt	0	OK
<input type="checkbox"/>		Both (S/M)	1	UInt		
<input type="checkbox"/>		Both (S/M)	1	UInt		

The following settings are available.

Modbus Type

Range: Actual Value, Setting, Coil, Both (S/M), Single, Multiple, Coil

Default: Actual Value or Both (S/M)

Actual Value — Data or actual values

Setting — A setting for the unit

Coil — Not used; do not select

Both (S/M) — Both single and multiple

Single — Single

Multiple — Multiple

Selection

Range: Hex, Char, Int, UInt, Long, ULong, Float, Binary
 Default: Hex or UInt

The format of the value to read from the device or write to it.

Hex — Hexadecimal

Char — Characters

Int — Integer

UInt — Unsigned integer; the first bit is not reserved for signing

Long — Integer

ULong — Unsigned integer; the first bit is not reserved for signing

Float — Floating decimal values, for example 0.000000

Binary — 0 or 1

Updating firmware

The firmware of a B95^{Plus} can be upgraded remotely over Ethernet using the EnerVista B95^{Plus} Setup software. You download the update, save existing settings, then update.




Updating the firmware deletes device settings and digital fault recorder records.

To update the hardware firmware:

1. Download the firmware update file from the GE website at <http://www.gedigitalenergy.com/multilin/software/index.htm>
 The file is a ZIP file that is password-protected. Do not unzip it.
2. Remove the B95^{Plus} unit from service.
3. In the **Online Window** area of the EnerVista software, right-click the B95^{Plus} device and select **Read Device Settings**.
4. In the window that displays, select an existing settings file to overwrite, or specify a location and name for a new settings file. Click **Receive** to start the backup.

Figure 9: Saving settings




5. In the **Online Window** area, navigate to **Maintenance > Update Firmware**. Select the firmware update file and click **Next** and continue with the prompts to start the update. Progress displays, as shown in the following figure. Ensure power to the device remains on during the update.

For an error message regarding Ethernet communications, access the **Ethernet** panel in the EnerVista software and finish configuring the IP addresses, for example the gateway address. Only one gateway is allowed, so ensure that in the **Ethernet** panel you are performing the update on the port with the gateway.

NOTICE

Interruption of communication during the update can result in corrupted firmware. If this occurs, consult the factory for recovery instructions.

Figure 10: Firmware update in progress



6. Right-click the saved settings file in the **Offline Window** and select **Write to Device**.

Replace module

WARNING

Remove or insert a module only when power has been removed from the unit, else death or serious injury can result.

CAUTION

Inserting an incorrect module type into a slot can result in personal injury, damage to the unit or connected equipment, or undesired operation.

NOTICE

Use proper electrostatic discharge protection (for example, an antistatic strap) when handling the modules, else damage can occur.

All modules are delivered installed. No cards are optional on the unit. There is no need to change a module except for repair purposes.

To change a module:

1. Return the unit to the factory or have a representative perform the work on-site.

Multilin B95^{Plus} Bus Protection System

Chapter 15: Bus replica application guide

A bus replica is a dynamic model of the power system bus that the unit is protecting. This chapter provides guidance on configuring the bus replica for a variety of bus arrangements.

See the earlier sections on the bus replica in the Protection chapter for details on individual settings, and see IEEE Standard C37.234-2009 IEEE Guide for Protective Relay Applications to Power System Buses to learn about bus protection concepts. See also earlier sections in the EnerVista Software chapter on use of the Bus Replica Graphical Editor.

Bus arrangements are typically extensions or combinations of the classical arrangements presented here. For example, triple or quadruple buses are typically extensions of the double-bus standard arrangement. Another example is an arrangement that is the combination of the double-bus single-breaker arrangement and a transfer bus arrangement. During the bus protection setting development phase, it is typically sufficient to recognize the parts of the bus at hand that can be conceptually split off and handled as for one of the classical arrangements. Unusual cases can be dealt with using the relay's FlexLogic features.

Static bus arrangements

Simplest to handle are the static bus arrangements, where the boundaries of the bus do not change from moment-to-moment. Examples are a single bus, two single buses with a bus coupler, double-bus double-breaker arrangements, breaker-and-a-half arrangements, and terminal buses. The following figures represent each type. This section also provides an example using both the Bus Replica Graphical Editor and the usual matrix of settings type screens.


The following bullets explain terminal buses and ring buses:

- **Terminal buses** — Used within breaker-and-a-half arrangements, double-bus double-breaker arrangements, and ring bus arrangements for cases where part of the tripping zone requires high sensitivity (for example, a transformer) and part is subjected to high through currents (such as the leads between the two ring/diameter breakers and the transformer terminals). The tripping zone in these cases is divided into a measuring zone with high sensitivity for the network element and a separate terminal bus measuring zone with high through fault current security for the part of the tripping zone subjected to through currents. Examples of such network elements

are transformers, capacitors, reactors, and long lines. The first figure shows the oneline of a typical terminal bus.

- **Ring bus** – Arrangements of multiple circuit breakers connected in a ring, with a network element tapped between each adjacent pair of circuit breakers. Ring buses do not normally have a specific ring bus protection; they are protected by the network element protections and/or terminal bus protections.

Figure 1: Terminal bus arrangement



configuration for these classical bus arrangements is discussed at the end of this section.

In the oneline figures here, the boundaries of the zones are marked with dashed line. The line is shown passing through the boundary CTs. Overlapping the zones as is shown in these figures is typical practice.

The following figure identifies corresponding symbols used in the scenarios outlined in this section.

Figure 2: Single bus arrangement (with symbols identified)




Figure 3: Two single buses with a bus coupler




Figure 4: Double bus double breaker arrangement





Figure 5: Breaker-and-a-half arrangement



To configure the bus replica for any of these static bus arrangements, using the breaker-and-a-half arrangement as an example:

1. Decide which one of the six available bus zones to use for each bus segment.

2. Navigate to **Settings > Protection > General > Bus Differential** to set the bus zone IDs to describe the bus segments, and set the appropriate bus zones' **Function** setting to Enabled in the **General Settings** group. For example, set bus zone Z1 to BU1, Z2 to BU2, and so on.

PARAMETER	Z1	Z2	Z3	Z4	Z5	Z6
ID	BU1	BU2	BU3	BU4		
General Settings						
Function	Enabled	Enabled	Enabled	Enabled	Disabled	Disabled
Block	OFF	OFF	OFF	OFF	OFF	OFF
Auxiliary Zone Trip	OFF	OFF	OFF	OFF	OFF	OFF
Check-Zone	No	No	No	No	No	No
Events	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled
ACTUAL VALUES						
J CT in Zone						

3. Where a single CT on a single Brick is used to define the boundary between two bus segment measurement zones, map the CT's field unit to two bus sources, one for each bus segment.
4. Map each of the CTs needed to define a bus segment measurement zone to a bus source. This involves configuring **Settings > Remote Resources > Field Units** to map field units to Bricks. For example, map the Brick for CB3 to field unit F1, the CB5 Brick to F2, and so on, and Enable them.

PARAMETER	F1	F2	F3
ID	CB3	CB5	CB12
Function	Enabled	Enabled	Enabled
Brick Order Code	CC55	CC55	CC55
Brick Serial Number	000000000000	000000000001	000000000002
Brick Core	1	2	1
ACTUAL VALUES			
	Auto Populate S/N	Auto Populate S/N	Auto Populate S/N

5. Configure **Settings > Protection > General > Bus Sources** to set the bus source IDs to describe the bus source (bay) modelled, and set the appropriate bus sources' **Function** setting to Enabled in the **General Settings** group. For example, set the F/SRC1 ID to CB3, and Enable it.

In the **CT Settings** group, map the bus source to a CT bank by setting an **Origin** to the appropriate bank (AC1...3 or AC5...7) in the appropriate field unit. Set the **Primary** and **Secondary** settings to match the CT's ratings.

For each of these bus sources, set each zone connection setting in the **Bus Configuration Settings** group to an operand that reflects whether that bus source is

at present connected to that zone. Static bus arrangements need use only the ON and OFF operands for connection settings: ON where the bus source is permanently connected to the zone, OFF where there is no connection.

PARAMETER	F/SRC 1	F/SRC 2	F/SRC 3	F/SRC 4	F/SRC 5
ID	CB3	CB5	CB12 for BU1	CB12 for BU2	CB4
General Settings					
Function	Enabled	Enabled	Enabled	Enabled	Enabled
Block	OFF	OFF	OFF	OFF	OFF
Events	Enabled	Enabled	Enabled	Enabled	Enabled
HMI Template	1	1	2	3	1
CT Settings					
Bus Configuration Settings					
BU1 (Z1) Connection	ON	ON	ON	OFF	OFF
BU2 (Z2) Connection	OFF	OFF	OFF	ON	ON
BU3 (Z3) Connection	OFF	OFF	OFF	OFF	OFF
BU4 (Z4) Connection	OFF	OFF	OFF	OFF	OFF
(Z5) Connection	OFF	OFF	OFF	OFF	OFF
(Z6) Connection	OFF	OFF	OFF	OFF	OFF
Bypass Connection	OFF	OFF	OFF	OFF	OFF
Breaker Open 1	OFF	OFF	OFF	OFF	OFF
Breaker Open 2	OFF	OFF	OFF	OFF	OFF
Breaker Open Delay	0.400 s	0.400 s	0.400 s	0.400 s	0.400 s
Manual Close 1	OFF	OFF	OFF	OFF	OFF
Manual Close 2	OFF	OFF	OFF	OFF	OFF
Bus Trip Settings					
Breaker Failure Inputs					
ACTUAL VALUES					

- For the field contact outputs that trip a bus breaker, set the operate operand setting to the corresponding bus source's Bkr Trip Init logic operand. In the case of bus couplers that have two CTs and therefore two bus sources, use FlexLogic to OR the two bus source Bkr Trip Init logic operands, assign the result to a virtual output, and set the field contact operate operand to that virtual output.

The figure that follows shows these settings for the breaker-and-a-half arrangement. It was decided to use bus zone Z1 for BU1, Z2 for BU2, Z3 for BU3, and Z4 for BU4, and the bus zone ID settings were set accordingly. Settings not shown map the CT's Bricks to field units, and the field units AC inputs to bus sources. Each bus source ID has been set to the designation of its CT's breaker. These IDs can be seen in the figure. Finally, the bus source connection settings have been changed from the default OFF to ON at the table row/column intersections where the CT connects to the zone. Settings different from the default are highlighted in yellow in the figures.

The final figure that follows, the bus replica presentation, shows these same settings in the Bus Replica Graphical Editor. The bus source objects and how they are used to model an actual bus arrangement become more apparent. The long horizontal lines represent the bus zones (bus segments), with their IDs and designations at the far left. The boxes arranged across the screen each containing a designation (for example, F/Src3), an ID (for example, CB3), isolators (slash symbols), a CT and a breaker, with the bus zones passing through them, are the bus sources. Greyed-out items are inactive. The breakers are greyed-out as bus expansion/reduction and end fault protection are not used in this particular example. The bus coupler breaker CB12 has both a set of CTs for BU1 and a set of CTs for BU2, necessitating the use of two bus sources, which in turn makes the coupler breaker appear twice, once in each bus source.

Figure 6: Settings for breaker-and-a-half arrangement

Bus Differential // Quick Connect: Quick Connect Device: Settings: Protection: General

Save Restore Default Reset

PARAMETER	Z1	Z2	Z3	Z4
ID	BU1	BU2	BU3	BU4
General Settings				
Function	Enabled	Enabled	Enabled	Enabled
Block	OFF	OFF	OFF	OFF
Auxiliary Zone Trip	OFF	OFF	OFF	OFF
Check-Zone	No	No	No	No
Events	Enabled	Enabled	Enabled	Enabled
ACTUAL VALUES				
F CT in Zone				
J CT in Zone				

Quick Connect Device Settings: Protection: General


Bus Sources // Quick Connect: Quick Connect Device: Settings: Protection: General

Save Restore Default Reset

PARAMETER	F/SRC 3	F/SRC 4	F/SRC 5	F/SRC 6	F/SRC 7	F/SRC 8	F/SRC 9	J/SRC 3	J/SRC 4	J/SRC 5	J/SRC 6	J/SRC 7	J/SRC 8	J/SRC 9
ID	CB3	CB4	CB5	CB6		CB12 for BU2	CB12 for BU1	CB7	CB8	CB9	CB10		CB34 for BU4	CB34 for BU3
General Settings														
CT Settings														
Bus Configuration Settings														
BU1 (Z1) Connection	ON	OFF	ON	OFF	OFF	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF
BU2 (Z2) Connection	OFF	ON	OFF	ON	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
BU3 (Z3) Connection	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON	OFF	ON	OFF	OFF	OFF	ON
BU4 (Z4) Connection	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON	OFF	ON	OFF	ON	OFF
(Z5) Connection	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
(Z6) Connection	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Bypass Connection	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Breaker Open 1	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Breaker Open 2	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Breaker Open Delay	0.400 s	0.400 s	0.400 s	0.400 s	0.400 s	0.400 s	0.400 s	0.400 s	0.400 s					
Manual Close 1	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Manual Close 2	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Bus Trip Settings														
Breaker Failure Inputs														
ACTUAL VALUES														

Quick Connect Device Settings: Protection: General

Figure 7: Bus Replica Graphical Editor presentation of breaker-and-a-half arrangement



Dynamic bus arrangements

Dynamic bus arrangements are those where the boundaries of the bus zones need to change from moment-to-moment due to switching to accommodate changing power system conditions. Examples of classical dynamic bus basic arrangements are sectionalized bus, double-bus single-breaker, main and transfer bus, breaker bypass, and combinations thereof. This section includes examples and discussion of these basic types.

To configure the bus replica for any of these dynamic bus arrangements:

1. Decide which one of the six available bus zones to use for each bus segment.
2. Map each of the CTs needed to define a bus segment measurement zone to a bus source. This involves configuring **Settings > Remote Resources > Field Units** to map field units to Bricks.
3. Navigate to **Settings > Protection > General > Bus Differential** to set the appropriate bus zone **Function** setting to Enabled in the **General Settings** group.
4. Configure **Settings > Protection > General > Bus Sources** to map bus sources to field units, setting the appropriate bus sources' **Function** setting to Enabled in the **General Settings** group.

In the CT Settings group, give it an **Origin**, and **Primary** and **Secondary** currents and **Polarity**.

Where a single CT on a single Brick is used to define the boundary between two bus segment measurement zones, map the CT's field unit to two bus sources, one for each bus segment.

For each of these bus sources, set each zone connection setting in the **Bus Configuration Settings** group to an operand that reflects whether that bus source is at present connected to that zone. Typically in dynamic bus arrangements either the bus source is not connectable to given zone, or is connected when a primary isolator (disconnect) switch is closed. A isolator function can be set to develop an operand for the connection setting in the latter case, the OFF operand is used in the former case.

NOTICE

If the state of an operand selected for a bus source to zone connection setting is incorrect, due for instance to brick communications failure or failure of isolator auxiliary contacts, the differential protection incorrectly includes or excludes the current of this connection. The differential comparator then sees a spurious difference current, and when sufficiently large, operates. It is strongly recommended that the relay be configured to prevent such an operation tripping the bus. This can include use of undervoltage supervision, use of check zone supervision, use of brick and isolator auxiliary contact redundancy, and/or use of connection status failure, for example Field Unit Off operand) to block the differential. See the isolators Settings section to implement redundancy.

5. For the field contact outputs that trip a bus breaker, set the operate operand setting to the corresponding bus source's Bkr Trip Init logic operand. In the case of bus couplers that have two CTs and therefore two bus sources, use FlexLogic to OR the two bus source Bkr Trip Init logic operands, assign the result to a virtual output, and set the field contact operate operand to that virtual output.

Sectionalized bus

As shown in the following figure, a single bus with sectionalizer arrangement, while the sectionalizer is open, is the equivalent to two simple buses. With the sectionalizer open, zone 1 measures the BU1 CTs on CB1, CB3 and CB5, and trips these same breakers when a BU1 (zone 1) fault is detected. Similarly zone 2 measures and trips BU2 breakers CB2, CB4 and CB6. Thus bus faults clear the faulted bus segment while leaving the other segment uninterrupted.

As shown in the second figure, when the sectionalizer is closed, the situation is equivalent to one single bus. Without CTs on the sectionalizer to measure the current flowing between the bus segments, it is not theoretically possible for protection to determine on which bus segment a bus fault exists. In any event, as the sectionalizer has neither the speed nor the interrupting capacity to separate a faulted bus from a healthy bus, so a fault on either segment needs to clear both. The bus replica arranges for this to happen by automatically transferring all BU2 CTs and breaker trips from zone 2 to zone 1 while the sectionalizer status shows closed, such that zone 1 covers both buses. This leaves zone 2 with no CTs, idling its differential comparator.

The bus replica implements this automatic transfer action when BU1 and BU2 are each configured as the simple single buses previously discussed using respectively zone 1 and zone 2, and another bus source is added to model the bus paralleling action performed by the sectionalizer. The sectionalizer bus source has no CT inputs, but its connection settings are selected such that it dynamically parallels zone 1 and zone 2 when sectionalizer status is closed. One of the sectionalizer bus source zone connection settings is set to ON (always closed) and the other to a logic operand that is On when the sectionalizer is closed. Typically a isolator function is used to develop this sectionalizer state operand from primary isolator status inputs.

With single bus arrangements, it is also possible to use one of the network element bus sources to model the sectionalizer instead of using a dedicated sectionalizer bus source. This technique reduces the number of bus sources required, but is only applicable to single buses. When the sectionalizer arrangement is combined with double bus single breaker for instance, a dedicated sectionalizer bus source as described above is required for each sectionalizer.

Figure 8: Single bus with sectionalizer arrangement - sectionalizer open





Figure 9: Single bus with sectionalizer arrangement - sectionalizer closed



The connection settings are as shown in the next two figures. Bus source F/Src4 is used to model the sectionalizer by being invariably connected to zone 1 (F/Src4 BU1 (Z1) Connection setting ON), and connected to zone 2 when the sectionalizer is closed (F/Src4 BU2 (Z2) Connection setting DS12 Closed). DS12 Closed is the user name for isolator operand F/Iso1 Closed.

Figure 10: Settings for single bus with sectionalizer arrangement

Bus Differential // Quick Connect: Quick Connect Device: Settings: Protection

Save
Restore
Default
Reset

PARAMETER	Z1	Z2	Z3	Z4	Z5	Z6
ID	BU1	BU2				
General Settings						
Function	Enabled	Enabled	Disabled	Disabled	Disabled	Disabled
Block	OFF	OFF	OFF	OFF	OFF	OFF
Auxiliary Zone Trip	OFF	OFF	OFF	OFF	OFF	OFF
Check-Zone	No	No	No	No	No	No
Events	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled
ACTUAL VALUES						
JCT in Zone						

Quick Connect Device | Settings: Protection: General


Bus Sources // Quick Connect: Quick Connect Device: Settings: Protection

Save
Restore
Default
Reset

PARAMETER	F/SRC 1	F/SRC 2	F/SRC 3	F/SRC 4	F/SRC 5
ID	CB3	CB1	CB5	DS12	CB4
General Settings					
Function	Enabled	Enabled	Enabled	Enabled	Enabled
Block	OFF	OFF	OFF	OFF	OFF
Events	Enabled	Enabled	Enabled	Enabled	Enabled
HMI Template	1	1	1	2	1
CT Settings					
Bus Configuration Settings					
BU1 (Z1) Connection	ON	ON	ON	ON	OFF
BU2 (Z2) Connection	OFF	OFF	OFF	DS12 Closed	ON
BU3 (Z3) Connection	OFF	OFF	OFF	OFF	OFF
BU4 (Z4) Connection	OFF	OFF	OFF	OFF	OFF
(Z5) Connection	OFF	OFF	OFF	OFF	OFF
(Z6) Connection	OFF	OFF	OFF	OFF	OFF
Bypass Connection	OFF	OFF	OFF	OFF	OFF
Breaker Open 1	OFF	OFF	OFF	OFF	OFF
Breaker Open 2	OFF	OFF	OFF	OFF	OFF
Breaker Open Delay	0.400 s	0.400 s	0.400 s	0.400 s	0.400 s
Manual Close 1	OFF	OFF	OFF	OFF	OFF
Manual Close 2	OFF	OFF	OFF	OFF	OFF
Bus Trip Settings					
Breaker Failure Inputs					
ACTUAL VALUES					

Quick Connect Device | Settings: Protection: General

Figure 11: Bus Replica Graphical Editor presentation of single bus with sectionalizer



Double-bus single-breaker

A double-bus single-breaker arrangement as shown in the first figure that follows has an isolator (also known as a disconnect or an air-break switch) that allows each network element to be connected to either or both bus segments. Typically only one of the two isolators in each feeder/transformer bay are closed. Both isolators are closed at the same time only for a brief period while transferring the network element from one bus segment to the other without network element interruption. A bus coupler breaker provides the normal bus segment tie capability, a tie that can be broken under both load and fault conditions. Typically the coupler's isolators are both closed, except when both are open for coupler maintenance.

With at most one isolator in each bus source closed, the arrangement is electrically equivalent to two of the single buses discussed earlier, except that separation between the bus segments is not so clearly evident on inspection of the one line. In this example, while the buses are separated, zone 1 measures the CTs on the coupler and the CTs of feeder/transformer bays that at that moment are connected via their isolators to BU1. Zone 1 trips the coupler and the breakers in these connected bays when a BU1 (zone 1) fault is detected. Similarly zone 2 measures the connected CTs and trips the connected breakers. Thus bus faults clear the faulted bus segment while leaving the other segment uninterrupted.

With both isolators in a single bus source closed, the buses BU1 and BU2 are said to be paralleled, and the situation is now equivalent to one single bus. Without CTs on the isolators to measure the current flowing between the bus segments, it is not theoretically possible for protection to determine on which bus segment a bus fault exists. In any event, as the paralleling isolators have neither the speed nor the interrupting capacity to separate the faulted bus from the healthy bus, a fault on either bus needs to clear both. The bus replica arranges for this to happen by automatically transferring all zone 2 CTs and breaker trips to zone 1 while both isolators in any bus source show closed, such that zone 1 covers both buses. This leaves zone 2 with no CTs, idling its differential comparator.

In the figure, the zone boundaries are both dynamic and visually complex, so are not shown in full.

The bus replica is configured to implement this automatic transfer action when the bus source's zone connection settings are configured to a logic operand that is On when the isolator that connects that bus source to that bus zone shows closed. Typically a isolator function is used to develop the isolator status operands from physical isolator auxiliary contacts. In this example, DSxx Closed are the user names of isolator closed operands.

The connection settings are as shown in the second and third figures that follow. In this example, the bus coupler isolator dynamic status DS121 Closed and DS 122 Closed are used to make the connection between the coupler and the zones. This results in the zone boundaries being automatically moved to the isolators when open. This can prevent unnecessary tripping, for example due to test current injection while the coupler is isolated. An alternative that does not rely on correct isolator status during normal coupler operation is to use the ON operand in place of DS121 and DS122 status.

Figure 12: Double-bus single-breaker arrangement





Figure 13: Bus Configuration Settings for double-bus single-breaker arrangement

Bus Differential // Quick Connect: Quick Connect Device: Settings: Protection						
Save Restore Default Reset						
PARAMETER	Z1	Z2	Z3	Z4	Z5	Z6
ID	BU1	BU2				
General Settings						
Function	Enabled	Enabled	Disabled	Disabled	Disabled	Disabled
Block	OFF	OFF	OFF	OFF	OFF	OFF
Auxiliary Zone Trip	OFF	OFF	OFF	OFF	OFF	OFF
Check-Zone	No	No	No	No	No	No
Events	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled
ACTUAL VALUES						
JCT in Zone						
Quick Connect Device Settings: Protection: General						
Bus Sources // Quick Connect: Quick Connect Device: Settings: Protection						
Save Restore Default Reset						
PARAMETER	F/SRC 2	F/SRC 3	F/SRC 4	F/SRC 5	F/SRC 6	
ID	CB3	CB5	CB12 for BU1	CB12 for BU2	CB4	
General Settings						
Function	Enabled	Enabled	Enabled	Enabled	Enabled	
Block	OFF	OFF	OFF	OFF	OFF	
Events	Enabled	Enabled	Enabled	Enabled	Enabled	
HMI Template	1	1	2	3	1	
CT Settings						
Bus Configuration Settings						
BU1 (Z1) Connection	DS31 Closed	DS51 Closed	DS121 Closed	OFF	DS41 Closed	
BU2 (Z2) Connection	DS32 Closed	DS52 Closed	OFF	DS122 Closed	DS42 Closed	
BU3 (Z3) Connection	OFF	OFF	OFF	OFF	OFF	
BU4 (Z4) Connection	OFF	OFF	OFF	OFF	OFF	
(Z5) Connection	OFF	OFF	OFF	OFF	OFF	
(Z6) Connection	OFF	OFF	OFF	OFF	OFF	
Bypass Connection	OFF	OFF	OFF	OFF	OFF	
Breaker Open 1	OFF	OFF	OFF	OFF	OFF	
Breaker Open 2	OFF	OFF	OFF	OFF	OFF	
Breaker Open Delay	0.400 s	0.400 s	0.400 s	0.400 s	0.400 s	
Manual Close 1	OFF	OFF	OFF	OFF	OFF	
Manual Close 2	OFF	OFF	OFF	OFF	OFF	
Bus Trip Settings						
Breaker Failure Inputs						
ACTUAL VALUES						
Quick Connect Device Settings: Protection: General						

Figure 14: Bus Replica Graphical Editor presentation of double-bus single-breaker



Main and transfer bus

A main and transfer bus has a bus segment, the so-called transfer bus, used to maintain a feeder in-service while its breaker service isolators are open for breaker maintenance. For an illustrative main and transfer bus oneline, see the first and second figures that follow.

A fundamental feature of this arrangement is that transfer isolators connect the transfer bus to a point between a bay's breaker and its CT in a way that the CT is not bypassed, unlike the breaker bypass arrangement discussed in the next section, yet the bay breaker is bypassed, unlike the double-bus single-breaker arrangement discussed previously. This allows the bus and network element protections to remain operational while the network element is transferred, although the network element needs to trip the transfer breaker instead of its bay breaker, and the transfer bus zone typically needs to trip the remote end of network elements at the moment connected to the transfer bus. A transfer breaker performs a function similar to a bus coupler; that of tying the transfer bus to the main bus.

Figure 15: Main and transfer bus arrangement - transfer bus idle





Figure 16: Main and transfer bus arrangement - transfer bus supplying feeder F5



With all the transfer isolators open as shown in the first figure, the arrangement is electrically equivalent to the two single buses discussed earlier. In this example, while the buses are separated, zone 1 measures the CTs of breakers CB1, CB2, CB3, CB4, CB5 and CB6, and trips these same breakers when a main bus BU1 (zone 1) fault is detected. The transfer bus (BU2) zone (zone 2) measures the CT and trips only the transfer breaker CB6. Thus transfer bus faults clear only the transfer bus, leaving the main bus uninterrupted. While main bus faults do not trip the transfer bus, with the main bus tripped the transfer bus is in any case disconnected.

When a bay's transfer isolator shows closed and that bay's breaker service isolators show open as for CB5 in the second figure, the bus replica automatically moves the transferred bay's CTs and breaker tripping to zone 2, the transfer bus, maintaining correct zone boundaries for both bus segments.

For the brief time while a bay's transfer isolator shows closed and the bay's breaker service isolators do not yet show open, or vice-versa, the bus segments are said to be paralleled, and the situation is now equivalent to one single bus. Without CTs on the isolators to measure the current flowing between the bus segments, it is not theoretically possible for protection to determine on which bus segment a bus fault exists. In any event, as the paralleling isolators have neither the speed nor the interrupting capacity to separate the faulted bus from the healthy bus, a fault on either bus needs to clear both. The bus replica arranges for this to happen by automatically transferring all zone 2 (transfer bus) connected CTs and breaker trips to zone 1 while both breaker service and transfer isolators show closed, such that zone 1 covers both buses. This leaves zone 2 with no CTs, idling its differential comparator.

The bus replica is configured to implement this automatic transfer action when:

1. The network element bus source's main bus zone connection settings are set to a logic operand that is On when the isolator that connects that bus source to the main bus zone is closed.
2. The network element bus source's transfer bus zone connection settings are set to a logic operand that is On when the isolator that connects that bus source to the transfer bus zone is closed.
3. The transfer breaker bus source's main bus zone connection settings are set to ON or to a logic operand that is On when the isolator that connects the transfer breaker CTs to the main bus zone is closed.
4. The transfer breaker bus source's transfer bus zone connection settings are set to ON or to a logic operand that is On when the isolator that connects the transfer breaker CTs to the transfer bus zone is closed.

Typically a isolator function is used to develop the isolator status operands from physical isolator auxiliary contacts. In this example, DSxx Closed are the user names of isolator closed operands.

Although the relay can use any of its six bus zones for the transfer bus, the Bus Replica Graphical Editor can only correctly show the configuration when the transfer bus is zone 6.



NOTE

Zone expansion/reduction and end fault protection are incompatible with bus sources using a transfer bus. This is because the bus source breaker being open does not necessarily mean that faults between the CT and the breaker require no bus tripping. In fact, if the transfer isolator is closed, faults in this area require transfer bus tripping. Therefore, bus sources using the transfer bus should leave the bus source breaker open settings at OFF.

The connection settings are shown in the next two figures.

Figure 17: Bus Configuration Settings for main and transfer bus arrangement

Bus Differential // Quick Connect: Quick Connect Device: Settings: Protection: General

Save Restore Default Reset

PARAMETER	Z1	Z2	Z3	Z4	Z5	Z6
ID	BU1					BU-T
General Settings						
Function	Enabled	Disabled	Disabled	Disabled	Disabled	Enabled
Block	OFF	OFF	OFF	OFF	OFF	OFF
Auxiliary Zone Trip	OFF	OFF	OFF	OFF	OFF	OFF
Check-Zone	No	No	No	No	No	No
Events	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled
ACTUAL VALUES						
JCT in Zone						

Quick Connect Device | Settings: Protection: General


Bus Sources // Quick Connect: Quick Connect Device: Settings: Protection: General

Save Restore Default Reset

PARAMETER	F/SRC 2	F/SRC 4	F/SRC 5	F/SRC 6	F/SRC 7
ID	CB3	CB4	CB5	CB6 for BU1	CB6 for BU-T
General Settings					
Function	Enabled	Enabled	Enabled	Enabled	Enabled
Block	OFF	OFF	OFF	OFF	OFF
Events	Enabled	Enabled	Enabled	Enabled	Enabled
HMI Template	1	1	1	2	3
CT Settings					
Bus Configuration Settings					
BU1 (Z1) Connection	DS31 Closed	DS41 Closed	DS51 Closed	ON	OFF
BU2 (Z2) Connection	OFF	OFF	OFF	OFF	OFF
BU3 (Z3) Connection	OFF	OFF	OFF	OFF	OFF
BU4 (Z4) Connection	OFF	OFF	OFF	OFF	OFF
(Z5) Connection	OFF	OFF	OFF	OFF	OFF
(Z6) Connection	DS3T Closed	DS4T Closed	DS5T Closed	OFF	ON
Bypass Connection	OFF	OFF	OFF	OFF	OFF
Breaker Open 1	OFF	OFF	OFF	OFF	OFF
Breaker Open 2	OFF	OFF	OFF	OFF	OFF
Breaker Open Delay	0.400 s				
Manual Close 1	OFF	OFF	OFF	OFF	OFF
Manual Close 2	OFF	OFF	OFF	OFF	OFF
Bus Trip Settings					
Breaker Failure Inputs					
ACTUAL VALUES					

Quick Connect Device | Settings: Protection: General


Figure 18: Bus Replica Graphical Editor presentation of main and transfer bus



Breaker bypass switches

A breaker bypass switch is often used in double-bus single-breaker arrangements to allow a network element to remain in-service while its breaker service isolators are open for breaker maintenance. For an example of a bay with breaker bypass, see the following figure. A feature of this arrangement is that the bypass switch bypasses both the breaker and its CTs.

Figure 19: Breaker bypass arrangement, shown with a double-bus single-breaker



To prepare for a bypass, the network elements are transferred such that one bus segment has only the network element being bypassed; all other network elements are transferred to the other bus. The bypass isolator is then closed, bypassing the CTs, so neither the bus zone the bypassed breaker is connected to nor the bypassed breaker's network element protection can measure the network element current.

This lack of current signal necessary for protection is typically handled by the provision of separate protection using bus coupler CTs to cover both the bus used by the bypassed network element and bypassed network elements. The normal network element protection and the affected bus differential are both blocked.

The bus replica is configured to automatically block any bus zone differential that has a connected CT bypassed when the bus source bypass connection settings of bays with bypass are each set to a logic operand that is On when its bypass switch is closed. Typically an isolator function is used to develop the bypass switch status operand from physical bypass switch auxiliary contacts.

Check zones

A check zone is a non-selective part of a multi-zone protection system measuring current flows around the entire station and supervising tripping from individual bus zones of protection. For a further description of check zones, see IEEE Standard C37.234-2009 IEEE Guide for Protective Relay Applications to Power System Buses.

The correct operation of dynamic bus differential protection depends on the correctness of the CTs and associated signal processing hardware, as well as the correctness of the isolator status monitoring and associated signal processing hardware. With large dynamic buses, this can amount to a large amount of protection critical hardware, multiplying the frequency of unnecessary hardware failure related protection in comparison to network element protection. As unnecessary bus tripping typically has unacceptable impact on the power system, check zones that are not sensitive to isolator status are often employed to block tripping when no fault is present inside the station. On occasion where the additional cost is justified, check zones use redundant CTs and redundant associated signal processing hardware to provide complete independence from failures affecting the individual bus zones.

Check zones have traditionally also been used with protection schemes that do not account for the impact to the individual zones of the bus paralleling that occurs when doing live-transfer of a network element from one bus segment to another. The however, with its dynamic bus replica configured, does recognize and adjust for paralleling, provided it is so configured and is receiving correct isolator status.

The first figure that follows shows the zone coverage of a check zone for a typical double bus single breaker arrangement. Zone 5 is used for the check zone in this case, although any otherwise unused zone can be employed. As shown in the second and third figures, the check zone is configured by setting the connection from each network element to zone 5 to ON. There is no dynamic status controlling which currents the check zone uses. The bus coupler bus sources are not included in the check zone, which makes the check zone immune to failure of coupler CT signals. Importantly, the zone 5 check zone setting is set to Yes, which prevents the bus replica from declaring all the individual zones paralleled through the check zone.

To configure the individual zones to be supervised by the check zone, set one of their Zone Supervision settings to the check zone's operate operand, Z5 Diff Op in this case. The other Zone Supervision setting and the Zone Supervision Voting setting must be set appropriately. If the other Zone Supervision setting is not used, set it to OFF and set Zone Supervision Voting to OR.

Pay attention to cases where the check zone covers two buses with widely different currents.

NOTICE

Set check zones to be at least as sensitive as any zone supervised by the check zone. In some applications, the check zone per unit base value can be greater than that of a supervised zone, in which case the check zones pickup and break point are set proportionally less than the supervised zone's corresponding settings. Failure to configure the settings correctly can result in the fault not tripping; damage can occur.

Figure 20: Double-bus single-breaker arrangement with check zone (in red)




Figure 21: Settings for double-bus single-breaker arrangement with check zone

Bus Differential // Quick Connect: Quick Connect Device: Settings: Protection

Save Restore Default Reset

PARAMETER	Z1	Z2	Z3	Z4	Z5	Z6
ID	BU1	BU2			Check Zone	
General Settings						
Function	Enabled	Enabled	Disabled	Disabled	Enabled	Disabled
Block	OFF	OFF	OFF	OFF	OFF	OFF
Auxiliary Zone Trip	OFF	OFF	OFF	OFF	OFF	OFF
Check-Zone	No	No	No	No	Yes	No
Events	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled
ACTUAL VALUES						
JCT in Zone						

Quick Connect Device | Settings: Protection: General


Bus Sources // Quick Connect: Quick Connect Device: Settings: Protection

Save Restore Default Reset

PARAMETER	F/SRC 2	F/SRC 3	F/SRC 4	F/SRC 5	F/SRC 6
ID	CB3	CB5	CB12 for BU1	CB12 for BU2	CB4
General Settings					
Function	Enabled	Enabled	Enabled	Enabled	Enabled
Block	OFF	OFF	OFF	OFF	OFF
Events	Enabled	Enabled	Enabled	Enabled	Enabled
HMI Template	1	1	2	3	1
CT Settings					
Bus Configuration Settings					
BU1 (Z1) Connection	DS31 Closed	DS51 Closed	DS121 Closed	OFF	DS41 Closed
BU2 (Z2) Connection	DS32 Closed	DS52 Closed	OFF	DS122 Closed	DS42 Closed
BU3 (Z3) Connection	OFF	OFF	OFF	OFF	OFF
BU4 (Z4) Connection	OFF	OFF	OFF	OFF	OFF
Check Zone (Z5) Connection (Z6) Connection	ON	ON	OFF	OFF	ON
Bypass Connection	OFF	OFF	OFF	OFF	OFF
Breaker Open 1	OFF	OFF	OFF	OFF	OFF
Breaker Open 2	OFF	OFF	OFF	OFF	OFF
Breaker Open Delay	0.400 s	0.400 s	0.400 s	0.400 s	0.400 s
Manual Close 1	OFF	OFF	OFF	OFF	OFF
Manual Close 2	OFF	OFF	OFF	OFF	OFF
Bus Trip Settings					
Breaker Failure Inputs					
ACTUAL VALUES					

Quick Connect Device | Settings: Protection: General

Figure 22: Bus Replica Graphical Editor presentation of double bus with check zone



Undervoltage supervision

An alternative or complement to the use of check zones in preventing undesired bus tripping due to hardware failure is the use of undervoltage supervision.

A legitimate bus fault invariably causes a substantial depression of the faulted phase(s). Protection hardware failures that can cause differential operation typically do not result in voltage depression. Undervoltage supervision uses this behavior to block protection hardware failure related to differential operation, but allow tripping for actual power system faults.

Undervoltage supervision has the advantage over check zones in that with a relatively few extra inputs it provides supervision that is independent of the CT inputs used by the individual bus zones. Providing the voltage inputs is typically less expensive than providing redundant CT inputs for a check zone. However, a separate set of three-phase VTs is typically required for each bus segment; in some installations only single-phase bus VTs are available.

Undervoltage supervision is implemented on a bus zone by setting one of its Zone Supervision settings to an operand that becomes On when the voltage of the protected bus segment becomes depressed. Typically, the undervoltage operate operand of one of the voltage sources is used, although there are other possibilities, such as using a remote input driven via GOOSE from an undervoltage element on another device. The other Zone Supervision setting and the Zone Supervision Voting setting must be set appropriately. If the other Zone Supervision setting is not used, set it to OFF and set Zone Supervision Voting to OR.

The undervoltage elements logic is such that when a voltage input is lost, it operates, and unless other measures are taken, the bus zone becomes unsupervised. This is considered superior behavior to forcing the supervision signal to off on loss of voltage input, and thus blocking differential protection.

Zone expansion/reduction and end fault protection

The dynamic bus replica supports a zone expansion/reduction feature that can be optionally used to improve the following under breaker open conditions: bus fault clearance time (in the case of bus side CTs), or bus tripping selectivity (in the case of network element side CTs). The end fault protection can be optionally used to improve under breaker open conditions: low-level bus fault sensitivity (in the case of bus side CTs), or network element protection fault clearance time (in the case of network element side CTs).

When the bus replica developed breaker position indication is open, the bus replica removes the bus source currents from the bus differential. In the case of bus side CTs, this expands the differential measurement zone past the CTs to the open breaker, so the differential can provide instantaneous coverage of faults between the CT and the open breaker. In the case of network element side CTs, this reduces (shrinks) the differential measurement zone from the CTs to the open breaker, so that the differential does not cover and thus does not unnecessarily operate for faults beyond the open breaker.

Again when the bus replica developed breaker position indication is open, the end fault protection operates on detecting current through the CT to the open breaker. In the case of bus-side CTs, the bus source's end fault operate operand can be selected by one of the bus source's Connected Zone Trip settings, to trip the bus as a sensitive backup to the

differential. In the case of network element side CTs, the bus source's end fault operate operand can be communicated (for example using GOOSE) to the network element protection to provide sensitive instantaneous element tripping.

Additional description of the zone expansion/reduction and end fault protection features can be found in the Bus Replica Concept section in the Protection chapter of this manual.

Both the zone expansion/reduction feature and the end fault on a particular bus source are enabled by setting one or both of the bus source's Breaker Open settings to operands that follow the breaker's open position status. To prevent premature feature activation on breaker opening, set the Breaker Open Delay setting such that the breaker main contacts have actually opened before the replica sees breaker open status. To ensure timely feature deactivation on breaker closing, set one or both of the Manual Close settings to operands that follow both manual and auto-reclose breaker close commands.

The correctness of feature operation depends on the correctness of these operands' status. The settings developer can evaluate the advantages of improved protection performance over the limited time and space the feature addresses against the risk of improper or non-operation due to status input error.

Breaker failure

The breaker failure protection is described in the Bus Sources section of the Protection chapter of this document. This section focuses on the role of the bus replica in relation to breaker failure.

In many applications, breaker failure is implemented in the bus protection. In other applications, breaker failure is implemented in the network element protection. This latter implementation is necessary for example where single phase tripping is implemented for the network element, because the breaker failure function does not support single phase tripping. It is also possible for breaker failure to be implemented in both the bus protection and in the network element protection, which allows the breaker failure timing and/or sensitivity to be responsive to the fault location.

Breaker failure initiate

When a bus fault is detected, it is necessary to trip the breakers that are connected to the faulted bus segment and to initiate the breaker failure protections of those breakers. The bus replica automatically and continuously analyses the dynamic configuration of the bus, and when the zone trip bus is activated by the bus segment's differential, it activates the Bkr Trip Init operands of the bus sources of those breakers. The breakers can be tripped and their breaker failure protections initiated by selecting these operands for the breaker tripping field contact outputs and for one of the breaker failure initiates of each the bus sources. Breaker failure in the network element protections can be initiated by communicating these operands values to those protections using for example shared I/O through a Brick or GOOSE over the station bus.

When a network element fault is detected, the network element protection can send breaker failure initiate to the again via shared I/O through a Brick or GOOSE over the station bus. In the the shared input or remote input operand is selected for another of the breaker failure initiate settings of the appropriate bus source.

Breaker failure operate

When a bus breaker's breaker failure protection operates, it is usually deemed necessary to trip the breakers that are at that moment connected to the faulted bus segment(s) that the breaker is connected to, and any other breakers of the network element's trip zone (for example, the far end of a line network element). Actually, if the fault is on the bus, the bus has already been tripped, so in that case it is unnecessary to trip the bus. If the fault is on

the network element, the network element has already been tripped, so in that case it is unnecessary to trip the network element. Usually, however, breaker failure trips both as it is simpler to do so.

To configure the to perform this tripping, the breaker failure operate operand is selected for one of the Connected Zone Trip settings of that breaker failure's bus source and selected to send a trip to the network element protection again via shared I/O through a Brick or GOOSE message over the station bus. Again, the bus replica automatically and continuously analyses the dynamic configuration of the bus, and on activation of any operand selected by a bus source's Connected Zone Trip setting, activates the zone trip bus of any zone that the bus source is at that moment connected to. The zone trip bus in turn activates the Bkr Trip Init operands of the all sources that at that moment are connected to that zone. As mentioned for breaker failure initiate, the Bkr Trip Init operands are configured to trip the breakers.

Breaker failure initiating breaker failure

Note that this scheme results in breaker failure operations initiating itself and initiating breaker failure in other breaker failure protections. The breaker failure has an interlock that prevents this from sealing itself in. Similar interlocks need to be programmed into any breaker failures implemented in network element protection and using the bus replica.

Multilin B95^{Plus} Bus Protection System

Chapter 16: Appendix

This chapter contains information about revisions to this document and includes the product warranty.

Revision history

The tables outline the releases and major changes of this manual.

Table 1: Revision history

Publication number	Part number	Firmware	Release date	ECO
GEK-113629	1601-0015-A1	1.00x	21 March 2012	12-3267
GEK-113657	1601-0015-A2	1.00x	17 August 2012	12-3471

Table 2: Major updates for version A2

Page	Change
Title	Updated contact information and branding
2	Updated contact information in the For Further Assistance section
231	Added a Replace Module section

Warranty

GE Multilin warrants each relay it manufactures to be free from defects in material and workmanship under normal use and service for a period of 24 months from date of shipment from factory.

In the event of a failure covered by warranty, GE Multilin will undertake to repair or replace the relay providing the warrantor determined that it is defective and it is returned with all transportation charges prepaid to an authorized service centre or the factory. Repairs or replacement under warranty will be made without charge.

Warranty shall not apply to any relay which has been subject to misuse, negligence, accident, incorrect installation or use not in accordance with instructions nor any unit that has been altered outside a GE Multilin authorized factory outlet.

GE Multilin is not liable for special, indirect or consequential damages or for loss of profit or for expenses sustained as a result of a relay malfunction, incorrect application or adjustment.

For complete text of Warranty (including limitations and disclaimers), refer to GE Multilin Standard Conditions of Sale.

Multilin B95^{Plus} Bus Protection System

Index

A

Access, unauthorized	209
Actual values	35
Admin account	205
Alarms	
annunciator	190
Brick	218
chatter	219
configure	193
Ethernet ports	219
IRIG-B	219
login	209
remote devices	220
SNTP	220
temperature	219
Altitude	16
Analog input data from Bricks	223
Annunciator	
description	190
operation	190
settings	192
shown on front panel	3
ANSI	5
Approvals	16

B

Breaker failure	
logic diagram	138
model in bus replica	261
Breaker failure settings	132
Brick	
alarms	218
data	222
FlexLogic operands	102
monitoring, trouble	102
overview	6

serial number	228
settings	99
settings, autopopulate	101
voltage source configuration	147
Bus differential	
logic diagram	161
settings	155, 157, 160
status	163
Bus differential logic analog operands	165
Bus differential logic FlexLogic operands	164
Bus modelling using the bus replica	165
Bus parallel definition	119
Bus replica	
definition	165
examples	233, 241
examples, check zones	256
logic diagram	119, 165
Bus source template editor	197
Bus sources	
analog operands	145
breaker failure	132
FlexLogic operands	144
logic diagram	123, 130, 138, 140, 142
settings, bus	125
settings, CT	122
settings, general	121
settings, overcurrent	140, 141
settings, zone trip bus	129
status	142

C

Cautions	1
CE certification	16
Chatter	
alarms	219
settings	105
Check zone	

bus differential settings	156
Check zones	
configure	126
definition	120
model in bus replica	256
modeling	117
Clock time	
internal	221
IRIG-B	94
SNTP	62
Communication logic operands	97
Communications overview	57
Configuration	31, 51
IP addresses	59
Contact GE	2
Current cut-off level	53

D

Damage to the unit	2
Data	
Brick	222
event records	36
raw data viewer	222
transient records	37
view	35
Date and time	
configure using IRIG-B	94
internal	221
IRIG-B	24
SNTP	62
Daylight savings time	95
DC power	21
definition	99
Dielectric strength	16
Digital fault recorder	179
Dimensions	17
DNP	
settings	69
user point list	73

E

Electrical installation	19
End fault protection	
logic diagram	132
model in bus replica	260
settings	131
EnerVista software	
add device/unit	32
Ethernet setup	31
installation	28
USB setup	30
Ethernet	
connect cable	31
connections	23
pinout	31

port monitoring	55
ports	23
settings	57
Ethernet ports	
actual values	66
alarms	219
speed, view	65
Event records	
compare records in software	180
description	179
view	36
view in software	180
view on front panel	180

F

Fault detection, undervoltage detection	145, 152
Field contact input	
chatter	105
FlexLogic operands	105
settings	103
status	104
Field contact output	
definition	107
FlexLogic operands	109
settings	107
status	108
Field latching output	
definition	110
FlexLogic operands	112
settings	110
status	111
Field units, definition	99
File transfer by TFTP	61
Firmware update	230
FlexLogic	
gates	167
introduction	165
operand renaming	211
operands	97
operands for bricks	102
operands for bus differential logic	164
operands for field contact inputs	105
operands for field contact outputs	109
operands for field latching outputs	112
operands for field units	102
operands for shared inputs	116
operands for shared outputs	116
operands, bus sources	144
operands, isolators	177
operands, self-test	220
operands, transient record	188
operands, voltage source	153
operators	168
securing and locking	47
timers	169
Front panel	3, 189
FTP	

configure gateway address	59	Internet, view info over	63
settings	61	IP address	
<hr/>		configure	59
G		SNTP	63
GE, contact	2	view in web browser	63
Getting help	2	view on unit	32
GGIO1 settings	90	IRIG-B	
GOOSE	76	alarms	219
GSSE	76	configure time	94
Guarantee	263	connections	24
<hr/>		specifications	14
H		test	55
HardFiber Brick		ISO 9001 certification	16
alarms	218	Isolators	
data	222	definition	172
overview	6	FlexLogic operands	177
serial number	228	logic diagram	176
settings	99	settings	174
settings, autopopulate	101	status	175
voltage source configuration	147	<hr/>	
HardFiber brick		L	
FlexLogic operands	102	Log in	205
Hardware update	230	Logic diagram	
HMI		Breaker failure	138
display data using metering summary	201	bus differential	161
shown on front panel	3	bus replica	165
HTTP server	63	bus source	130
<hr/>		bus source isolator	176
I		bus sources	123
ICD file	93	bus sources overcurrent	140, 142
IEC 60870-5-104 protocol		end fault protection	132
point lists	75	transient records	183, 185
settings	74	undervoltage	151
IEC 61850		zone trip bus	119
actual values	90	Login alarms	209
GGIO1 settings	90	<hr/>	
GSSE/GOOSE configuration	76	M	
remote devices	76	Metering summary	201
remote inputs	85	Metering values	194
remote outputs	87, 88	Mimic diagram	
server settings	89	definition	197
IED Capability Description file	93	templates	201
In-service, placing unit	52	Modbus protocol	66
Inspection checklist	1	data from other devices	96
Installation	51	settings	67
add device/unit	32	specifications	11
configuration	31	user map	68
connect Ethernet cable	31	Model bus using bus replica	165, 233
connect to unit with USB cable	28	Module withdrawal	231
electrical	19	<hr/>	
error due to driver being blocked	29	N	
software	28	Name	52
system requirements	28	double-point status input	87
		remote device	78, 84

remote input	85
Network settings	57
Nominal frequency	53
Non-volatile latches	
description	169
logic	171
settings	170
Notes	1

O

Operands	
analog bus source	145
analog for bus differential	165
analog voltage source	153
communications	97
Operating temperature	16
Order code in EnerVista software	8
Order code mismatch	217
Order codes	8

P

Password security	
settings	207
Settings files	40
Polarity	125
Ports	
Ethernet	23
shown on rear panel	18
speed	22
Power supply	
connections	21
specifications	14
Product code	8
Program self-tests	54
Programming the unit with FlexLogic	165

R

Rack unit, 19 inch	17
Raw data viewer	222
Rear terminal layout	18
Remote devices	
alarms	220
description	76
settings	78, 84
statistics	92
status	90
Remote double-point status inputs	
operands	97
status	92
Remote DPS input settings	86
Remote inputs	
settings	85
specifications	11

status	91
Remote outputs	
DNA bit pairs	88
specifications	12
UserSt bit pairs	88
Remote resources	99
field units	99
Retrieve button	187

S

Self-tests	
major	217
minor	218
operands	97, 220
Serial number	
Brick	99, 101, 228
Brick mismatch	102
lock FlexLogic equation to	48
view	213
Service	2
Setting group settings	171
Setting templates	
editing	40
enabling	39
security	40
Settings	
annunciator	192
breaker failure	132
Brick	99
bus differential	155, 157, 160
bus sources	121, 122, 125, 129, 140, 141
end fault protection	131
field contact inputs	103
field contact outputs	107
field latching outputs	110
FTP	61
group control	171
isolator	174
shared input	113
shared output	115
transient records	181, 184
voltage sources	146, 147, 150
Settings files	
deploying to multiple devices	38
enabling	39
introduction	37
password	40
template removal	42
template, viewing	41
templates	38
traceability	48
Shared input	
definition	112
FlexLogic operands	116
settings	113
status	114
Shared output	

definition	113
FlexLogic operands	116
settings	115
status	116
Size	17
Slots	
order codes	8
shown on rear panel	18
SNTP	
alarms	220
configure gateway address	59
settings	62
test	55
Specifications	8
Status	
bus differential	163
bus sources	142
field contact outputs	108
field latching outputs	111
isolators	175
shared input	114
shared output	116
voltage sources	151
System requirements	28

T	
Technical support	2
Temperature	
alarms	219
operating	16
Test mode	215
Tests	
program	54
test mode	215
TFTP	61
Time	
internal	221
IRIG-B	24
SNTP	62
Time to live, GOOSE	81, 83
Time zone	94
Transient recorder	
logic	183
settings	184
view records	37
Transient records	
definition	180
digital channels	184
FlexLogic operands	188
logic diagram	183, 185
retrieve button	187
settings	181
view in software	187
view on front panel	186
Typical wiring	20

U	
UL certification	16
Unauthorized access	209
Undervoltage fault detection	145, 152
Undervoltage, model in bus replica	260
Unit Not Programmed	52, 218
Update firmware	230
USB	
connect unit to computer	28
port on front panel	3
User-programmable self-tests	216
Users, add	205

V	
View bus using bus replica	165
Virtual input data from other devices	96
Volt age sources	
settings	147
Voltage cut-off level	54
Voltage fault detection	145, 152
Voltage sources	
analog operands	153
FlexLogic operands	153
logic diagram	151
settings	146, 150
status	151
trouble	152
Voltage transformer settings	147
VT settings	147

W	
Warnings	1
Warranty	263
Web browser use	63
Wiring	20

